



Operation manual

VFD500 Series AC DRIVE

High Performance vector and torque



Preface

Thank you for purchasing the VFD500 series high performance vector and torque control frequency inverter

VFD500 series with advanced functions, such as high-performance vector control of induction motor, user-programmable function and backstage monitoring software, variable communication and supporting multiple PG cards etc. It is applicable to textile, paper making, tension control, wire drawing fans and pumps, machine tools, packaging, food and all kinds of automatic production equipment. Its excellent performance is equivalent and competitive to most of international brand AC drives

This manual introduces functional characteristics and usage of VFD500 series inverter, includes product model selection, parameter settings, running and debugging, maintenance, checking, and so on. Please be sure to read this manual carefully before operation. For equipment matching manufacturers, please send this manual to your end user together with your devices, in order to facilitate the usage.

PRECAUTIONS

- ◆ To describe the product details, the illustrations in the manual sometimes are under the state of removing the outer housing or security covering. While using the product, please be sure to mount the housing or covering as required, and operate in accordance with the contents of manual.
- ◆ The illustrations in this manual is only for explanation, may be different from the products you ordered.
- ◆ Committed to constantly improving the products and features will continue to upgrade, the information provided is subject to change without notice.
- ◆ Please contact with the regional agent or client service center directly of factory if there is any questions during usage.

EDIT : V3.19

TIME : 2025-07

Contents

Chapter 1 Safety Information and Precautions.....	1
1.1 Safety Precautions.....	1
1.2 Precaution.....	2
Chapter 2 Product Information.....	4
2.1 Designation Rules.....	4
2.2 Product series instruction.....	4
2.3 Technical Specification.....	7
Chapter 3 Product appearance and Installation Dimension.....	10
3.1 Product appearance and installation.....	10
3.1.1 Product appearance.....	10
3.1.2 Appearance and Mounting Hole Dimension.....	13
3.1.3 Removal and installation of cover and inlet plate.....	18
3.2 Wiring.....	21
3.2.1 Standard wiring diagram.....	21
3.2.2 Main Circuit Terminals.....	22
3.2.3 Terminal screws and wiring specifications.....	24
3.2.4 Cautions for Main Circuit Wiring.....	25
3.2.5 Control Circuit Terminal.....	26
3.3 EMC question and solution.....	32
Chapter 4 Operation and display.....	34
4.1 LED Instruction of operation and display.....	34
4.2 Display hierarchy and menu mode.....	35
4.3 Digital tube display.....	36
4.4 Test run.....	37
Chapter 5 Function Code Table.....	38
Chapter 6 Fault Diagnosis and Solution.....	121
Chapter 7 Selection Guide of inverter Accessory.....	128
7.1 Selection Guide of braking component.....	128
7.2 PG card type.....	130
7.3 Extension card.....	134
7.4 CANopen extension card.....	136
Chapter 8 Daily maintenance of frequency inverters.....	138
8.1 Daily maintenance.....	138
8.1.1 Daily maintenance.....	138
8.1.2 Regular inspection.....	138
8.2 Wearing parts replacement.....	138
8.3 Warranty Items.....	139
Appendix A Modbus communication protocol.....	140

Chapter 1 Safety Information and Precautions

Safety Definitions: In this manual, safety precautions are divided into the following two categories:



indicates that failure to comply with the notice will result in serious injury or even death











indicates that failure to comply with the notice will result in moderate or minor injury and equipment damage

Read this manual carefully so that you have a thorough understanding. Installation, commissioning or maintenance may be performed in conjunction with this chapter. will assume no liability or responsibility for any injury or loss caused by improper operation.

1.1 Safety Precautions

Use stage	Security Level	Precautions
Before Installation	 DANGER	<ul style="list-style-type: none"> ➤ packing water, parts missing or damaged parts, please do not install! ➤ Packaging logo and physical name does not match, please do not install!
	 WARNING	<ul style="list-style-type: none"> ➤ Handling should be light lift, otherwise there is the danger of damage to equipment! ➤ Do not use damaged drive or missing drive. Risk of injury! ➤ Do not touch the control system components by hand, or there is the danger of electrostatic damage!
During Installation	 DANGER	<ul style="list-style-type: none"> ➤ Please install the flame-retardant objects such as metal, away from combustibles, or may cause a fire!
	 WARNING	<ul style="list-style-type: none"> ➤ Do not allow lead wires or screws to fall into the drive, otherwise the drive may be damaged! ➤ Install the drive in a place where there is less vibration and direct sunlight. ➤ Drive placed in airtight cabinet or confined space, please note the installation of space to ensure the cooling effect.
Wiring	 DANGER	<ul style="list-style-type: none"> ➤ You must follow the guidance of this manual and be used by qualified electrical engineers. Otherwise, unexpected danger may occur! ➤ There must be a circuit breaker between the drive and the power supply, otherwise a fire may occur! ➤ Make sure the power supply is in zero-energy state before wiring, otherwise there is danger of electric shock! ➤ Please follow the standard to the drive properly grounded, otherwise there is the risk of electric shock!
	 WARNING	<ul style="list-style-type: none"> ➤ Never connect input power to the drive's output terminals (U, V, W). Note that the terminal markings, do not take the wrong line! Otherwise, it will cause damage to the drive! ➤ Never connect the braking resistor directly to the DC bus +, - terminals. Otherwise, it will cause a fire! ➤ Refer to the manual's recommendations for the wire diameter used. Otherwise, it may happen accident! ➤ Do not disassemble the connecting cable inside the driver. Otherwise, the internal of the servo driver may be damaged.

Use stage	Security Level	Precautions
Before Power-on	 DANGER	<ul style="list-style-type: none"> ➤ Make sure the voltage level of the input power is the same as the rated voltage of the driver. Check if the wiring position of the power input terminals (R, S, T) and output terminals (U, V, W) is correct; Of the external circuit is short-circuited, the connection is tightened, or cause damage to the drive! ➤ No part of the drive needs to withstand voltage test, the product has been made before the test. Otherwise, it may cause accident!
	 WARNING	<ul style="list-style-type: none"> ➤ The driver must be covered before the cover can be powered, otherwise it may cause electric shock! ➤ All peripheral accessories must be wired according to the instructions in this manual, and be properly wired in accordance with this manual. Otherwise, it may cause accident!
After Power-on	 DANGER	<ul style="list-style-type: none"> ➤ Do not open the cover after power on, otherwise there is danger of electric shock! ➤ If the indicator light does not light after power on, the keyboard does not display the situation, immediately disconnect the power switch, do not touch any input and output terminals of the drive, otherwise there is the risk of electric shock!
	 WARNING	<ul style="list-style-type: none"> ➤ If parameter identification is required, preclude the possibility of injury when rotating the motor! ➤ Do not arbitrarily change the drive manufacturer parameters, or it may cause damage to the device!
During Operation	 DANGER	<ul style="list-style-type: none"> ➤ Do not touch the cooling fan, radiator and discharge resistance to test the temperature, otherwise it may cause burns! ➤ Non-professional technicians Do not detect the signal during operation, otherwise it may cause personal injury or equipment damage!
	 WARNING	<ul style="list-style-type: none"> ➤ Drive operation, should avoid something falling into the device, otherwise it will cause damage to the device! ➤ Do not use the contactor on-off method to control the start and stop the drive, otherwise it will cause damage to the equipment!
Maintenance	 DANGER	<ul style="list-style-type: none"> ➤ Do not live on the equipment repair and maintenance, or there is a risk of electric shock! ➤ Turn off the input power for 10 minutes before performing maintenance and repair on the drive, otherwise the residual charge on the capacitor will cause harm to people! ➤ Do not carry out maintenance and repair on the drive without personnel who have been professionally trained, otherwise personal injury or equipment damage will occur! ➤ All pluggable plug-ins must be unplugged in the case of power failure! ➤ The parameters must be set and checked after replacing the drive.
	 WARNING	<ul style="list-style-type: none"> ➤ Before performing maintenance work on the drive, make sure that the motor is disconnected from the drive to prevent the motor from feeding back power to the drive due to accidental rotation.

1.2 Precaution

• Contactor using

If the contactor is installed on the power input side of the inverter, do not make the contactor frequent on-off operation. The interval between ON and OFF of the contactor should not be less than one hour. Frequent charging and discharging will reduce the use of capacitors in the inverter life.

If a contactor is installed between the inverter output terminals (U, V, W) and the motor, make sure that the inverter is turned on and off when there is no output. Otherwise, the inverter may be damaged.

- **Lightning impulse protection**

Although this series of inverters are equipped with lightning over-current protection device, there is a certain degree of self-protection for inductive lightning, but for lightning frequent place, customers should also install lightning protection device in the front of the inverter.

- **Altitude and derating use**

In areas above 1000m above sea level, it is necessary to derate the inverter due to poor air quality due to poor air quality. In this case, please consult our company.

- **Power input**

The inverter power input should not exceed the operating voltage range specified in this manual. If necessary, use a step-up or step-down device to change the power supply to the specified voltage range.

Do not change the three-phase inverter to two-phase input, otherwise it will cause malfunction or inverter damage.

- **Output filtering**

When the cable length between the inverter and the motor exceeds 100 meters, it is suggested to use the output AC reactor to avoid inverter over-current caused by excessive distributed capacitance. Output filter according to the needs of the field matching.

Inverter output is PWM wave, please do not install the capacitor on the output side to improve the power factor or lightning varistor, etc., otherwise it may easily lead to inverter instantaneous overcurrent or even damage the inverter.

- **About motor heat and noise**

Because the inverter output voltage is PWM wave, contains a certain degree of harmonics, so the motor temperature rise, noise and vibration compared with the same frequency operation will be slightly increased.

- **Disposal**

Electrolytic capacitors on the main circuit and electrolytic capacitors on the printed circuit board may explode when incinerated, and poisonous gases are generated when plastic parts are burned. Please dispose as industrial waste.

- **The scope of application**


This product is not designed and manufactured for use on equipment where life is at stake. To use this product on a mobile, medical, aerospace, nuclear or other special purpose device, please contact our company For more information.

This product is manufactured under strict quality control and should be equipped with a safety device if it is used in a device that may cause a serious accident or damage due to inverter failure.

Chapter 2 Product Information


2.1 Designation Rules

Name plate:



2-1 Name Plate

Model instruction:



2-2Model instruction

2.2 Product series instruction

Table 2-1 VFD500 inverter models and technical data

Model	Power capacity (KVA)	Input current (A)	Output current(A)		Adapt able Motor (KW)	SIZE	Brake Unit
			Heavy load	Light load			
Three phase: 380-480V, 50/60Hz							
VFD500-R75GT4B	1.5	3.4	2.5	4.2	0.75	SIZE A	Internal
VFD500-1R5GT4B	3	5	4.2	5.6	1.5		
VFD500-2R2GT4B	4	5.8	5.6	9.4	2.2		
VFD500-4R0G/5R5PT4B	5.9	10.5	9.4	13.0	3.7		
VFD500-5R5G/7R5PT4B	8.9	14.6	13.0	17.0	5.5	SIZE B	
VFD500-7R5G/011PT4B	11	20.5	17.0	25.0	7.5		
VFD500-011G/015PT4B	17	26.0	25.0	32.0	11	SIZE C	Internal
VFD500-015G/018PT4B	21	35.0	32.0	37.0	15		
VFD500-018G/022PT4B	24	38.5	37.0	45.0	18.5	SIZE D	
VFD500-022G/030PT4B	30	46.5	45.0	60.0	22		
VFD500-030G/037PT4	40	62.0	60.0	75.0	30	SIZE E	optional
VFD500-037G/045PT4	50	76.0	75.0	90.0	37		
VFD500-045G/055PT4	60	92.0	90.0	110.0	45	SIZE F	
VFD500-055G/075PT4	75	113.0	110.0	152.0	55		
VFD500-075G/090PT4	104	157.0	152.0	176.0	75	SIZE G	
VFD500-090G/110PT4	112	170.0	176.0	210.0	90		
VFD500-110G/132PT4	145	220.0	210.0	253.0	110	SIZE H	External
VFD500-132G/160PT4	170	258.0	253.0	304.0	132	SIZE I	
VFD500-160G/185PT4	210	320.0	304.0	360.0	160		
VFD500-185G/200PT4	245	372.0	360.0	380.0	185	SIZE J	
VFD500-200G/220PT4	250	380.0	380.0	426.0	200		
VFD500-220G/250PT4	280	425.0	426.0	465.0	220	SIZE K	
VFD500-250G/280PT4	315	479.0	465.0	520.0	250		
VFD500-280G/315PT4	350	532.0	520.0	585.0	280	SIZE L	

VFD500-315G/355PT4	385	585.0	585.0	650.0	315		
VFD500-355G/400PT4	420	638.0	650.0	725.0	355	SIZE M	
VFD500-400G/450PT4	470	714.0	725.0	820.0	400		
VFD500-450G/500PT4	530	800.0	820.0	/	450	SIZE N	
VFD500-500G/560PT4	580	880.0	900.0	/	500		
VFD500-560G/630PT4	630	950.0	980.0	/	560	SIZE O	
VFD500-630GT4	710	1080	1120.	/	630	SIZE O	
VFD500-710GT4	790	1200	1260	/	710	SIZE O	
Single phase :220V ,50/60HZ							
VFD500-R40GS2B	1.3	6.0	2.5	5.6	0.4	SIZE A	Inbuilt
VFD500-R75GS2B	2.4	11.0	4.2	8.0	0.75	SIZE A	
VFD500-1R5GS2B	3.5	15.0	7.5	10.6	1.5	SIZE A	
VFD500-2R2GS2B	5.5	25.0	9.4	14.0	2.2	SIZE A	
VFD500-4R0GS2B	7.7	35.0	17.0	23.0	4.0	SIZE B	
VFD500-5R5GS2B	8.9	53.0	25.0	31.0	5.5	SIZE C	
VFD500-7R5GS2B	11	67.0	32.0	37.0	7.5	SIZE C	
Three phase 220V ,50/60HZ							
VFD500-R40GT2B	4	6.0	2.5	5.6	0.4	SIZE A	Inbuilt
VFD500-R75GT2B	4	11.0	4.2	8.0	0.75	SIZE A	
VFD500-1R5GT2B	3.5	15.0	7.5	10.6	1.5	SIZE A	
VFD500-2R2GT2B	5.5	25.0	9.4	14.0	2.2	SIZE A	
VFD500-4R0GT2B	11	35.0	17.0	23.0	4.0	SIZE B	
VFD500-5R5GT2B	17	53.0	25.0	31.0	5.5	SIZE C	
VFD500-7R5GT2B	21	67.0	32.0	37.0	7.5	SIZE C	
VFD500-011GT2B	30	46.5	45.0	/	11	SIZE D	Optional
VFD500-015GT2	40	62.0	60.0	/	15	SIZE E	
VFD500-018GT2	50	76.0	75.0	/	18.5	SIZE E	

VFD500-022GT2	60	92.0	90.0	/	22	SIZE F	Optional
VFD500-030GT2	75	113.0	110.0	/	30	SIZE F	
VFD500-037GT2	104	157.0	152.0	/	37	SIZE G	
VFD500-045GT2	112	170.0	176.0	/	45	SIZE G	
VFD500-055GT2	145	220.0	210.0	/	55	SIZE H	External
VFD500-075GT2	145	320.0	304.0	/	75	SIZE I	

Description:

* The built-in brake unit of this model is optional. Take 30kW as an example. The model without brake unit is VFD500-030G/037PT4, and the model with brake unit is VFD500-030G/037PT4B

2.3 Technical Specifications

Table 2-2 VFD500 Technical Specifications

Item		Specification
Input	Input Voltage	1phase/3phase 220V : 200V \sim 240V 3 phase 380V-480V : 380V \sim 480V
	Allowed Voltage fluctuation range	-15% \sim 10%
	Input frequency	50Hz / 60Hz, fluctuation less than 5%
Output	Output Voltage	3phase : 0 \sim input voltage
	Overload capacity	General purpose application : 60S for 150% of the rated current Light load application : 60S for 120% of the rated current
Control	Control mode	V/f control Sensorless flux vector control without PG card (SVC) Sensor speed flux vector control with PG card (VC)
	Operating mode	Speed control、Torque control (SVC and VC)
	Speed range	1:100 (V/f) 1:200(SVC) 1:1000 (VC)
	Speed control accuracy	$\pm 0.5\%$ (V/f) $\pm 0.2\%$ (SVC) $\pm 0.02\%$ (VC)
	Speed response	5Hz(V/f) 20Hz(SVC) 50Hz(VC)
	frequency range	0.00\sim600.00Hz(V/f) 0.00\sim200.00Hz(SVC) 0.00\sim400.00Hz(VC)
	Input frequency resolution	Digital setting: 0.01 Hz Analog setting: maximum frequency x 0.1%
	Startup torque	150%/0.5Hz(V/f) 180%/0.25Hz(SVC) 200%/0Hz(VC)


Item		Specification
	Torque control accuracy	SVC : within 5Hz10%, above 5Hz5% VC:3.0%
	V/f curve	V / f curve type: straight line, multipoint, power function, V / f separation; Torque boost support: Automatic torque boost (factory setting), manual torque boost
	Frequency giving ramp	Support linear and S curve acceleration and deceleration; 4 groups of acceleration and deceleration time, setting range 0.00s ~ 60000s
	DC bus voltage control	Overvoltage stall control: limit the power generation of the motor by adjusting the output frequency to avoid skipping the voltage fault; Undervoltage stall control: control the power consumption of the motor by adjusting the output frequency to avoid yaw failure VdcMax Control: Limit the amount of power generated by the motor by adjusting the output frequency to avoid over-voltage trip; VdcMin control: Control the power consumption of the motor by adjusting the output frequency, to avoid jump undervoltage fault
	Carrier frequency	1kHz ~ 12kHz(Varies depending on the type)
	Startup method	Direct start (can be superimposed DC brake); speed tracking start
	Stop method	Deceleration stop (can be superimposed DC braking); free to stop
	Main control function	Jog control, droop control, up to 16-speed operation, dangerous speed avoidance, swing frequency operation, acceleration and deceleration time switching, VF separation, over excitation braking, process PID control, sleep and wake-up function, built-in simple PLC logic, virtual Input and output terminals, built-in delay unit, built-in comparison unit and logic unit, parameter backup and recovery, perfect fault record, fault reset, two groups of motor parameters free switching, software swap output wiring, terminals UP / DOWN. STO (Safe Torque Off)
Function	Keypad	LED Digital keyboard and LCD keypad(option)
	Communication	Standard: MODBUS communication TCP protocol communication CAN OPEN AND PROFINET
	PG card	Incremental Encoder Interface Card (Differential Output and Open Collector), Rotary Card , frequency division signal pg card
	Input terminal	Standard: 5 digital input terminals, one of which supports high-speed pulse input up to 50kHz; 2 analog input terminals, support 0 ~ 10V voltage input or 0 ~ 20mA current input; Option card: 4 digital input terminals 2 analog input terminals. support-10V-+10V voltage input
	Output terminal	standard: 1 digital output terminal; 1 high-speed pulse output terminal (open collector type), support 0 ~ 50kHz square wave signal output; 1 relay output terminal (second relay is an option) 2 analog output terminals, support 0 ~ 20mAcurrent output or 0 ~ 10V voltage output; Option card: 4 digital output terminals
Protection	Refer to Chapter 6 "Troubleshooting and Countermeasures" for the protection function	
Environment	Installation location	Indoor, no direct sunlight, dust, corrosive gas, combustible gas, oil smoke, vapor, drip or salt.
	Altitude	0-3000m.inverter will be derated if altitude higher than1000m and rated output current will reduce by 1% if altitude increase by 100m

Item		Specification
	Ambient temperature	-10°C~ +40°C, maximum 50°C (derated if the ambient temperature is between 40°C and 50°C) Rated output current decrease by 1.5% if temperature increase by 1°C
	Humidity	Less than 95%RH, without condensing
	Vibration	Less than 5.9 m/s ² (0.6 g)
	Storage temperature	-20°C ~ +60°C
Others	Installation	Wall-mounted, floor-controlled cabinet, transmural
	Protection level	IP20
	cooling method	Forced air cooling
EMC	CE ROHS	Internal EMC filter Complies with EN61800-3 Category C3 3 rd Environment


Chapter 3 Product appearance and Installation Dimension

3.1 Product appearance and installation


3.1.1 Product appearance




3-1-1 0.75kw-15kw




3-1-2 18.5kw-90kw



3-1-3 110kw-250kw



3-1-4 110KW-250KW (With bottom base)



3.1.2 Appearance and Mounting Hole Dimension

◆Keypad and keypad support size

The dimensions of the VFD500 series keypad are shown in Figure 3-1. When installing the keypad on the outside of the control cabinet, use the two screws on the back of the keypad to fix it (right side of Figure 3-1).




Diagram 3-2 KeyPad dimension

If you want to mount keyboard on control cabinet (to prevent the keypad from protruding toward the outside of the control cabinet), use a keypad Bracket. The dimensions of the keypad bracket are shown in Figure 3-2. The dimensions of the mounting diagram and control cabinet are shown in Figure 3-3.




Figure 3-3 Keypad Holder Size (Unit: mm)




Figure 3-4 Keypad support installation diagram and control cabinet processing dimensions

◆ Inverter dimensions and installation dimensions




Figure 3-5 SIZE A to SIZE C(0.75KW-15KW) Dimension




Figure 3-6 SIZE D~G(18.5KW-90KW) Dimension




Figure 3-7 SIZE H~J(110KW-250KW) Dimension

Note: SIZE H~SIZE J (110kw-200kw) standard model without reactor and bottom base Reactor and bottom base for option




Figure 3-8 SIZE K~J(280KW-315KW) Dimension




Figure 3-9 SIZE K~O(315KW-710KW) Dimensions

Table 3-1 VFD500 series appearance and installation dimension

SIZE	Appearance and installation dimensionCmm3									
	A	B	B2	H	H1	H2	W	D	Od	Mounting screws
0.75KW-4KW	87	206.5	/	215	/	/	100	170	ø5.0	M4X16
5.5KW-7.5KW	113	239.5	/	250	/	/	130	180	ø5.0	M4X16
11KW-15KW	153	299	/	310	/	/	170	193	Ø6.0	M5X16
18.5KW-22KW	165	350	/	370	335	/	210	196	Ø6.0	M5X16
30KW-37KW	218	438	/	452.5	424	/	260	230	Ø7.0	M6X16
45KW-55KW	250	535	/	555	520	/	320	275	Ø10.0	M8X20
75KW-90KW	280	620	/	640	605	/	350	290	Ø10.0	M8X20
110KW	280	695	915	715	660	935	370	313	Ø11.0	M8X25
132KW-160KW	280	705	925	725	670	945	360	338	Ø11.0	M8X25
185KW-200KW	360	795	1145	816	762	1166	490	358	Ø11.0	M10X25
220KW-250KW	360	795	1145	816	762	1166	490	358	Ø11.0	M10X25
280KW-315KW	450	1045	1495	1075	1005	1560	550	450	Ø13.0	M12X30
355KW-400KW	630	1013	1425	1045	970	1495	730	450	Ø13	M12×30
450KW-500KW	660	1065	/	1575	1095	/	785	450	Ø13	M12×30
560KW-710KW	620	1130	/	1800	1170	/	1080	500	Ø13	M12×30





Remarks:

(1) B2 and H2 are the installation dimensions when the reactor base is included.



(2) 0d is the diameter of the installation screw hole of the whole machine.

3.1.3 Removal and installation of cover and inlet plate



◆ SIZEA ~ SIZE C (0.75KW-15KW) Removal and installation of cover and inlet plate :


Removal steps	
 <p>Step 1: Open the top cover</p> <ol style="list-style-type: none"> ① Unscrew the screw on the cover ② Lift up the cover ③ Remove the cover from the front 	 <p>Step 2: Take out the inlet board</p> <ol style="list-style-type: none"> ① Hold down the sides of the inlet plate with your thumb and middle finger ② Press to disengage the buckle and pull it out of the board
Installation steps	
 <p>Step 1: Install the inlet board</p> <ol style="list-style-type: none"> ① Put the inlet board from the top down into the mounting position to ensure that the card buckles 	 <p>Step 2: Install the upper cover</p> <ol style="list-style-type: none"> ① Slant the front cover diagonally from the front to the docking station ② Lower the cover plate toward the inlet board ③ Tighten the screws on the cover

◆ SIZE D-G(18.5KW-90KW) Removal and installation of cover :


Removal steps	Installation steps
 <p>① Unscrew the two screws at the bottom of the bottom cover</p> <p>② Remove the cover vertically</p>	 <p>① Close the cover vertically</p> <p>② Tighten the two screws on the bottom of the cover</p>

◆SIZEH ~ SIZE I(110KW-160KW) Removal and installation of cover

 <p>① Unscrew the two screws at the bottom of the cover</p>	 <p>② Hold both sides of the cover with both hands and lift the lower part of the cover</p> <p>③ Push up and lift the entire cover (be careful or you will snap the keyboard cable)</p>
Installation steps	





① Plug in the keyboard line



② buckle the top of the cover

③ Tighten the screws at the bottom of the cover



110kw and above are door-open style

3.2 Wiring

3.2.1 Standard wiring diagram




Diagram 3-10 standard wiring

3.2.2 Main Circuit Terminals

	+	PB	=	R	S	T	U	V	W
DC-LINK				POWER			MOTOR		

Figure 3-11 SIZE A~SIZE C(0.75kw-15kw) Main Circuit Terminal




Figure 3-12 SIZE D 18.5kw-22kw main circuit terminal block diagram




Figure 3-13 SIZE E 30kw-37kw(LEFT)




Figure 3-14 SIZE F~G45kw-90kw(RIGHT)




Figure 3-15 110kw-250kw Main Circuit Terminal Blocks




Figure 3-16 280kw-400kw Main Circuit Terminal Blocks

Table 3-17 Function description of the main circuit terminal of the inverter

Terminal	Function instruction
R、S、T	AC power input terminal, connect three-phase AC power
U、V、W	Inverter AC output terminal, connect three-phase AC motor
+、-	The positive and negative terminals of the internal DC bus are connected to the external brake unit or For common DC bus
P1、P2	P1 and P2 are terminal to Connect DC reactor, short P1 to P2 when DC reactor is not used (P2 is equivalent to "+" of DC bus)
+、PB	Braking resistor connection terminal when built-in brake unit
⊕	Ground terminal, ground
EMC、VDR	Safety capacitor and varistor grounding selection screw (SIZE A~SIZE C EMC screw on the left side of the fuselage)

3.2.3 Terminal screws and wiring specifications

Model number	Power terminal			Ground terminal		
	Screw	Tightening torque (N.m)	Cable diameter (mm ²)	screw	Tightening torque (N.m)	Cable diameter (mm ²)
VFD500-R75GT4B	M3	1.5	2.5	M3	1.5	2.5
VFD500-1R5GT4B	M3	1.5	2.5	M3	1.5	2.5
VFD500-2R2GT4B	M3	1.5	2.5	M3	1.5	2.5
VFD500-4R0G/5R5PT4B	M3	1.5	4	M3	1.5	4
VFD500-5R5G/7R5PT4B	M4	2	6	M4	2	6
VFD500-7R5G/011PT4B	M4	2	6	M4	2	6
VFD500-011G/015PT4B	M5	4	10	M5	4	10
VFD500-015G/018PT4B	M5	4	10	M5	4	10
VFD500-018G/022PT4B	M6	4	10	M6	4	10
VFD500-022G/030PT4B	M6	4	16	M6	4	16
VFD500-030G/037PT4	M8	10	16	M6	5	10
VFD500-037G/045PT4	M8	10	16	M6	5	10
VFD500-045G/055PT4	M8	10	25	M6	5	16
VFD500-055G/075PT4	M8	10	35	M6	5	16
VFD500-075G/090PT4	M10	20	50	M8	8	25
VFD500-090G/110PT4	M10	20	70	M8	8	35
VFD500-110G/132PT4	M10	20	120	M8	10	70
VFD500-132G/160PT4	M12	35	150	M8	10	70
VFD500-160G/185PT4	M12	35	185	M8	10	70
VFD500-185G/200PT4	M12	35	95*2	M10	15	95
VFD500-200G/220PT4	M12	35	95*2	M10	15	95
VFD500-220G/250PT4	M12	35	120*2	M10	15	120
VFD500-250G/280PT4	M12	35	120*2	M10	15	120
VFD500-280G/315PT4	M12	35	150×2	M12	15	120
VFD500-315G/355PT4	M12	35	150×2	M12	15	150
VFD500-355G/400PT4	M12	35	150×2	M12	15	150
VFD500-400G/450PT4	M12	35	185×2	M12	15	185
VFD500-450G/500PT4	M12	35	240×2	M12	15	240
VFD500-500G/560PT4	M12	35	240×2	M12	15	240
VFD500-560G/630PT4	M12	35	185×3	M12	15	185
VFD500-630GT4	M12	35	240×3	M12	15	240
VFD500-710GT4	M12	35	240×3	M12	15	240

Table 3-18 Main circuit cable and screw specifications

3.2.4 Cautions for Main Circuit Wiring

(1) Power Supply Wiring

- ◆ It is forbidden to connect the power cable to the output terminal of the inverter. Otherwise, the internal components of the inverter will be damaged.
- ◆ In order to provide input side overcurrent protection and power outage overhaul convenience, the inverter should be connected to the power supply through circuit breakers and contactors.
- ◆ Please confirm the power phase, the voltage is consistent with the product nameplate, do not match may result in damage to the inverter.

(2) DC wiring

- ◆ Do not connect the braking resistor directly to +, -, which may cause the inverter to be damaged or even fire.
- ◆ When using the external brake unit, pay attention to +, - can not be reversed, otherwise it will cause damage to the inverter and brake unit or even cause a fire.

(3) Motor Wiring

- ◆ It is forbidden to short circuit or ground the inverter output terminal, otherwise the internal components of the inverter will be damaged.
- ◆ Avoid short circuit the output cables or with the inverter enclosure, otherwise there exists the danger of electric shock.
- ◆ It is forbidden to connect the output terminal of the inverter to the capacitor or LC/RC noise filter with phase lead, otherwise, the internal components of the inverter may be damaged.
- ◆ When contactor is installed between the inverter and the motor, it is forbidden to switch on/off the contactor during the running of the inverter, otherwise, there will be large current flowing into the inverter, triggering the inverter protection action.
- ◆ Length of cable between the inverter and motor
If the cable between the inverter and the motor is too long, the higher harmonic leakage current of the output end will produce by adverse impact on the inverter and the peripheral devices. It is suggested that when the motor cable is longer than 100m, output AC reactor be installed. Refer to the following table for the carrier frequency setting.

3.2.5 Control Circuit Terminal




Diagram 3-19 VFD500 control circuit terminal

Table 3-20 VFD500 control circuit terminal instruction

Type	Terminal Symbol	Terminal Name	Terminal function description
Analog input voltage	+10V	Input voltage	10.10V \pm 1%
			Maximum output current:10mA,it provides power supply to external potentiometer with resistance range of:1K Ω ~51K Ω
	GND	Analog ground	Internal isolation from COM
	AI1	Analog input1	Input voltage:0~10V:Impedance 22K Ω ,Maximum input voltage
			Input current:0~20mA:Impedance 500 Ω ,Maximum input current
			Through the jumper switch AI1 0 ~ 10V and 0 ~ 20mA analog input switch, the factory default voltage input.
	AI2	Analog input 2	Input voltage:0~10V:Impedance 22K Ω ,Maximum input voltage
			Input current:0~20mA:Impedance 500 Ω ,Maximum input current
			Through the jumper switch AI1 0 ~ 10V and 0 ~ 20mA analog input switch, the factory default voltage input.
Analog output	AO1	Analog output 1	Output voltage:0~10V:Impedance S10K Ω
			Output current:0~20mA:Impedance 200 Ω ~500 Ω
			Through the jumper switch AO1 0 ~ 10V and 0 ~ 20mA analog output switching, the factory default voltage output.
	AO2	Analog output 2	Output voltage:0~10V:Impedance S10K Ω
			Output current:0~20mA:Impedance 200 Ω ~500 Ω
			Through the jumper switch AO1 0 ~ 10V and 0 ~ 20mA analog output switching, the factory default voltage output.
	GND	Analog ground	Internal isolation from COM
Switch input	+24V	+24V current	24V \pm 10%, Internal isolation from GND
			Maximum output current:200mA
			To provide 24V power supply, generally used as a digital input and output terminal power supply and external sensor power
	PLC	Digital input terminal common	The factory default setting is connected PLC with +24V
			Terminal for on-off input high and low level switch
			When using the external signal to drive DI1~DI5, it will disconnect the connector slip of PLC with the +24V
	COM	+24V ground	Internal isolation from GND
	DI1~DI4	Digital input terminal 1~4	Optocoupler isolation, compatible with bipolar input
			Frequency range : 0~200Hz
			Voltage range : 10V~30V
	HDI	Digital input	Digital input terminal: same as DI1~DI4

	HDI	Digital input terminal /High-speed pulse input	Pulse input frequency input: 0~50KHz
			Voltage range: 10V~30V
Switch output	DO1	Open collector output	Optocoupler isolation
			Voltage range: 0V~24V
			Current range: 0mA ~50mA
	HDO	Open collector output /High-speed pulse output	Open collector output: same as DO1 High-speed pulse output: 0~50KHz
Relay output 1	T1A/T1B/T1C	Relay output	T1A-T1B: normal close
			T1A-T1C: normal open
			Contact rating: AC 250V, 3A; DC 30V, 1A
Relay output2 (optional)	T2A/T2B/T2C	Relay output	T2A-T2B: normal close
			T2A-T2C: normal open
			Contact rating: AC 250V, 3A; DC 30V, 1A
485 port	485+	485 Positive differential signal	Baud rate: 1200/2400/4800/9600/19200/38400/57600/115200bps
	485-	485 Negative differential signal	

Table 3-21 Functional Description of VFD500 Jumper Switch

Name	Function	Defaults
485	485 Termination resistor selection: ON has 100 ohm terminating resistor, OFF is no terminating resistor	OFF
AI1	AI1 analog type selection: V is the voltage input (0 ~ 10V), I is the current input (0 ~ 20mA)	V
AI2	AI2 analog type selection: V is the voltage input (0 ~ 10V), I is the current input (0 ~ 20mA)	V
AO1	AO1 analog type selection: V is the voltage output (0 ~ 10V), I is the current output (0 ~ 20mA)	V
AO2	AO2 analog type selection: V is the voltage output (0 ~ 10V), I is the current output (0 ~ 20mA)	V
PE1	GND ground selection: ON is grounded through the safety capacitor, OFF is not connected	OFF
PE2	COM ground selection: ON is grounded through the safety capacitor, OFF is not connected	OFF

◆ Analog input terminal instructions

The AI1 and AI2 terminals can accept both analog voltage input and analog current input. They can be switched by jumpers "AI1" and "AI2" on the IO board. The connection method and jumper switch configuration are shown in the following figure:




Figure 3-22 Analog input terminal wiring diagram

The AO1 and AO2 terminals support the voltage output (0~10V) and the current output (0~20mA). They are selected by jumpers “AO1” and “AO2” on the IO board. The connection method is as shown in the figure below:






Figure 3-23 Analog output terminal wiring diagram

◆Digital input terminal instructions



A: By internal 24V with NPN mode

B: By internal 24V with PNP mode



C: NPN mode uses external +24V power supply D: PNP mode uses external +24V power supply


3-24 Switching Digital input terminal wiring diagram

Note:

1. If the output of the external controller is a relay contact, it can be regarded as an NPN or PNP type. The "0V" or "VCC" of the external controller in the above figure can be regarded as the common terminal of the relay.
2. When using an external power supply, the shorting link between +24V and PLC must be removed, otherwise the product will be damaged!
3. When using an external power supply, when using HDI, connect the negative pole of the external power supply to COM, otherwise HDI will be invalid!
4. The voltage range of VCC is 10V~30V.

◆Switch output terminal instructions

The multi-function output terminals DO1 and HDO can be powered by the internal +24V power supply of the inverter or an external power supply. The wiring diagram is as follows:



A、Use internal power supply

B、Use external power supply


3-25 Switching digital output terminal wiring diagram

Note:

The multi-function terminal output is an open collector output with a maximum allowable current of 50mA. When using the internal power supply, if the inductive load is driven, an absorption circuit such as an RC snubber circuit or a freewheeling diode should be installed. When adding a freewheeling diode, be sure to confirm the polarity of the diode, otherwise the product will be damaged. For external power supply, connect the negative terminal of the

external power supply to the COM terminal.

◆ 4 RS485 communication terminal instructions



3-16 Multiple inverter RS485 is connected to the host computer for communication

3.3 EMC question and solution

The working principle of the inverter determines that it will certainly produce electromagnetic interference, affecting and interfering with other equipment. In the meantime, the frequency converter usually works under the industrial environment with very strong noise, its internal weak signal is also easily disturbed. For safe and trouble-free operation of the frequency converter, as well as the normal and orderly operation of other equipment, install the equipment according to the following rules.


- Install the input noise filter, the filter to the inverter input power supply side of the wiring should be as short as possible.
- Filter shell and the installation of the cabinet should be a large area of reliable connection, in order to reduce the noise current loop impedance.
- The wiring distance between inverter and motor should be as short as possible. The motor cable adopts 4-core cable. One end of the ground wire is grounded at the inverter side and the other end is connected with the motor case. The motor cable is sheathed into the metal pipe.
- Input power line and output motor line should be far away from each other.
- Easily affected equipment and signal lines should be installed away from the inverter.
- The key signal cable should use shielded cable. It is suggested that the shielded cable layer should be grounded by 360 degree grounding method and set in the metal pipe. As far as possible from the inverter input power cable and output motor cable, if the signal cable must cross the input power cable or output motor cable, the two should be orthogonal.
- When using the analog voltage and current signals for remote frequency setting, double-stranded, shielded and shielded cables should be used, and the shield should be connected to the grounding terminal PE of the inverter. The longest signal cable should not exceed 50 meters.
- The control circuit terminals T1A / T1B / T1C, T2A / T2B / T2C and other control circuit terminals should be separated wiring.
- It is forbidden to short-circuit the shield with other signal lines and equipment.
- When connecting the inductive load device (magnetic contactor, relay, solenoid valve, etc.) to the inverter, be sure to use the surge suppressor on the load device coil.
- Correct and reliable grounding is safe and reliable operation of the foundation:

(1) Inverter will generate leakage current, the greater the carrier frequency, the greater the leakage current. Inverter leakage current greater than 3.5mA, the size of the leakage current by the conditions of use, in order to ensure safety, inverter and motor must be grounded;

(2) Grounding resistance should be less than 10 ohms. Grounding cable diameter requirement, refer to the same type of input and output cables half of the cross-sectional area selection;

(3) Do not share the ground wire with welding machines and other power equipment;

(4) When using more than two inverters, do not make the ground wire loop.



3-27-1 Ground wire connection diagram

- Frequency converter to motor cable length and carrier frequency to maintain the appropriate relationship

When the cable between the inverter and the motor is long, due to the influence of distributed capacitance, it is easy to produce electrical resonance, thus generating a large current so that the inverter over-current protection. It is recommended to install the AC output reactor when the motor cable length exceeds 100 meters. Refer to the following table for carrier frequency setting

Inverter output cable length and carrier frequency table

3-27-2 diagram

Cable length between drive and motor	20m below	50m below	100m below	100m above
Carrier frequency (P22.00)	15kHz below	8kHz below	4kHz below	2kHzbelow

Chapter 4 Operation and display

4.1 LED Instruction of operation and display









LED keyboard consists of 5 digital tubes, 7 lights, 8 keys and a potentiometer; can be used to set the parameters, status monitoring and operation control, LED keyboard shape as shown in Figure 4-1 :












Figure 4-1 Operating panel

Description of indicator


Table 4-1 The name and function of each part of the keyboard

No.	Part	Name	Function
1		Exit	<ul style="list-style-type: none"> • exit menu level
2		Confirmation	<ul style="list-style-type: none"> • Enter the menu interfaces level by level, • confirm the parameter setting and save to EEPROM
3		Increment/Up	<ul style="list-style-type: none"> • The number indicated by the cursor increases by one. • Next function code. • Used to switch the left and right screens while in monitor mode
4		Decrement/Down	<ul style="list-style-type: none"> • The number indicated by the cursor minus one. • The previous function code.
5		Multi-function	<ul style="list-style-type: none"> • Perform function switchover according to the setting of 21.02
6		Shift	<ul style="list-style-type: none"> • Cursor shift. • Monitor Status Displays the next monitor volume. • Switch left and right screens.
7		Run	Start the frequency inverter in the operation panel control mode
8		Stop/Reset	<ul style="list-style-type: none"> • During operation, press to stop the operation (restricted by parameter 21.03). • In fault status, press this key to reset the fault.

9		Indicator light:Hz	Indicate the digital display unit, all three lights off means other units
10		Indicator light:A	
11		Indicator light:V	
12		Indicator light:Hz+A(rpm/minute)	When Hz" and "A" are lit at the same time, the unit of the currently displayed parameter is "RPM PER MINUTE"
13		Indicator light:A+V(%)	When "A" and "V" are lit at the same time, the unit of the currently displayed parameter is "percent".
14		Running lights	<ul style="list-style-type: none"> • Off: indicates a stop condition. • On: indicates inverter is running. • Blinking: Deceleration stopped.
15		Direction indicator	<ul style="list-style-type: none"> • Used to indicate the sign of the variable when the LED is displaying one of the variables listed in 27.02; • In other cases the sign of the output frequency is indicated.
16		Command source indicator	<ul style="list-style-type: none"> • Off: The command source is the keyboard. • On: The command source is terminal. • Blinking: The command source is communication.
17		Fault indicator	<ul style="list-style-type: none"> • When it is on, the drive is faulty.

4.2 Display hierarchy and menu mode

VFD500 digital keyboard display is divided into four layers, from top to bottom are: monitoring status, menu mode selection status, function code selection status, parameter editing / viewing status, as shown in Figure 4-2. In the menu mode selection status, press FUPF or FDOWNF key to select menu mode, press FENTERF to enter



4-2 Keyboard operation diagram

◆ Standard mode (-bSC-)

If visiting access (r00.01) is standard, all the function codes mentioned in this manual are accessible.
the selected menu mode, the following describes several menu modes:

If visiting access (r00.01) is the end user (in the state of user password lock), then only some function code can be accessed.

◆ User-defined mode (-USr-)

In this menu mode, only 20 user-defined parameters defined are displayed.

◆ Verify mode (-vrF-)

In this menu mode, only parameters that differ from the factory settings are displayed.

◆ Guide mode (-GdE-)

When users first use the inverter, can guide the user to complete a simple trial run.

4.3 Digital tube display Display of decimal data 16 digits:

The range of unsigned numbers is 0 ~ 65535 (without decimal point). The displayed range of signed numbers is -9999 ~ 32767 (excluding decimal point). The negative numbers less than -9999 will be displayed as -9999.

32 digits:

The left and right screen display, combined with the following figure to illustrate:



Dot1 is used to distinguish between the left and right screens. On indicates the left panel (upper 5 digits) and turns off the right screen (lower 5 digits). When the left screen is displayed, Dot5 is used to indicate the sign digit. On indicates that the value is negative, off indicates the value is Positive.


The display range of 32-bit unsigned numbers is 0 to 4294967295 (excluding decimal point), and the displayed range of signed numbers is -2147483648 to 2147483647 (excluding the decimal point).

◆ Binary data display

Binary number currently only supports 16 digits, points left and right screen display.


The leftmost digital tube is used to distinguish the left and right screens: the top digit segment lights up for the left panel and the bottom segment lights for the right panel.

Remove the leftmost digital tube, from right to left, followed by Bit0 ~ Bit15. The upper segment is lit to indicate 1, the lower segment to light to indicate 0.



◆ Parameter attribute identification

Editable parameters The leftmost LED displays "P"; the leftmost LED of the read-only parameter displays "r", as shown below.






◆ Specific symbol

In some cases, the digital tube will display a specific symbol. The meaning of specific symbols is shown in the following table: Table 4-2 Digital tube display symbol and meaning

Symbol	Meaning
tUnE	Motor parameter self-learning
bUSY	Processing parameter read and write requests
End	<ul style="list-style-type: none"> Indicates that the parameters have been changed and saved to the EEPROM The mission has been completed
Er.xxx	<ul style="list-style-type: none"> Fault code, "XXX" is the fault type, see Chapter 6 for details

4.4 Test run

Please follow the procedure below to commission the first time power-on



Chapter 5 Function Code Table

The following is the VFD500 parameter distribution list:

Classification	Parameter group	Page
Common parameters	00: Basic function	Page 39
	01: Frequency source selection	Page 41
	02: Start and stop	Page 47
	03: Ramp and S curve	Page 51
	04: Analog and pulse input	Page 53
	05: Analog and pulse output	Page 58
	06: Multi-function Digital input (DI)	Page 59
	07: Multi-function Digital output(DO)	Page 64
	08: Digital Output setting	Page 67
Motor control	10: Encoder type	Page 70
	11: Motor1 parameter	Page 72
	12: Motor1 VF control parameter	Page 74
	13: Motor1 Vector control parameter	Page 77
	14: Torque control	Page 79
	16: Energy saving control	Page 80
Display and protection	20: User-defined parameters	Page 81
	21: Keypad and display	Page 84
	22: AC Drive configuration	Page 87
	23: Drive protection function setting	Page 90
	24: Motor protection parameter	Page 93
	25: Fault tracking parameter	Page 96
	26: Fault recording parameter	Page 96
	27: Monitoring parameter	Page 97
	29: Communication special register	Page 99
Communication	30: Modbus communication	Page 100
	31: Canopen communication	Page 102
	32: Profinet communication	Page 103
Application	40: Process PID Function	Page 104
	41: Sleep function	Page 108
	42: Simple PLC	Page 109
	43: Programmable delay unit	Page 112
	44: Comparator and logic unit/controller	Page 113
	45: Multifunction counter	Page 117
	58: Fire mode	Page 119
Motor 2	60: Motor 2 basic parameter	Page 120
	61: Motor 2 parameter	Page 120
	62: Motor 2 VF control parameter	Page 120
	63: Motor 2 vector control parameter	Page 120

Term Description:

The parameter is also called function code; the operation panel is also called the keyboard.

Due to usage habits, different terms may be used in different places in this manual, but all refer to the same content.

Symbol Description:

"6" means that the setting value of this parameter can be changed when the inverter is stopped or running.


"𐀀" means that the setting value of this parameter can not be changed when the inverter is running.


"●" indicates that the value of this parameter is the actual test record value, which can not be cha

00 Group Basic Function				
Function code	Parameter name	Description	Default	Property
P00.00	User password	<p>0 ~ 65535</p> <p>➤ No user password status after power-on (P00.01=1);</p> <p>The way to set a user password to lock is that Entering the same non-zero value two times in succession</p> <p>➤ Locked status</p> <p>Enter the password to unlock</p> <p>➤ Unlocked status</p> <p>Enter the original password to lock inverter; enter the same value twice in a row to change the password (password will be cleared if you enter 0 two times in a row).</p>	0	☆
P00.01	Access authority	<p>0: END USER</p> <p>Some parameter are not authorized to check when user password in locked state</p> <p>1: Standard</p> <p>ALL Parameter can be checked</p>	1	•
P00.03	RESET	<p>0: NO ACTION</p> <p>11: Restore default parameter except for motor parameter and auto-tune related parameter and factory parameter</p> <p>12: Restore default to factory parameter</p> <p>13: Clear tripping record</p>	0	★
P00.04	Motor Control mode	<p>0: VF</p> <p>1: SVC(sensorless vector control)</p> <p>➤ Open loop vector without encoder feedback and the feedback speed is internally estimated and supports torque control mode.</p> <p>2: VC Vector control with sensor</p> <p>➤ Close loop vector and torque control supporting encoder feedback in high precision or torque control application.</p> <p>The inverter must be equipped with a PG card that matches the encoder. For the relevant parameters of the PG card, please refer to P10 group</p>	0	★

Function code	Parameter name	Description	Default	Property
P00.05	Running mode	0: Speed mode 1: Torque mode ➤ If use with DI function, 19: Switch between torque and speed Control and 20: torque control disabled. Actual effective running mode is related with DI status	0	★
P00.06	Source of the Operation Command	0: keypad 1: terminal 2: communication ➤ Command source: run、 stop、 forward、 reverse、 jog、 fast brake stop.etc ➤ If use with DI function, 12: Switching run command to Keypad and 13: Switching run command to Communication, Actual effective command source is related with DI status	0	★
P00.07	Numeric frequency setting	00.00Hz~maximum frequency(Set P21.17=1 to change the unit to 1Rpm)	50.00Hz	☆
P00.08	Rotation direction	0: Forward 1: Reverse ➤ It is only for keypad control to change running direction by giving frequency symbol to be reverse)If command by keypad/terminal /communication, and not want to achieve reverse running by giving frequency symbol to be reverse, need to change P22.13 in stop mode(see parameter P22.13)	0	☆
P00.09	Reverse control	0: enable 1: disable	0	★
P00.10	Motor option	0: motor 1 1: motor 2 If use with DI function, 16: Switch between motor 1 and motor 2, Actual effective command source is related with DI status	0	★
P00.11	Special industry	0: standard drive 1: Reserved	0	★
r00.18	Power board software version	-	-	•
r00.19	Control board software version	-	-	•
r00.21	SN 1	-	-	•
r00.22	SN 2	-	-	•

01Group frequency source selection				
Function code	Parameter name	Description	Default	Property
P01.00	Main frequency source selection (A)	0: Digital setting(P00.07) 1: AI1 2: AI2 3: AI3(IO extension card) 4: Reserved 5: HDI 6: multi-step speed 7: communication 8: PID 9: Internal PLC Notice: DI terminal function code 26-32 superior than this function code	0	★
P01.01	Auxiliary frequency source selection (B)	Same as P01.00 Notice: DI terminal function code 33 superior than this function code	0	★
P01.02	Reference option for auxiliary frequency source	0: Relative to Maximum frequency 1: Relative to main frequency	0	★
P01.03	Auxiliary frequency gains	0.0~300.0	100.0%	☆
P01.04	Frequency source selection	0: main frequency source A 1: auxiliary frequency source B 2: Main and auxiliary arithmetic results 3: Switchover between main and auxiliary frequency 4: switchover between main frequency source A and A+B Arithmetic results 5: Switchover between B and (A+B) C*3DI function code 25 effective to corresponding terminal ,frequency will adopt the latter	0	★
P01.05	Main and Auxiliary arithmetic	0: A+B 1: A-B 2: The bigger of main A and Auxiliary B 3: The smaller of Main A and Auxiliary B 4: A*B A*B have better frequency adjustment ,widely used for winding industry, fine sand machine, and leather, paper industry...	0	★
P01.06	Maximum frequency	10.00~600.00Hz	50.00Hz	★
P01.07	Upper limit frequency control	0: digital setting (set through P01.08) 1: AI1 2: AI2	0	★

Function code	Parameter name	Description	Default	Property
		3: Reserved 4: Reserved 5: Pulse setting HDI 6: Reserved 7: Communication setting		
P01.08	Upper limit frequency	Lower limit frequency(P01.09)~maximum frequency (P01.06)	50.00Hz	☆
P01.09	Lower limit frequency	0.00Hz~upper limit frequency	0.00Hz	☆
P01.10	Action when set frequency lower than lower limit frequency	0: Run at low limit frequency 1: Stop after delaying P01.11 2: Run at zero speed The inverter will coast to stop when the set frequency is lower than the lower-limit one. if the set frequency is above the lower limit one again and it lasts for the time set by P01.11, the inverter will come back to the running state automatically.	0	★
P01.11	Delay time when set frequency lower than lower limit frequency	0.000s~30.000s This function code determines the hibernation delay time. When the running frequency of the inverter is lower than the lower limit one, the inverter will stop to stand by. When the set frequency is above the lower limit one again and it lasts for the time set by P01.11, the inverter will run automatically.  <p>▲ Output frequency</p> <p>t1<t2, so the inverter does not work t1+t2=t3, so the inverter works t3=P01.20</p> <p>Running Dormancy Running</p> <p>Time</p>	0.000s	★
P01.12	Jump frequency start up protection	Unit/ten/hundred' digit: three jump frequency 1/2/3 0: Disable 1: Enable (avoid risk speed)	000	☆
P01.13	Jump frequency 1 lower limit	0.00Hz~(P01.14)	0.00Hz	☆
P01.14	Jump frequency upper limit	P01.13- (P01.06)Maximum frequency	0.00Hz	☆
P01.15	Jump frequency 2 lower limit	0.00Hz~(P01.16)	0.00Hz	☆

Function code	Parameter name	Description	Default	Property
P01.16	Jump frequency 2 upper limit	P01.15~maximum frequency(P01.06)	0.00Hz	☆
P01.17	Jump frequency 3 lower limit	0.00Hz~(P01.18)	0.00Hz	☆
P01.18	Jump frequency 3 upper limit	P01.17~maximum frequency(P01.06)	0.00Hz	☆
<p>Risk speed or Jump frequency start up protection is used to some situation which need avoid motor speed and speed range, for example, due to mechanical resonance ,P01.12 will be enabled to avoid risk speed in forward or reverse mode .</p> 				
P01.19	Multi-step speed reference source	Unit'digit: 0 phase reference source set by 0-multi-step speed(P01.21) 1-preset frequency (P00.07) 2:AI1 3:AI2 4:AI3(IO expansion board) 5:Reserved 6:HDI pulse 7:Communication 8:PID Ten's digit: Combination of multiple speed 0:Combination method 1:Priority method	00	★

Combination method Description:


Multispeed terminal 4	Multispeed terminal 3	Multispeed terminal 2	Multispeed terminal 1	Combination method Speed reference
Ineffective	Ineffective	Ineffective	Ineffective	Multispeed 0
Ineffective	Ineffective	Ineffective	effective	Multispeed 1
Ineffective	Ineffective	effective	Ineffective	Multispeed 2
Ineffective	Ineffective	effective	effective	Multispeed 3
Ineffective	effective	Ineffective	Ineffective	Multispeed 4
Ineffective	effective	Ineffective	effective	Multispeed 5
Ineffective	effective	effective	Ineffective	Multispeed 6
Ineffective	effective	effective	effective	Multispeed 7
effective	Ineffective	Ineffective	Ineffective	Multispeed 8
effective	Ineffective	Ineffective	effective	Multispeed 9
effective	Ineffective	effective	Ineffective	Multispeed 10
effective	Ineffective	effective	effective	Multispeed 11
effective	effective	Ineffective	Ineffective	Multispeed 12
effective	effective	Ineffective	effective	Multispeed 13
effective	effective	effective	Ineffective	Multispeed 14
effective	effective	effective	effective	Multispeed 15

Priority method Description:

Multispeed terminal 4	Multispeed terminal 3	Multispeed terminal 2	Multispeed terminal 1	Priority method Speed reference
Ineffective	Ineffective	Ineffective	Ineffective	Multispeed 0
Ineffective	Ineffective	Ineffective	effective	Multispeed 1
Ineffective	Ineffective	effective	random	Multispeed 2
Ineffective	effective	random	random	Multispeed 3
effective	random	random	random	Multispeed 4

Function code	Parameter name	Description	Default	Property
P01.20	Multiple step speed Rotation direction	Bit0~ 15 corresponding to 0 ~ 15 phase direction (P01.21-P01.36) 0:forward direction 1:reverse direction	0	☆
P01.21	Multiple step speed 0/in-built plc 1	Lower limit frequency (P01.09) ~maximum frequency(P01.06) Note: When the unit's digit of P01.19 is set to non-zero, this setting is invalid.	0.00Hz	☆
P01.22	Multiple step speed 1/in-built plc 2	Lower limit frequency(P01.09)~maximum frequency(P01.06)	0.00Hz	☆
P01.23	Multiple step speed 2/in-built plc 3	Lower limit frequency(P01.09) ~maximum frequency(P01.06)	0.00Hz	☆
P01.24	Multiple step speed 3/in-built plc 4	Lower limit frequency(P01.09) ~maximum frequency(P01.06)	0.00Hz	☆
P01.25	Multiple step speed 4/in-built plc 5	Lower limit frequency(P01.09) ~maximum frequency(P01.06)	0.00Hz	☆

Function code	Parameter name	Description	Default	Property
P01.26	Multiple-step speed 5/in-built plc 6	Lower limit frequency(P01.09) ~ maximum frequency(P01.06)	0.00Hz	☆
P01.27	Multiple step speed 6/in-built plc 7	Lower limit frequency(P01.09) ~ maximum frequency(P01.06)	0.00Hz	☆
P01.28	Multiple step speed 7/in-built plc 8	Lower limit frequency(P01.09) ~ maximum frequency(P01.06)	0.00Hz	☆
P01.29	Multiple step speed 8/in-built plc 9	Lower limit frequency(P01.09) ~ maximum frequency(P01.06)	0.00Hz	☆
P01.30	Multiple step speed 9/in-built plc 10	Lower limit frequency(P01.09) ~ maximum frequency(P01.06)	0.00Hz	☆
P01.31	Multiple step speed 10/in-built plc 11	Lower limit frequency(P01.09) ~ maximum frequency(P01.06)	0.00Hz	☆
P01.32	Multiple step speed 11/in-built plc 12	Lower limit frequency(P01.09) ~ maximum frequency(P01.06)	0.00Hz	☆
P01.33	Multiple step speed 12/in-built plc 13	Lower limit frequency(P01.09)~maximum frequency(P01.06)	0.00Hz	☆
P01.34	Multiple step speed 13/in-built plc 14	Lower limit frequency(P01.09)~maximum frequency(P01.06)	0.00Hz	☆
P01.35	Multiple step speed 14/in-built plc 15	Lower limit frequency(P01.09)~maximum frequency(P01.06)	0.00Hz	☆
P01.36	Multiple step speed 15/in-built plc 16	Lower limit frequency(P01.09)~maximum frequency(P01.06)	0.00Hz	☆
P01.37	Jog frequency	0.00Hz~maximum frequency(P01.06)	5.00Hz	☆
P01.38	Jog command when running	0: not responsive 1: responsive	0	★
P01.39	UP/DOWN rates	0.00(auto rates)~600.00Hz/s	1.00Hz/s	☆
P01.40	TERMINAL UP AND DOWN CONTROL	Unit'digit: 0:Zero clearing in non-running 1:Zero cleaning when UP/DOWN command not effective 2:Not zero cleaning (decide by remembering digit when power failure) Ten's digit: 0:Non-zero cleaning at power failure 1:Save at power failure UP/DOWN offset Hundred's digit: UP/DOWN near to zero 0: Forbidden 1:Enable Thousand's digit up and down action mode 0:Superposition 1:Gain effect	0002	★
P01.41	Droop control gains	0.00~1.00 Rotation speed drop value based on Rated load (relative to maximum frequency)	0.00	☆

Function code	Parameter name	Description	Default	Property
		Frequency drop volume: Max frequency*P01.41*Current load/rated load		
P01.42	Droop control filtering time	0.000s~10.000s	0.050s	☆
<p>When several motors drive the same load, each motor's load is different because of the difference of motor's rated speed. The load of different motors can be balanced through droop control function which makes the speed droop along with load increase.</p> <p>When the motor outputs rated torque, actual frequency drop is equal to P1.41. User can adjust this parameter from small to big gradually during commissioning.</p>				
P01.43	Textile frequency setting	0: relative to center of textile frequency 1: relative to maximum frequency	0	☆
P01.44	Textile frequency	0.0%~100% relative to center of textile frequency P01.43 = 0: Textile frequency $A_w = P01.44 * \text{center frequency}$ P01.43 = 1: Textile frequency $A_w = P01.44 * \text{max frequency}$	0.0%	☆
P01.45	Jump frequency	0.0%~50.0% relative to textile frequency	0.0%	☆
P01.46	Textile period	0.1s~3000.0s	10.0s	☆
P01.47	Triangle wave rising time coefficient	0.1%~100.0% relative to textile period	50.0%	☆
<p>This function is mostly used in textile and chemical industry and some application such as traversing and winding so it is used for balancing the workload allocation when multiple motors are used to drive the same load. The output frequency of the frequency inverters decreases as the load increases. You can reduce the workload of the motor under load by decreasing the output frequency for this motor, implementing workload balancing among multiple motors. P01.44 or P01.46=0, This function disable</p> 				
P01.48	Auxiliary frequency effective threshold	When the main frequency S this setting, the auxiliary frequency will be effective	0.00Hz	☆

02 Group Start and stop Control				
Function code	Parameter name	Description	Default	Property
P02.00	Starting mode	0: Direct start Inverter will start from P02.01, After P02.02, It will go to setting frequency as per S curve 1: Speed tracking/Searching Inverter will do search for motor speed and recognize and accelerate and decelerate to setting frequency. See Parameter P02.16- P02.19 The direction and speed will be tracked automatically for the smoothing starting of rotating motors. It suits the application with reverse rotation when big load starting.	0	★
P02.01	Startup frequency	0.00Hz~10.00Hz	0.00Hz	★
P02.02	Startup frequency holding time	0.000s~10.000s	0.000s	★
P02.04	Pre-excitation current	0%~200% motor rated current	Depend	★
P02.05	Pre-excitation time	0.00s~10.00s Pre-excitation enable Asynchronous motor for magnetic field for higher starting torque	Depend	★
P02.06	DC brake current at start-up	0~200% motor rated current	100%	☆
P02.07	DC brake time at start-up	0.000s~30.000s No start DC brake when set to 0s	0.000s	★
<p>DC braking is used to make the running motor stop & restart. Pre-excitation is used to establish asynchronous motor magnetic field, then start, improve the response speed.</p> <p>DC braking is only valid when start directly, the inverter performs DC braking according to P02-06 firstly, and runs after P02-07. If DC braking time is 0, the inverter starts directly. The bigger the DC braking current is, the greater the braking force</p> <p>If the start mode is pre-excitation start, then the inverter establishes magnetic field according to the set pre-excitation current firstly, runs after the set pre-excitation time. If the pre-excitation time is 0, the inverter starts directly.</p> <p>DC braking current before start/pre-excitation current refers to the percentage of the inverter rated current.</p>				

Function code	Parameter name	Description	Default	Property
P02.08	Stop method	<p>0:ramp to stop after the stop command becomes valid, the inverter decelerates to reduce the output frequency during the set time. When the frequency decreases to 0Hz, the inverter stops.</p> <p>1:free coast to stop after the stop command becomes valid, the inverter ceases the output immediately. And the load coasts to stop at the mechanical inertia.</p>	0	☆
P02.09	Startup frequency of DC brake at stop	<p>0.00Hz~50.00Hz start the DC braking when running frequency reaches starting frequency determined by P02.09.</p>	1.00Hz	★
P02.10	DC braking current at stop	<p>0~200% motor rated current(Maximum value not higher than drive rated current) the value of P02.10 is the percentage of rated current of inverter. The bigger the DC braking current is, the greater the braking torque is DC braking time: the retention time of DC braking. If the time is 0, the DC braking is invalid. The inverter will stop at the set deceleration time.</p>	100%	☆
P02.11	DC brake time at stop	<p>0.000s~30.000s Inverters blocks the output before starting the DC braking. After this waiting time, the DC braking will be started so as to prevent over-current fault caused by DC braking at high speed.</p>	0.000s	★

Function code	Parameter name	Description	Default	Property
P02.12	Magnetic flux brake gain	<p>1.00~1.50</p> <p>Over excitation braking convert some kinetic energy to motor heating by increasing motor excitation. value 1 means ineffective: value higher better performance but output current bigger</p> <p>This inverter can slow down the motor by increasing the magnetic flux. The energy generated by the motor during braking can be transformed into heat energy by increasing the magnetic flux. The inverter monitors the state of the motor continuously even during the magnetic flux period. So the magnetic flux can be used in the motor stop, as well as to change the rotation speed of the motor. Its other advantages are:</p> <p>Brake immediately after the stop command. It does not need to wait the magnetic flux weaken.</p> <p>The cooling is better. The current of the stator other than the rotor increases during magnetic flux braking, while the cooling of the stator is more effective than the rotor.</p>	1.00	★
P02.13	Delaying frequency at stop	0.00Hz~20.00Hz	0.50Hz	★
P02.14	Delaying time at stop	<p>0.000s~60.000s</p> <p>0.000s:no function for delaying time at stop >0.000s:it is effective, when output frequency decrease lower than delaying frequency at stop (P02.13),inverter will block pulse output after delaying time at stop (P02.14).if run command comes during delaying time, inverter will restart.it is useful to some application with jog function</p>	0.000s	★
P02.15	The minimum blocking time after free stop	0.010s~30.000s	Depend	★
P02.16	Speed tracking mode	<p>Unit's digit:tracking mode</p> <p>0 : Speed tracking for maximum output frequency</p> <p>1:Speed tracking for frequency at stop 2:Speed tracking for grid frequency Ten's digit:direction choosing</p> <p>0:only search at given frequency direction</p>	00	★

Function code	Parameter name	Description	Default	Property
		1:search on the other direction when failed for given frequency tracking		
P02.17	Deceleration time for speed search	0.1s~20.0s	2.0s	★
P02.18	Current for speed search	10%~150% drive rated current	40%	★
P02.19	Speed search compensation factor	0.00~10.00	1.00	★

03 Group Ramp and S curve				
Function code	Parameter name	Description	Default	Property
P03.00	Acceleration and deceleration curve selection	0: linear 1: S curve A 2: S curve B	0	★
<p>Acceleration and deceleration curve, also known as "Ramp Frequency Generator (RFG)", is used to smooth the frequency command. VFD500 supports the following acceleration and deceleration curve:</p> <p>0: linear acceleration / deceleration</p> <p>The output changes at a constant acceleration or deceleration. Acceleration time refers to the time from when the inverter accelerates from zero to the reference frequency (selected by P03.15); deceleration time refers to the time required to decelerate from the reference frequency to zero.</p> <p>1: S curve method</p> <p>This acceleration and deceleration curve acceleration "a" changes in a ramp, start and stop relatively flat. Acceleration and deceleration process as shown below, Tacc and Tdec for the set acceleration and deceleration time.</p> <p>The acceleration and deceleration curve of the equivalent acceleration and deceleration time:</p> <p>Acceleration time = $T_{acc} + (T_{s1} + T_{s2}) / 2$</p> <p>Deceleration time = $T_{dec} + (T_{s3} + T_{s4}) / 2$</p> <div style="text-align: center;"> <p>The graph illustrates the S-curve method for acceleration and deceleration. The vertical axis represents 'Output frequency recommend' and the horizontal axis represents time 't'. The acceleration curve starts at the origin, rises with a constant slope (T_acc), and then levels off. The deceleration curve starts at a peak frequency and falls with a constant slope (T_dec) until it reaches zero. The acceleration phase is divided into two segments, T_s1 and T_s2, and the deceleration phase is divided into two segments, T_s3 and T_s4.</p> </div> <p>2: S curve method B</p> <p>The time of this S-curve is defined as in the method A except that in the acceleration / deceleration process, if the target frequency suddenly approaches or the acceleration / deceleration time changes, the S-curve is re-planned. In addition, when the target frequency changes, the S Curves avoid "overshoot" as much as possible.</p>				
P03.01	Acceleration time 1	Setting value depend on P03.16 P03.16 = 2, 0.00~600.00s; P03.16 = 1, 0.0s~6000.0s; P03.16 = 0, 0s~60000s	Depend on model	☆
P03.02	Deceleration time 1	Setting value depend on P03.16 P03.16 = 2, 0.00~600.00s; P03.16 = 1, 0.0s~6000.0s; P03.16 = 0, 0s~60000s	Depend on model	☆
P03.03	Acceleration time2	0.01~60000s same as P03.01	Depend on model	☆
P03.04	Deceleration time2	0.01~60000s same as P03.02	Depend on model	☆
P03.05	Acceleration time3	0.01~60000s same as P03.01	Depend on model	☆


Function code	Parameter name	Description	Default	Property
P03.06	Deceleration time3	0.01~60000s same as P03.02	Depend on model	☆
P03.07	Acceleration time4	0.01~60000s same as P03.01	Depend on model	☆
P03.08	Deceleration time4	0.01~60000s same as P03.02	Depend on model	☆

The VFD500 provides four groups of acceleration and deceleration time. The actual acceleration / deceleration time can be selected by different methods such as DI terminal, output frequency and PLC running segments. Several methods can not be used at the same time. Factory default is to use acceleration / deceleration time

1. DI terminal select acceleration and deceleration time of the mapping table is as follows::

Acceleration and deceleration time DI terminal 2	Acceleration and deceleration time DI terminal 1	Acceleration and deceleration time
Ineffective	Ineffective	Acceleration and deceleration time terminal 1(P03.01,P03.02)
Ineffective	Effective	Acceleration and deceleration time terminal 2(P03.03,P03.04)
Effective	Ineffective	Acceleration and deceleration time terminal 3(P03.05,P03.06)
Effective	Effective	Acceleration and deceleration time terminal 4(P03.07,P03.08)

The schematic diagram of selecting acceleration / deceleration time according to the output frequency is as follows:




Other ways to select acceleration / deceleration time can be found in the description of relevant parameters.

P03.09	Jog Acceleration time	Time Setting same as P03.01	6.00s	☆
P03.10	Jog Deceleration time	Time Setting same as P03.02	10.00s	☆
P03.11	S-curve Acceleration begin time	Setting value depend on P03.16 P03.16 = 2, 0.01~30.00s; P03.16 = 1, 0.1s~300.0s; P03.16 = 0, 1s~3000s	0.50s	☆
P03.12	S-curve Acceleration arrival time	SAME AS P03.11	0.50s	☆
P03.13	S-curve Deceleration begin time	SAME AS P03.11	0.50s	☆


Function code	Parameter name	Description		Default	Property
P03.14	S-curve Deceleration Arrival time	SAME AS P03.11		0.50s	☆
P03.15	Accel and Decel time frequency benchmark	0: Maximum frequency 1: Motor rated frequency		0	★
P03.16	Accel and Decel time unit selection	0: 1s 1: 0.1s 2: 0.01s		2	★
P03.17	Quickstop deceleration time	The value range is determined by P03.16		5.00s	☆
P03.18	Switching frequency 1 in acceleration time	0.00Hz~maximum frequency(P01.06)		0.00Hz	☆
P03.19	Switching frequency 1 in deceleration time	0.00Hz~maximum frequency(P01.06)		0.00Hz	☆
P03.20	Forward/reverse Dead band time	0.00s~30.00s Waiting time for zero speed during forward and reverse switchover		0.00s	★
04 Group Analog and Pulse input					
P04.00	Minimum input pulse frequency	0.00kHz ~ 50.00kHz	<div>Corresponding setting</div> <div>HDI input frequency</div>	1.00kHz	☆
P04.01	Maximum input pulse frequency	0.00kHz ~ 50.00kHz		30.00kHz	☆
P04.02	Setting Corresponding to Minimum input	- 100.0%~ 100.0%		0.0%	☆
P04.03	Setting Corresponding to maximum input	- 100.0%~ 100.0%		100.0%	☆
P04.04	Pulse input filter time	0.000s~10.000s		0.050s	☆
r04.05	Pulse input frequency	0.00kHz~50.00kHz(it is used to check HDI pulse input frequency)		-	●
r04.06	HDI equivalent value	-100.0%~100.0%(it is used to View the output of the HDI mapping curve)		-	●
P04.07	AI 1 Curve setting	Unit's : AI curve selection 0: curve A 1: curve B 2: Curve C 3: Curve D Ten'unit: when input signal lower than minimum input 0: equal to minimum input 1: equal to 0.0%		00	★
P04.08	AI1 filter time	0.000s~10.000s		0.100s	☆

Function code	Parameter name	Description	Default	Property
r04.09	AI 1 actual value	0.00V~10.00V (it is used to view the port voltage of AI1. When AI1 is a current type (0~20mA) input, multiplying this value by 2 is the input current (mA) of the AI1 port.)	-	●
r04.10	AI 1 Conversion value	-100.0%~100.0%(It is used to view the output of the AI1 mapped curve)	-	●
P04.11	AI 2 Curve setting	Unit's : AI curve selection 0: curve A 1: curve B 2: Curve C 3: Curve D Ten'unit: when input signal lower than minimum input 0: equal to minimum input 1: equal to 0.0%	01	★
P04.12	AI2 filter time	0.000s~10.000s	0.100s	☆
r04.13	AI 2 actual value	0.00V~10.00V (it is used to view the port voltage of AI2. When AI2 is a current type (0~20mA) input, multiplying this value by 2 is the input current (mA) of the AI2 port.)	-	●
r04.14	AI 2 Conversion value	-100.0%~100.0%(It is used to view the output of the AI2 mapped curve)	-	●
P04.15	AI 3(option card) Curve setting	Unit's : AI curve selection 0: curve A 1: curve B 2: Curve C 3: Curve D Ten'unit: when input signal lower than minimum input 0: equal to minimum input 1: equal to 0.0%	02	★
P04.16	AI3 (option card) filter time	0.000s~10.000s	0.100s	☆
r04.17	AI3(option card) actual value	0.00V~10.00V (it is used to view the port voltage of AI3. When AI3 is a current type (0~20mA) input, multiplying this value by 2 is the input current (mA) of the AI3 port.)	-	●
r04.18	AI3(option card) Conversion value	-100.0%~100.0%(It is used to view the output of the AI3 mapped curve)	-	●
P04.19	AI 4(option card) Curve setting	Unit's : AI curve selection 0: curve A 1: curve B 2: Curve C 3: Curve D Ten'unit: when input signal lower than minimum input 0: equal to minimum input 1: equal to 0.0%	03	★
P04.20	AI4(option card) filter time	0.000s~10.000s	0.100s	☆

Function code	Parameter name	Description		Default	Property
r04.21	AI4(option card) actual value	0.00V~10.00V (it is used to view the port voltage of AI4. When AI4 is a current type (0~20mA) input, multiplying this value by 2 is the input current (mA) of the AI4 port.)		-	●
r04.22	AI4(option card) Conversion value	-100.0%~100.0%(It is used to view the output of the AI4 mapped curve)		-	●
P04.23	Curve A horizontal axis 1	0.00V~ P04.25	 <p>Note: input less than P04.23,output decided by curve ten's digit</p>	0.00V	☆
P04.24	Curve A vertical axis 1	- 100.0% ~ 100.0%		0.0%	☆
P04.25	Curve A horizontal axis 2	P04.23 ~ 10.00V		10.00V	☆
P04.26	Curve A vertical axis 2	- 100.0% ~ 100.0%		100.0%	☆



Setting method mode for AI1 4~20mA form

1. Switch the corresponding AI1 jumper on the IO board to current;
2. Set the function code: P04.07 Unit's place=0 (default), P04.23=2.00.

P04.27	Curve B horizontal axis 1	0.00V~ P04.29	 <p>if you want to use 4-20MA,Set 04.27=2.00V Note: input less than P04.27,output decide by curve ten's digit</p>	0.00V	☆
P04.28	Curve B vertical axis 1	100.0% ~ 100.0%		0.0%	☆
P04.29	Curve B horizontal axis 2	P04.27 ~ 10.00V		10.00V	☆
P04.30	Curve B vertical axis 2	- 100.0% ~ 100.0%		100.0%	☆

Setting method mode for AI2 4~20mA form

1. Switch the corresponding AI1 jumper on the IO board to current;
2. Set the function code: P04.11 one place=1 (default), P04.27=2.00

Function code	Parameter name	Description		Default	Property
P04.31	Curve C horizontal axis 1	0.00V~ P04.33	<p>Corresponding setting</p>  <p>Note: Input less than P04.31,output decided by curve ten's digit</p>	0.00V	☆
P04.32	Curve C vertical axis 1	100.0%~ ~100.0%		0.0%	☆
P04.33	Curve C horizontal axis 2	P04.31~ ~P04.35		3.00V	☆
P04.34	Curve C vertical axis 2	100.0%~ ~100.0%		30.0%	☆
P04.35	Curve C horizontal axis 3	P04.33~ ~P04.37		6.00V	☆
P04.36	Curve C vertical axis 3	- 100.0%~ ~100.0%		60.0%	☆
P04.37	Curve C horizontal axis 4	P04.35~ ~10.00V		10.00V	☆
P04.38	Curve C vertical axis 4	- 100.0%~ ~100.0%		100.0%	☆
P04.39	Curve D horizontal axis 1	0.00V~ P04.41	<p>Corresponding setting</p>  <p>Note: Input less than P04.39,output decided by curve ten's digit</p>	0.00V	☆
P04.40	Curve D vertical axis 1	- 100.0%~ ~100.0%		0.0%	☆

Function code	Parameter name	Description		Default	Property
P04.41	Curve D horizontal axis 2	P04.39 ~P04.43		3.00V	☆
P04.42	Curve D vertical axis 2	- 100.0% ~100.0%		30.0%	☆
P04.43	Curve D horizontal axis 3	P04.41 ~P04.45		6.00V	☆
P04.44	Curve D vertical axis 3	- 100.0% ~100.0%		60.0%	☆
P04.45	Curve D horizontal axis 4	P04.43 ~10.00V		10.00V	☆
P04.46	Curve D vertical axis 4	- 100.0% ~100.0%		100.0%	☆

Description: The range of HDI, AI1 ~ AI4 mapping curve:

- For frequency setting, 100% corresponds to the maximum frequency P01.06.
- For torque setting, 100% corresponds to the maximum torque P14.02.
- For other uses, see the description of the relevant function.

05 Group Analog and Pulse output				
Function code	Parameter name	Description	Default	Property
r05.00	Actual output Pulse frequency	0.00kHz~50.00kHz	-	●
P05.01	HDO Pulse Output type	0: Common numeric output (DO2 P07.02) 1: high frequency pulse output (Hdo)	0	☆
P05.02	HDO output source selection	0:Running frequency (0~max frequency) 1:Set frequency(0~max frequency) 2:Output current(0~2 times motor rated current) 3:Output torque(0~3times motor rated torque) 4:Set torque(0~3times motor rated torque) 5:Output voltage(0~2times motor rated voltage) 6: DC bus voltage(0~2times drives standard DC bus voltage) 7: output power(0~2times motor rated power) 8: encoder rotating speed (0-maximum frequency rotating speed) 9: AI1(0.00~10.00V) 10: AI2(0.00~10.00V) 11: AI3(0.00~10.00V) 12: Reserved 13: Reserved 14: Acceleration and deceleration instructions (0.00~maximum frequency)	0	☆
P05.03	HDO Minimum output pulse frequency	0.00kHz~50.00kHz HDO terminal output pulse frequency when Output signal source=0	1.00kHz	☆
P05.04	HDO Max output pulse frequency	0.00kHz~50.00kHz HDO terminal output pulse frequency when Output signal source=maximum value	30.00kHz	☆
r05.05	AO1 actual value	0.0%~100.0%	-	●
P05.06	AO1 output function signal selection	Same as P05.02 function description	0	☆
P05.07	AO1 output offset	-100.0%~100.0%	0.0%	☆
P05.08	AO1 output gain	-8.00~8.00	1.00	☆

The output error of AO1 can be corrected by P05.07 and P05.08, or the mapping relationship between signal source and actual output can be changed. The formula is:

$AO.c = P05.07 + P05.08 \times AO.p$ AO.c: the actual output of AO1;

AO.p: AO1 Value before correction and **AO.c, AO.p, 100.0% of P05.07 corresponds to 10V or 20mA.**

Example: AO1 is set to 4~20mA output:

1. Switch the corresponding AO1 jumper on the IO board to current

2. Set the function code: P05.07=20.0%, P05.08=0.80

r05.09	AO2 actual value	0.0%~100.0%	-	•
P05.10	AO2 output function signal selection	Same as P05.02 function description	0	☆
P05.11	AO2 output offset	-100.0%~100.0%	0.0%	☆
P05.12	AO2 gain	-10.00~10.00	1.00	☆

The output error of AO2 can be corrected by P05.11 and P05.12, or the mapping relationship between signal source and actual output can be changed. The formula is:

$AO.c = P05.11 + P05.12 \times AO.p$ AO.c: the actual output of AO2;

AO.p: AO2 value before correction and **AO.c, AO.p, 100.0% of P05.11 corresponds to 10V or 20mA.**

Example: Such as: AO2 is set to 4~20mA output:





1. Switch the corresponding AO2 jumper on the IO board to current

2. Set the function code: P05.11=20.0%, P05.12=0.80

06 Group Multi-function Digital input				
Function code	Parameter name	Description	Default	Property
r06.00	DI port status	Bit0~Bit8 Correspond to DI1~DI9 Bit12~Bit15 Correspond to VDI1~VDI4	-	•
P06.01	DI1 Numeric input function	0: No function 1: FORWARD 2: Reverse/Forward and reverse switchover 3: Three wire control 4: Forward jog command 5: Reverse jog command 6: Terminal UP 7: Terminal DOWN 8: Clear up UP/DOWN offset 9: Coast to stop/free stop 10: Fault reset 11: Reverse forbidden 12: Switching run command to Keypad 13: Switching run command to Communication 14: fast stop 15: external stop 16: Switch between motor 1 and motor 2 17: Pause operation 18: DC braking 19: Switch between torque and speed Control 20: Torque control disabled 21: Multi-step speed terminal 1 22: Multi-step speed terminal2 23: Multi-step speedterminal3 24: Multi-step speed terminal4 25: Frequency source switchover 26: Switch main frequency source to Numeric frequency setting 27: Switch main frequency source to AI1	1	★

Function code	Parameter name	Description	Default	Property
P06.02	DI2 Numeric input function	28: Switch main frequency source to AI2 29: Switch main frequency source to AI3 30: Switch main frequency source to AI4	2	★
P06.03	DI3 Numeric input function	31 : Switch main frequency source to high-frequency pulse input	4	★
P06.04	DI4 Numeric input function	32 : Switch main frequency source to communication setting 33: Switch auxiliary frequency source to numeric frequency setting	10	★
P06.05	DI5(HDI) Numeric input function	34: Accel and Decel time terminal 1 35: Accel and Decel time terminal 2	0	★
P06.06	DI6 Numeric input function (option Card)	36: Accel and Decel Stop 37: User-defined fault 1 38: User-defined fault 2	0	★
P06.07	DI7 Numeric input Function (option Card)	39: PID pause 40: PID integral pause 41: PID parameter Switchover 42: PID Positive/negative reaction switch	0	★
P06.08	DI8 Numeric input function (option Card)	43: Preset PID terminal 1 44: Preset PID terminal 2 45: PID Main and Auxiliary command switch	0	★
P06.09	DI9 Numeric input Function (option Card)	46: PID Main and Auxiliary feedback switch 47: Simple PLC status reset 48: Simple PLC time stop	0	★
P06.13	VDI1 Numeric input Function (Virtual DI3)	49: Swing frequency stop 50: Counter 1 input 51: Counter 1 reset/clear	0	★
P06.14	VDI2 Numeric input Function (Virtual DI)	52: Counter 2 input 53: Counter 1 reset/clear 54: Reserved 55: Motor 2 acceleration and deceleration time selection	0	★
P06.15	VDI3 Numeric input function (Virtual DI)	56: Grid phase lock enable	0	★
P06.16	VDI4 Numeric input function (Virtual DI)		0	★
P06.17	Virtual input source	Unit's digit: VDI1 input source 0~F: P06.33 specifies the bit0~bit15 of the parameter Ten's digit: VDI2 input source 0~F: P06.34 specifies the bit0~bit15 of the parameter. Hundred's digit: VDI3 input source 0~F: P06.35 specifies the bit0~bit15 of the parameter Thousand's digit: VDI4 input source	0003	★



Function code	Parameter name	Description	Default	Property
		0~F: P06.36 specifies the bit0~bit15 of the parameter		
P06.18	DI Forcing function	Define as per bit : Disable ;1: Enable Bit0-bit11:DI1-DI12 Bit12-bit15:VDI1-VDI4 When the bit is enabled, the state of the DI or VDI is set by the corresponding bit of P06.19.	H000000 00 L000000 00	★
P06.19	DI Forcing data	Define as per bit 0:effective;1:ineffective Bit0-bit11:DI1-DI12 Bit12-bit15:VDI1-VDI4	0	☆
P06.20	Effective logic of Numeric input terminal	Define as per bit 0:positive logic;1:negative logic Bit0-bit11:DI1-DI12 Bit12-bit15:VDI1-VDI4 In the reverse logic, the inactive level of the DI terminal becomes the active level.	0	★
P06.21	DI1 Effective delay time	0.000s ~ 30.000s	0.000s	☆
P06.22	DI1 ineffective delay time	0.000s ~ 30.000s	0.000s	☆
P06.23	DI2 Effective delay time	0.000s ~ 30.000s	0.000s	☆
P06.24	DI2 ineffective delay time	0.000s ~ 30.000s	0.000s	☆
P06.25	DI3 Effective delay time	0.000s ~ 30.000s	0.000s	☆
P06.26	DI3 ineffective delay time	0.000s ~ 30.000s	0.000s	☆
P06.27	DI4 Effective delay time	0.000s ~ 30.000s	0.000s	☆
P06.28	DI4 ineffective delay time	0.000s ~ 30.000s	0.000s	☆
P06.29	Two wire/3wire operation control	0:2-wire mode (FWD+REV)1 1:2-wire mode (RUN+DIRECTION)2 2:3-wire 1(FWD+REV+ENABLE) 3:3-wire 2 (RUN (along) + DIRECTION + ENABLE) 4: 2-wire 3 (RUN/STOP (along) + DIRECTION)	0	★



Function code	Parameter name	Description	Default	Property
<div><div><p>Figure1 : Two-line mode 1</p></div><div><p>Figure 2 : Two-line mode2</p></div><div><p>Figure 3 : Three-line mode1</p></div><div><p>Figure 4 : Three-line mode2</p></div><p>Two-line mode 1: K1 is closed, the drive is running forward, K2 closed reverse operation, K1, K2 at the same time closed or disconnected, the inverter stops running.</p><p>Two-line mode 2: In K1 closed state, K2 disconnect the inverter forward, K2 closed inverter reverse; K1 off the inverter to stop running.</p><p>Three-line mode 1: DI3 is set to three-wire control function. When the SB1 button is closed, press the SB2 button. The inverter is forward running. Press the SB3 button to invert the inverter. When the SB1 button is off, the inverter will stop. During normal start-up and running, it is necessary to keep the SB1 button closed, and the commands of SB2 and SB3 buttons take effect during the closing operation. The running status of the inverter takes the last key action of the three buttons as the standard.</p><p>Three-line mode 2: DI3 is set to three-wire control function. When the SB1 button is closed, press the SB2 button to run the inverter, K to switch the inverter forward, K to close the inverter and SB1 to turn off the inverter. During normal start-up and operation, it is necessary to keep the SB1 button closed and the command of the SB2 button effective during the closing operation.</p></div>				
P06.30	Digital input terminal filtering time	0.000~0.100s Set the sample filter time of DI1~DI4 and HDI terminals. If the interference is strong, increase the parameter to avoid wrong operation.	0.010s	☆

Function code	Parameter name	Description	Default	Property
P06.31	Terminal protection function	0: no protection When command is terminal, power on and terminal effective, inverter will run 1: protection When command is terminal, power on and terminal effective, inverter will not run ,so need terminal ineffective then effective, then inverter will run	0	★
P06.32	DI terminal on/ready time	0.000s~30.000s	1.000s	★
P06.33	VDI1 source	To Select the source of VDI1, Please select the input signal of VDI1 together with the Unit's digit of P06.17.	06.00	★
P06.34	VDI 2 source	To Select the source of VDI2, Please select the input signal of VDI1 together with the Ten's digit of P06.17.	06.00	★
P06.35	VDI 3 source	To Select the source of VDI3, Please select the input signal of VDI1 together with the Hundred's digit of P06.17.	07.00	★
P06.36	VDI 4 source	To Select the source of VDI4, Please select the input signal of VDI1 together with the Thousand's digit of P06.17.	44.00	★
07 Group Multi-function Digital output				
r07.00	DO output port status	Define as per bit, 0:ineffective 1:effective Bit0:DO1 Bit1:DO2 Bit2:relay1, Bit 3:relay 2(option) Bit4: DO3;Bit5: DO4 Bit6: DO5; Bit7: DO6Bit8: VDO1;Bit9: VDO2	-	●
P07.01	DO1 Output terminal function group	0:No function 1:READY 2:RUN 3>Error1 (All fault) 4>Error2 (Stop fault) 5>Error 3 t(fault but It still keeps running) 6:Swing frequency limit 7:Torque limit 8:Reverse running 9: Upper limit frequency arrival 10:Lower limit frequency arrival 1(not detect when stop) 11: Lower limit frequency arrival2(detect when stop) 12:FDT1 output frequency detection range 13:FDT2 output frequency detection range 14:Setting frequency arrival	0	☆

Function code	Parameter name	Description	Default	Property
P07.02	DO2(HDO) Output terminal function group	15:Desired frequency attained 1 P08.05 16:Desired frequency attained 2P08.07 17:Zero speed (stop without output)	0	☆
P07.03	Relay 1 Output terminal function group(T1A T1B T1C)	18: Zero speed (stop with output) 19:Zero current status 20:Output current exceed limit 21:Counter 1 setting value arrival	3	☆
P07.04	Relay 2 Output terminal function group(T2A T2B T2C)(Optional)	22:Counter 1 setting value arrival 23:Simple PLC cycle finish 24:Reserved 25:Drive overload pre-warning	0	☆
P07.05	DO3 Output terminal function group(IO card)	26: Motor overload pre-warning 27: Motor overheat pre-warning 28:Off loading 29:Reserved	0	☆
P07.06	DO4 Output terminal function group(IO card)	30:Reserved 31: Reserved 32:Variable selector unit 1 output	0	☆
P07.07	DO5 Output terminal function group(IO card)	33:Variable selector unit 2 output 34:Variable selector unit 3 output 35:Variable selector unit 4 output	0	☆
P07.08	DO6 Output terminal function group(IO card)	36:Logic unit 1 output 37:Logic unit 2 output 38:Logic unit 3 output 39:Logic unit 4 output	0	☆
P07.09	VDO1(virtual DO1) output Terminal function	40:Delaying unit 1 output 41:Delaying unit 2 output 42: Delaying unit 3 output	0	☆
P07.10	VDO2(virtual DO2) output Terminal function	43: Delaying unit 4 output 44: Reserved 45: Reserved	0	☆
P07.11	Output logic negative	Define as per bit 0:off;1:on(negative) Bit0:DO1 Bit1:DO2 Bit2:Relay 1 Bit3: Relay 2(option) Bit4: DO3;Bit5: DO4 Bit6: DO5; Bit7: DO6 Bit8: VDO1;Bit9: VDO2 Notice: positive logic equivalent to Normal open point And negative logic equivalent to Normal close point	0	☆
P07.12	DO1 effective delay time	0.000s~30.000s	0.000s	☆


Function code	Parameter name	Description	Default	Property
P07.13	DO1 ineffective delay time	0.000s~30.000s	0.000s	☆
P07.14	DO2 effective delay time	0.000s~30.000s	0.000s	☆
P07.15	DO2 ineffective delay time	0.000s~30.000s	0.000s	☆
P07.16	Relay 1 effective delay time	0.000s~30.000s	0.000s	☆
P07.17	Relay 1 ineffective delay time	0.000s~30.000s	0.000s	☆
P07.18	Relay 2 effective delay time	0.000s~30.000s relay 2 as option	0.000s	☆
P07.19	Relay 2 ineffective delay time	0.000s~30.000s relay 2 as option	0.000s	☆

08 Group Digital output setting				
Function code	Parameter name	Description	Default	Property
P08.00	Frequency detection value (FDT1)	0.00Hz~maximum frequency(P01.06)	50.00Hz	☆
P08.01	Frequency detection hysteresis 1	0.0%~100.0% FDT1	5.0%	☆
P08.02	Frequency detection value 2(FDT2)	0.00Hz~maximum frequency(P01.06)	50.00Hz	☆
P08.03	Frequency detection hysteresis 2	0.0%~100.0% FDT2(P08.02)	5.0%	☆
<p>FDT is used to check inverter output frequency, when output frequency is greater than frequency detection value, FDT effective, when output frequency is less than frequency detection value*(1- Frequency detection hysteresis),FDT ineffective; when output frequency is between the above two, FDT output keep no change, following is FDT chart</p> 				
P08.04	Detection range of frequency arrival	0.0%~100.0% maximum frequency (P01.06) When output frequency is between command frequency $\pm P08.04 * P01.06$, corresponding DO output effective signal 	3.0%	☆
P08.05	Desired frequency attained 1	0.00Hz~maximum frequency (P01.06)	50.00Hz	☆
P08.06	Any frequency reaching detection amplitude 1	0.0%~100.0% maximum frequency (P01.06)	3.0%	☆
P08.07	Desired frequency attained2	0.00Hz~maximum frequency(P01.06)	50.00Hz	☆

Function code	Parameter name	Description	Default	Property
P08.08	Any frequency reaching detection amplitude 2	0.0%~100.0% maximum frequency (P01.06)	3.0%	☆
<p>When the output frequency reaches positive or negative detection amplitude of frequency detection value, DO outputs ON signal. VFD500 series inverter provides two parameters of any arrival frequency detection value, used to set frequency value and frequency detection range.</p> 				
P08.09	Zero speed detection amplitude	0.00H~5.00Hz	0.25Hz	☆
P08.10	Zero current detection level	0.0%~100.0% rated motor current	5.0%	☆
P08.11	Zero current detection delay time	0.000~30.000s 0.000~30.000s Notice: When output current SP08.10 and endure P08.11 time, corresponding DO output effective signal	0.100s	☆
<p>When the output current S zero current detection level, lasts for longer than zero current detection delay time, DO terminal outputs ON signal.</p> 				

Function code	Parameter name	Description	Default	Property
P08.12	Output overcurrent threshold	0.0%~300.0% motor rated time	200.0%	☆
P08.13	Overcurrent detection delay time	0.000~30.000sNotice : When output currentSP08.12 and endure P08.13time, corresponding DO output effective signal	0.100s	☆

When the output current is bigger than or over-limit detection point, lasts for longer than software over current point detection delay time, DO terminal outputs ON signal.





10 Group encoder type				
Function code	Parameter name	Description	Default	Property
P10.01	Encoder type	0: ABZ 1: ABZUVW 2: Rotary/resolver 3: sin/cos encoder ➤ Consult factory when need PG card	0	★
P10.02	Encoder line number	1~65535 Rotary pulse number: 1024× rotary pair of poles	1024	★
P10.03	AB pulse direction	0: forward, 1: reverse ➤ If control mode is VC (with PG card) we can get this value by auto tuning for motor ➤ We can run motor with open loop, and observe r10.12 and r27.00 if they are in the same direction, if not, then change this value	0	★
P10.07	Rotating ratio molecule between motor and encoder	1~65535	1000	★
P10.08	Rotating ratio denominator between motor and encoder	1~65535	1000	★
<p>When encoder is not installed on the motor rotor axis, asynchronous motor vector control with encoder is effective by setting motor and encoder rotating speed ratio (P10.07 and P10.08)</p> <p>motor rotating speed = $\frac{P10.07}{P10.08} \times \text{encoder speed}$</p> <p>For example: if motor rotating speed is 1500RPM and encoder speed 1000RPM, set P10.07=1500, P10.08=1000.</p>				
P10.09	Encoder offline detection time	0.0(not detecting)~10.0s	2.0	★
P01.10	ABZ input port filter time	Unit digit: Reserved ... Thousands digit: ABZ pin adopts cycle, which is the setting value * 0.167us	5501	★
P10.11	Encoder rotation filter time	0~32 speed loop control cycle	1	★
r10.12	encoder feedback rotating speed	Current rotating speed by measuring, unit: 0.01Hz/1Rpm ➤ unit set by P21.17 ➤ no symbolic number, Function code r27.02:Bit5 for direction: keypad indicator FREVF indicate direction	-	•
r10.13	Encoder current position	0 ~ 4*encoder pulse number -1 encoder current position refer Z pulse as zero point, motor forward running and one cycle to Z pulse ,then position to zero	-	•

Function code	Parameter name	Description	Default	Property
r10.14	Z pulse marking value	0 ~ 4*encoder pulse number-1 (it is used to monitor encoder slipping and AB being disturbed)	-	●
r10.15	UVW status	0~65535 When the encoder type is ABZUVW, used to monitor the current UVW level When the encoder type is resolver or sine and cosine encoder with CD: used to monitor the absolute position of the encoder.	-	●

11 Group Motor 1 Parameter				
Function code	Parameter name	Description	Default	Property
r11.00	Motor type	0:AC asynchronous motor 1:Synchronous motor(Special software) See appendix parameter	0	•
P11.02	Motor rated power	0.1kW~800.0kW ➤ when power is less than 1kw ,0.75kw set to 0.8 as per round up principle ,0.55kw motor set 0.6 ➤ when change motor rated power,AC drive will automatically set other parameter of motor name plate and motor model parameter be careful to use	Depend	★
P11.03	Motor rated voltage	10V~2000V	Depend	★
P11.04	Motor rated current	P11.02<30kW:0.01A P11.02>=30kW:0.1A	Depend	★
P11.05	Motor rated frequency	1.00Hz~600.00Hz	50.00Hz	★
P11.06	Motor rated RPM	1~60000rpm	Depend	★
P11.07	Motor rated power factor	0.500~1.000	Depend	★
r11.08	Motor rated torque	Read only,0.1Nm(P11.02<30KW); 1Nm(P11.02>30KW)	-	•
r11.09	Number of motor 1 pairs of pole	Read only, It will auto calculate as per motor rated frequency and rated rotating speed	-	•
P11.10	Auto-tune/self-learning	0:no auto tuning 1:Stationary auto tuning of Asynchronous motor It is suitable in the cases when the motor can not de-couple form the load. The auto tuning for the motor parameter will impact the control accuracy. 2:dynamic or Rotational auto tuning of Asynchronous motor Comprehensive motor parameter autotune It is recommended to use rotation auto tuning when high control accuracy is needed.	0	★

Function code	Parameter name	Description	Default	Property
<p>1: Stationary auto tuning of Asynchronous motor</p> <p>When do auto tuning ,motor stationary ,it can get parameter P11.11 ~P11.13o</p> <p>Static self-learning can not learn all the motor parameters, so the control performance is difficult to achieve the best; if the motor nameplate information is incomplete, or the motor is not a 4-pole 50Hz GB motor, it is recommended to perform "rotation self-learning".</p> <p>In the case of limited rotation, such as limited travel, limited load (crane), limited running direction, etc., static self-learning is used.</p> <p>2: Rotational auto tuning of Asynchronous motor</p> <p>When do auto tuning ,motor first stationary and rotary, ,it can get parameter P11.11~P11.18, as to close loop control, it can get P10.03 encoder direction</p> <p>When rotating self-learning, the motor will rotate forward and the speed can reach 50%~100% of the rated speed. The lighter the load during self-learning, the better the learning effect.</p> <p>note:</p> <p>Notice: it can do motor auto tune when command source is keypad</p> <p>Please self-learn when the motor is cold. Make sure the motor is at rest before learning!</p> <p>Please confirm that the motor nameplate parameters have been set before self-learning. For closed-loop control, you should also set the encoder parameters!</p> <p>After setting this parameter, press the “RUN” button on the keyboard, the self-learning will start, and the inverter will stop itself after the self-learning is completed.</p>				
P11.11	Stator resistor of Asynchronous motor	Unit:0.001Ω(P11.02<30kW) Unit:0.01mΩ(P11.02≥30kW)	Depend	★
P11.12	Rotor resistor of Asynchronous motor	Unit:0.001Ω(P11.02<30kW) Unit:0.01mΩ(P11.02≥30kW)	Depend	★
P11.13	Leakage inductance of Asynchronous motor	Unit:0.01mH(P11.02<30kW) Unit:0.001mH(P11.02≥30kW)	Depend	★
P11.14	Mutual inductance of Asynchronous motor	Unit:0.1mH(P11.02<30kW) Unit:0.01mH(P11.02≥30kW)	Depend	★
P11.15	No-load excitation current of Asynchronous motor	Unit:0.01A(P11.02<30kW) Unit:0.1A(P11.02≥30kW)	Depend	★
P11.16	Excitation saturation factor 1	At non rated-excitation status	1.100	★
P11.17	Excitation saturation factor 2	At non rated-excitation status	0.900	★
P11.18	Excitation saturation factor3	At non rated-excitation status	0.800	★

12 Group Motor 1 VF control parameter				
Function code	Parameter name	Description	Default	Property
P12.00	VF curve	0: linear VF 1: Multi-point VF 2: VF to the 1.3 3: 1.7 power 4: 2.0 power 5: VF complete separation 6: VF Half separation	0	★
<p>➤ When the VF curve is straight line and power curve, the frequency-voltage curve is as follows:</p>  <p>Figure 1: Straight line VF and 1.3s1.7s2.0 power VF</p> <p>➤ Multi-stage line type VF curve:</p>  <p>Figure 2: multi-stage line type VF curve</p> <p>➤ VF full separation</p> <p>The output voltage and output frequency are completely independent. The output frequency is determined by the frequency source. The output voltage is determined by P12.20. Suitable for applications such as variable frequency power or torque motors.</p> <p>➤ VF semi-isolated</p> <p>At this point the ratio of output voltage and output frequency given by the voltage source, the formula is as follows: :</p> $\text{output voltage} = 2 \times \text{Voltage source given} \times \text{output frequency} \times \frac{\text{motor rated voltage}}{\text{motor rated frequency}}$				
P12.01	Multi-point VF Frequency 1(F0)	0.00Hz~multi-point VF curve F1(P12.03)	0.00Hz	☆
P12.02	Multi-point VF Voltage 0(V0)	0.0%~100.0%	0.0%	☆

Function code	Parameter name	Description	Default	Property
P12.03	Multi-point VF Frequency 1(F1)	multi-point VF curve F0(P12.01)~ multi-point VF curve F2(P12.05)	50.00Hz	☆
P12.04	Multi-point VF Voltage 1(V1)	0.0%~100.0%	100.0%	☆
P12.05	Multi-point VF Frequency 1(F2)	multi-point VF curve F1(P12.03)~ multi-point VF curve F3(P12.08)	50.00Hz	☆
P12.06	Multi-point VF Voltage 2(V2)	0.0%~100.0%	100.0%	☆
P12.07	Multi-point VF Frequency 3(F3)	multi-point VF curve F2(P12.05)~ 600.00Hz	50.00Hz	☆
P12.08	Multi-point VF Voltage 3(V3)	0.0%~100.0%	100.0%	☆
P12.09	Torque boost	0%~200% 0% is automatic torque boost	0%	☆
<p>➤ Automatic torque boost</p> <p>When P12.09=0=Automatic torque boost, inverter will automatically compensate output voltage to improve torque in low frequency as per actual load ,it is useful for linear VF curve</p> <p>➤ Manual torque boost</p> <p>➤ When P12.09 not 0,it means manual torque output. Output frequency 0 torque increasing value=p12.09*motor stator resistance *rated excitation current, increasing value will be gradually decreased as frequency increase ,if higher than 50% of motor rated frequency, increasing value will be zero</p> <p>➤ Notice: manual torque boost is useful to linear and power curve</p>				
P12.11	Slip compensation gain	0~200% It is used to compensate the speed drop of the asynchronous motor VF control with load, and improve the speed control accuracy. Please adjust according to the following principles: <ul style="list-style-type: none"> • Increase the setting when the motor speed is lower than the target value with loading. • Reduce this setting when the motor speed is higher than the target value with loading, 	100%	☆
P12.12	Slip compensation filter time	0.01s~10.00s It is used to adjust the speed and stability of the VF control response to the load. <ul style="list-style-type: none"> • Decrease this setting when the load response is slow. • Increase this setting when the speed is unstable 	1.00s	☆

Function code	Parameter name	Description	Default	Property
P12.13	Oscillation suppression gains	0~2000 In the SVPWM control mode, current fluctuation may occur to the motor on some frequency, especially the motor with big power. The motor can not run stably or over current may occur. These phenomena can be canceled by adjusting this parameter.	300	☆
P12.14	Oscillation suppression effective frequency range	Oscillation suppression effective range :100%~1200% Set the range of the oscillation suppression function, 100% corresponds to the rated frequency of the motor	110%	☆
P12.15	Current limit function selection	0: ineffective 1: only adjust output voltage (Current limiting for general VF separation) 2: adjust output frequency	2	★
P12.16	Current limit level	20%~180% drive rated current	150%	☆
P12.17	Weak magnetic zone current limit factor	0.50-2.00 optimize dynamic performance of Weak magnetic zone	0.60	☆
P12.19	VF maximum output voltage	100%~130%, increasing this parameter can improve the load capacity of VF control in the weak magnetic area.	110%	☆
P12.20	Voltage source for VF separation	0: digital setting 1: AI1 2: AI2 3: AI3(IO expansion board) 4: Reserved 5: HDI 6: Reserved 7: communication 8: PID	0	★
P12.21	Digital setting for VF separation voltage	0.0%~100.0%	0.0%	☆
P12.22	VF separation voltage Accel and Decel time	0.00s~60.00s	1.00s	☆
P12.23	VF Separation voltage rates as per time	VF Separation Voltage variation every hour range:-100.00%~100.00%	0.0%	☆

13 Group Motor 1 vector control				
Function code	Parameter name	Description	Default	Property
P13.00	Speed Proportional Gain ASR_P1	0.1~100.0	12.0	☆
P13.01	Speed Integral Time constant ASR_T1	0.001s~30.000s	0.200s	☆
P13.02	Speed Proportional Gain ASR_P2	0.1~100.0	10.0	☆
P13.03	Speed Integral Time constant ASR_T1	0.001s~30.000s	0.500s	☆
P13.04	ASR parameter Switching frequency 1	0.00Hz~ ASR switching frequency 2(P13.05)	5.00Hz	☆
P13.05	ASR parameter Switching frequency 2	ASR switching frequency 1~600.00Hz(P13.04)	10.00Hz	☆

By setting the speed factor and integration time of the speed regulator, you can adjust Section vector controlled speed loop dynamic response characteristics. Increase the proportional gain and reduce The integration time can speed up the dynamic response of the speed loop, but the proportional gain is too large Or the integration time is too small, it is easy to cause the system to oscillate, and the overshoot is too large. Proportion increase Too small is also likely to cause steady-state oscillations of the system, and there may be a speed difference.

PI parameter

PI has a close relationship with the inertia of the system. Adjust on the base of PI according to different loads to meet various demands.

P13.00 and P13.01 are Speed adjuster parameter for low-speed use, scope of action from zero to P13.04

P13.02 and P13.03 are Speed adjuster parameter for high-speed use, scope of action from P13.05 to maximum frequency

P13.04-P13.05 Two sets of parameter for linear transitions

P13.06	Speed control torque limit source selection	Unit's digit: Electric torque limit source 0:Digital setting 1: Ai1 2: Ai2 3: AI3((IO expansion board) 4:Reserved 5: HDI 6:Communication Ten'unit:Braking torque limit source Same as unit'digit	00	★
--------	---	---	----	---

Function code	Parameter name	Description	Default	Property
P13.07	Electric torque limit	0.0%~300.0%	160.0%	☆
P13.08	Upper limit of brake torque	0.0%~300.0%	160.0%	☆
P13.12	Torque current directives filter time	Unit: current loop adjust cycle ,0~100	2	☆
P13.13	ACR Proportional Gain1	0.01~1000	300	☆
P13.14	ACR Integral Time1	0.01~300.00ms	10.00ms	☆
P13.15	ACR Proportional Gain2	0.01~1000	300	☆
P13.16	ACR Integral Time2	0.01~300.00ms	10.00ms	☆
ACR: Automatic current regulator. ACR parameters adjust the PI adjustment parameter of the current loop which affects the dynamic response speed and control accuracy directly. Generally, users do not need to change the default value; Only apply to the vector control mode without PG card (P00.04=0).				
P13.17	Voltage feedforward Gain	0~100improve the dynamic response of vector control,	0	★
P13.19	Voltage margin	0.0%~50.0%improve the dynamic response of weak magnetic curvature.	3%	☆
P13.20	Flux weakening adjuster integral time	0.001s-5.000s	0.010s	☆
P13.21	Proportional gain of field weakening regulator	0.000~2.000	0.100	☆

14 Group Torque control				
Function code	Parameter name	Description	Default	Property
P14.00	Torque control input source	0:Digital setting(P14.01) 1:AI1 2:AI2 3:AI3(IO expansion board) 4:Reserved 5:HDI 6:Communication	0	★
P14.01	Torque digital setting	-200.0~200.0% The torque reference greater than 0 indicates that the direction of the torque is the same as the forward direction of the motor; less than 0 indicates that the direction of the torque is the same as the reverse direction of the motor.	0	☆
P14.02	Maximum torque	Benchmark 10.0%~300.0% Notice: It is torque benchmarks as torque reference for analog inputs and high frequency pulse input also it is the ultimate output torque during torque control.	200.0%	★
P14.03	Torque reference ramp-up time	0.000s~60.000s Notice: The time for the torque reference to increase from 0 to the rated torque of the motor	0.100s	☆
P14.04	Torque reference ramp-down time	0.000s~60.000s Notice: The time for the torque reference to decrease from the rated torque of the motor to 0	0.100s	☆
P14.05	Speed limit source	Units: speed limit source selection 0: Digital setting (P14.06) 1: AI1 2: AI2 3: AI3 (expansion card) 4: Reserved 5: HDI 6: Communication Ten's place: speed limit source symbol 0: unsigned 1: Signed	0	★
P14.06	Digital setting of forward speed limit value	Relative to the maximum frequency: 0.00%~100.00%	100.0%	☆
P14.07	Digital setting of reverse speed limit value	Relative to maximum frequency:0.0%~100.0%	100.0%	☆

Function code	Parameter name	Description	Default	Property
P14.08	Torque setting over limit speed	0: Symmetrical torque command After the motor speed exceeds the speed limit value, the torque input source sets the absolute value of the torque reference, and the direction of the torque is always the braking force. 1: Enter speed mode After the motor speed exceeds the speed limit value, enter the speed mode, and the inverter will limit the speed to within the speed limit value as much as possible.	0	★
P14.10	Static friction torque	0.0%~50.0%	10.0%	☆
P14.11	Static friction torque compensation	0.00Hz~50.00Hz It is used to overcome the static friction force at the start, and the speed is higher than P14.11 and the static friction torque compensation is canceled.	1.00Hz	★
P14.12	Dynamic friction factor	0.0%~50.0% Dynamic friction at rated speed Notice: motor sliding friction torque at rated rotating speed	0.0%	☆
P14.13	Dynamic friction starting value	0.0%~50.0%	0.0%	☆

16 Group Energy saving control

r16.00	Electricity meter count (32BIT)	Unit: KW/H	-	●
r16.02	Output power	Unit:0.1kw, output power will be negative in regen state	-	●
r16.03	Power factor	-1.000~1.000	-	●
P16.04	Electricity meter zero clearing	0:no function : 1111 : clear to zero	0	☆
P16.05	Energy saving control	0 : disable 1 : enable	0	★
P16.06	Energy saving voltage limit	0%~50%(0% means Energy saving control disable and more than 0% means Energy saving control enable)	0%	☆
P16.07	Energy saving filter time	0.0~10.0s	2.0s	☆

Notice: P16.05 is invisible (it is useful in vf control) and When energy saving enabled, the output current can be reduced and the power loss can be reduced when the load is light. For example, the fan and pump is light loaded, most of the inverters do not have this function, so we are more energy efficient. Energy savings can be achieved when it is light loads or load changes so slow

18 group Asynchronous motor control advanced parameters				
Function code	Parameter name	Description	Default	Property
P18.08	SVC low frequency processing	Unit's place: zero-speed processing mode in speed mode 0: no processing 1: Output DC (can prevent shaft shaking when running at zero speed) Ten's place: low frequency excitation current in speed mode 0: equal to rated excitation current 1: Reduced to P18.09 Hundred's place: low frequency excitation current in torque mode 0: equal to rated excitation current 1: Reduced to P18.09	100	☆
P18.09	SVC low frequency excitation current	30.0%~100.0%	100.0	☆
P18.10	Asynchronous motor vector control slip gain	50%~200%	100%	☆
P18.11	Closed-loop vector (VC) parameter online adjustment coefficient	0~20 The larger the setting, the faster the adjustment, but it is easy to cause oscillation, set 0 to cancel	0	☆


20 Group User-defined function code menu				
P20.00	User-defined function code 0	This group of parameters can be used for two purposes: Use 1: Customize menu display When using the digital keyboard, specify the function code displayed in the user-defined menu mode (-USr-). Example: If you want to display P03.01 and P13.00 in "-USr-" mode, set P20.00=03.01, P20.01=13.00 Use 2: Communication address mapping In order to improve the communication efficiency, when one frame needs to read and write the function codes of different parameter groups, the address pointer function of this group of parameters can be used. Method 1: Set P30.16 to 1, then when the communication reads and writes P20.xx (address 0x14xx), the parameters	00.00	☆

Function code	Parameter name	Description	Default	Property
P20.01	User-defined function code 1	<p>pointed to by P20.xx are automatically operated internally.</p> <p>Use method 2: Communication read and write register 0x6F.xx, which is equivalent to operating the parameter pointed to by P20.xx.</p> <p>Precautions:</p> <p>1. When mapped to register 00.00, the return value of read data is 0, and the write data is invalid.</p> <p>2. One frame can read and write up to 16 function codes.</p>	00.00	☆
P20.02	User-defined function code 2		00.00	☆
P20.03	User-defined function code 3		00.00	☆
P20.04	User-defined function code 4		00.00	☆
P20.05	User-defined function code 5		00.00	☆
P20.06	User-defined function code 6		00.00	☆
P20.07	User-defined function code 7		00.00	☆
P20.08	User-defined function code 8		00.00	☆
P20.09	User-defined function code 9		00.00	☆
P20.10	User-defined function code 10		00.00	☆
P20.11	User-defined function code 11		00.00	☆
P20.12	User-defined function code 12		00.00	☆
P20.13	User-defined function code 13		00.00	☆
P20.14	User-defined function code 14		00.00	☆
P20.15	User-defined function code 15		00.00	☆
P20.16	User-defined function code 16		00.00	☆
P20.17	User-defined function code 17		00.00	☆
P20.18	User-defined function code 18		00.00	☆
P20.19	User-defined function code 19		00.00	☆
P20.20	User-defined function code 20		00.00	☆
P20.21	User-defined function code 21		00.00	☆
P20.22	User-defined function code 22		00.00	☆

Function code	Parameter name	Description	Default	Property
P20.23	User-defined function code 23		00.00	☆
P20.24	User-defined function code 24		00.00	☆
P20.25	User-defined function code 25		00.00	☆
P20.26	User-defined function code 26		00.00	☆
P20.27	User-defined function code 27		00.00	☆
P20.28	User-defined function code 28		00.00	☆
P20.29	User-defined function code 29		00.00	☆
P20.30	User-defined function code 30		00.00	☆
P20.31	User-defined function code 31		00.00	☆
P20.32	User-defined function code 32		00.00	☆
P20.33	User-defined function code 33		00.00	☆
P20.34	User-defined function code 34		00.00	☆
P20.35	User-defined function code 35		00.00	☆
P20.36	User-defined function code 36		00.00	☆
P20.37	User-defined function code 37		00.00	☆
P20.38	User-defined function code 38		00.00	☆
P20.38	User-defined function code 39		00.00	☆
P20.39	User-defined function code 39		00.00	☆

21 Group Keypad and Display Group				
Function code	Parameter name	Description	Default	Property
P21.00	Keyboard UP/DOWN function	Units: UP/DOWN enable selection 0: Disable 1: Enable Ten's unit: clear selection 0: Cleared in non-operational state 1: Not cleared Hundred's unit: Power-down memory selection 0: no memory 1: memory Thousand's unit: rate selection 0: automatic rate 1: P01.39 rate	0111	★
P21.02	MK function option	0: no function; 1: Forward Jog 2: Reverse Jog; 3: Forward/reverse Switch 4: Quick stop; 5: coast to stop 6: Curse left shift(LCD keypad)	1	★
P21.03	STOP function	0: Valid only at Keypad Control 1: valid at all command Channels	1	☆
P21.04	Monitoring display1	00.00~99.99	27.00	☆
P21.05	Monitoring display2	00.00~99.99	27.01	☆
P21.06	Monitoring display3	00.00~99.99	27.06	☆
P21.07	Monitoring display4	00.00~99.99	27.05	☆
P21.08	Monitoring display5	00.00~99.99	27.03	☆
P21.09	Monitoring display6	00.00~99.99	27.08	☆
P21.10	Monitoring display7	00.00~99.99	06.00	☆
P21.11	Running status Monitoring display parameter option	Unit's digit to Thousand's digit set 1-4 monitor parameter 0 means no display, 1~7 corresponds to monitor parameter 1~7 Unit's digit: choose first monitoring data, 0~7 Ten's digit: choose second monitoring data, 0~7 Hundred's digit: choose third monitoring data, 0~7 Thousand's digit: choose fourth monitoring display, 0~7	5321	☆
P21.12	Stop status Monitoring display parameter option	Same as P21.11	0052	☆
<p>VFD500 digital keyboard monitoring interface supports up to 4 monitoring volume. Monitoring variables in running status and monitoring variables in stop status are set by P21.11 and P21.12, respectively. Press FSHIFTF key on the keyboard to switch the monitoring volume from low to high of P21.11 or P21.12, Encountered "0" then skip, cycle monitoring.</p> <p>Take the shutdown monitoring interface for example, P21.12 = 0052, there are 2 monitoring variables, which are r27.01 (monitor display parameter 2, P21.05 = 27.01) and r27.03 (monitor display parameter 5, P21.08 =</p>				

27.03), press the FSHIFTF key on the keyboard to switch between the two monitors, as shown below.



The rules for running the monitoring interface are the same as the shutdown monitoring interface, and will not be repeated

Function code	Parameter name	Description	Default	Property
P21.13	Digital keypad personalized setting	<p>Unit's digit: quick editing function selection</p> <p>0: invalid</p> <p>1: Numeric frequency setting</p> <p>2: Numeric torque setting</p> <p>3: PID digital setting 0</p> <p>4. Forward speed limit value setting in torque control</p> <p>Note: The quick editing function means that if the current monitoring value is the output frequency or command frequency under the monitoring status, press the [ENTER] key to enter the parameter editing interface directly. The edited parameters are set by the ones digit of this function code.</p> <p>Ten's digit: monitor pointer reset selection</p> <p>0: When the display status is in the monitoring status from other status, or when the running monitoring status and stop monitoring status are switched, the previously recorded monitoring pointer position will be restored.</p> <p>1: When the display status is in the monitoring status by other status, or when the monitoring status of running status and stop status are switched, the monitor pointer will be reset to the ones of P21.11 or P21.12.</p> <p>Note: when power-on, the shutdown monitoring pointer points to the P21.12 bits, the operation monitoring pointer points to P21.11 bits</p>	01	★
P21.14	Load speed display factor	0.001~65.000	30.000	☆

Function code	Parameter name	Description	Default	Property
P21.15	Load speed decimal point digit	0~2	0	☆
r21.16	Load speed display	Load speed =P27.00*P21.10 Decimal point digit defined by P21.11	-	●
P21.17	Speed display unit	0:0.01Hz:1: 1Rpm Display unit for selecting P00.07, r27.00, r27.01, r10.12	0	★

22 Group AC drive data and configuration				
Function code	Parameter name	Description	Default	Property
P22.00	Carrier/switching frequency	<p>Depend on drives power S7.5kW: 1kHz~12.0kHz 11kW~45kW: 1kHz~8kHz S55kw: 1kHz~4kHz</p> <p>The carrier frequency can be reduced when it came like following phenomenon: 1 The leakage current generated by the inverter is large 2 The interference generated by the inverter has an impact on peripheral devices 3 Long wiring distance between inverter and motor</p> <p>The carrier frequency can be increased when it came like following phenomenon: 1 The electromagnetic noise generated by the motor is large</p>	Depend	☆
<p>Carrier frequency will affect the noise of motor and the EMI of inverter.</p> <p>If the carrier frequency is increased, it will cause better current wave, less harmonic current and lower noise of motor.</p> <p>Notice:</p> <p>The factory default is optimal in most cases. Modification of this parameter is not recommended.</p> <p>If the carrier frequency exceeds the factory default, the inverter must be derated because the higher carrier frequency will cause more switching loss, higher temperature rise of inverter and stronger electromagnetic interference.</p> <p>If the carrier frequency is lower than the factory default, it is possible to cause less output torque of motor and more harmonic current.</p>				
P22.01	Carrier frequency adjustment	<p>Unit'digit: adjustment as per Rotation 0:No : 1:Yes</p> <p>Ten'digit: adjustment as per Temperature 0 no : 1 : yes</p> <p>The inverter can automatically adjust the carrier frequency according to its temperature. This function can reduce the possibility of overheat alarm of the inverter.</p>	00	★
P22.02	Low speed carrier frequency	1.0kHz~15.0kHz	Depend	☆
P22.03	High speed carrier frequency	1.0kHz~15.0kHz	Depend	☆

Function code	Parameter name	Description	Default	Property
P22.04	Carrier frequency switching point 1	0.00Hz~600.00HzWhen the carrier frequency is adjusted according to the output frequency, the carrier frequency set by P22.02 is used when the output frequency is lower than this set value.	10.00Hz	☆
P22.05	Carrier frequency switching point2	0.00Hz~600.00Hz When the carrier frequency is adjusted according to the output frequency, the carrier frequency set by P22.03 is used when the output frequency is higher than this set value.	50.00Hz	☆
P22.06	PWM modulation method	0:SVPWM It is normally used 1:SVPWM+DPWM Using this modulation method can reduce the switching loss of the inverter and reduce the probability of overheating alarm of the inverter; however, the electromagnetic noise of the motor in the medium speed section will be too large. 2:PWM at random The electromagnetic noise generated by the motor is white noise, not a sharp squeak. 3:SPWM It is only used in special situation	0	★
P22.07	DPWM switching point	10%~100%(modulation percentage) When P22.06 is set to 1, increasing this setting value can reduce the electromagnetic noise in the middle speed section.	30%	★
P22.08	Modulating limit	100%-110% It is used to define the duty cycle of the inverter side IGBT. Over modulation is allowed when it is set to 100% or more, and the allowable over modulation is deepened when the set value is increased from 101 to 110.	105%	★
P22.10	AVR function	0:disabled 1:enabled When the AVR function is enabled, the effect of the DC bus voltage change on the output voltage can be eliminated.	1	★

Function code	Parameter name	Description	Default	Property
P22.11	Energy braking voltage function	0-Disabled 1-Enabled 2-only enable when ramp to stop This parameter is only used to control the built-in brake unit. For models without a built-in brake unit, this setting can be ignored.	1	☆
P22.12	Energy braking voltage	320V~400V(220V level) 600V~800V(380V level) 690V~900V(480V level) 950V~1250V(690V level)	Depend	☆
P22.13	Output phase switch	0:No Operation 1:Output phase switch (equal to change Phase between V and W. For closed loop control, you need to re-rotate the self-learning to confirm the encoder direction)	0	★
P22.14	Cooling method (fan control)	0:Effective when running 1:Forced control(effective when power on) 2:Adjustable as per drive temperature	0	☆
P22.15	G/P drive type	0-G type;1-P type ➤ G means normal duty (constant torque load) ➤ P means light duty such as fan and pump	0	★
r22.16	Drive rated power	Read only Unit:0.1kw	-	●
r22.17	Drive rated Voltage	Read only Unit:V	-	●
r22.18	Drive rated current	Read only Unit:0.1A	-	●
P22.20	Trial time setting	After this time, the inverter will stop and report Er.TTA fault; if set to 0, it will be cancelled. Note: This parameter needs agency authority to be able to see	0	☆

23 Group Drive protection function setting				
Function code	Parameter name	Description	Default	Property
P23.00	DC Bus voltage control option	<ul style="list-style-type: none"> ➤ Unit'digit :Overvoltage stall control 0:overvoltage stall disabled 1:overvoltage stall enabled 2:overvoltage stall enabled self-adjustable ➤ The over-voltage stall function limits the amount of power generated by the motor by extending the deceleration time or even increasing the speed, avoiding over-voltage on the DC side and reporting over-voltage faults Ten'unit: Undervoltage stall control 0:undervoltage stall disabled 1:Undervoltage stall(decelerate to zero speed and be in standby mode, after power restoring ,it will run again automatically) 2: Undervoltage stall deceleration(decelerate to zero and stop) ➤ The undervoltage stall function reduces the motor power consumption or reduces the power consumption of the motor or turns it into a power generation operation to avoid the undervoltage fault on the DC side. ➤ The undervoltage stall function is used when the input power supply quality is poor (the power supply voltage fluctuates downward or the sporadic short power is suspended), and it is necessary to keep the inverter running as much as possible. 	01	★
P23.01	Overvoltage stall threshold	220V Level: 320V~400V 380V Level: 540V~800V 480V Level: 650V~950V	Depend	★
P23.02	Undervoltage threshold	220V level: 160V~300V 380V level: 350V~520V 480V level: 400V~650V	Depend	★
P23.03	Overvoltage stall ratio	0~10.0	1.0	☆
P23.04	Undervoltage stall ratio	0~20.0	4.0	☆
P23.05	Undervoltage trip threshold	220V Level:160V~300V 380V Level:350V~520V 480V Level:400V~650V	Depend	★
P23.06	Undervoltage fault detecting time	0.0s~30.0s	1.0s	☆

Function code	Parameter name	Description	Default	Property
P23.07	Hardware protection configuration	Unit's digit: Wave-by-wave current limit enable 0: invalid; 1: valid Ten's digit short to ground enable bit 0: invalid; 1: Valid power-on detection 2: Detection before operation 3: Check before power-on and operation	11	★
P23.10	Over-speed detection value	0.0%~120.0% maximum frequency	120.0%	☆
P23.11	Over-speed detection time	0.0s~30.0s0.: shielding	1.0s	☆
P23.12	Detection value of too large speed deviation	0.0%~100.0%(motor rated frequency)	20.0%	☆
P23.13	Detection value of too large speed deviation	0.0s~30.0s 0.0: shielding	0.0s	☆
P23.14	Input phase loss detection time	0.0s~30.0s 0.0: forbidden	8.0s	☆
P23.15	Output phase loss imbalance detecting	0%~100%	30%	☆
P23.18	Fault protection action selection 1	Unit's digit : input phase loss 0: coast to stop 1: Emergent stop 2: Stop as per stop mode 3: Continue to Run Ten'unit: user self-defined fault 1 same as Unit's digit Hundred'unit: user self-defined fault 2 same as Unit'digit Thousand's unit: communication fault same as unit's digit	0000	☆
P23.19	Fault protection action selection 2	Unit's digit: motor overload 0: Coast to stop 1: Emergent stop 2: Stop as per stop mode 3: Continue to run Ten'unit: motor overheat same as unit'digit Hundred'unit: too large speed deviation same as unit'digit Thousand's unit: motor over speed same as Unit'digit	0000	☆



Function code	Parameter name	Description	Default	Property
P23.20	Fault protection action selection 3	Unit's digit: PID feedback lost during running 0: Coast to stop 1: Fast stop 2: Stop as per stop mode 3: Continue to run Ten'unit: Reserved same as unit'digit Hundred'unit: reserved same as unit'digit thousand'unit: reserved same as unit'digit	0000	☆
P23.21	Fault protection action selection 4	Unit's digit: output phase loss 0: Coast to stop 1: Fast stop 2: Stop as per stop mode Ten'unit: EEPROM fault 0: Coast to stop 1: Fast stop 2: Stop as per stop mode 3: Continue to run Hundred's unit: Reserved Thousand's unit: off load fault 0: Coast to stop 1: Fast stop 2: Stop as per stop mode 3: Continue to run	0000	☆
P23.24	Fault reset	Define as per bit: bit0-undervoltage;bit1- inverter overload bit2-inverter overheat ;bit3-motor overload bit4-motor overheat;bit5-user'fault 1 bit6- user'fault 2; bit7~15 reserved	0	☆
P23.25	Fault source for auto reset	Bitwise definition: Bit0-Output overcurrent; Bit1-Reserved Bit2-Reserved; Bit3-DC bus overvoltage Bit4-Reserved; Bit5-Reserved Bit6-Inverter undervoltage; Bit7-Input phase loss Bit8-Inverter overload Bit9-Inverter overheating Bit10-Motor overload; Bit11-Motor overheating Bit12-User fault 1; Bit13-User fault 2 Bit14-Reserved; Bit15-Confidential bit12-user'fault 1; Bit13-user'fault 2 bit14-Reserved; Bit15-Reserved	0	☆

Function code	Parameter name	Description	Default	Property
P23.26	Fault auto Reset times	0~99	0	☆
P23.27	Numeric output Action at fault reset	0:Disabled 1:Enabled	0	☆
P23.28	Interval time of fault auto reset	0.1s~300.0s	0.5s	☆
P23.29	Fault auto reset times clearing time	0.1s~3600.0s	10.0s	☆
P23.30	Continuing Running frequency selection when trip	0: Run at the set frequency 1: Run at abnormal standby frequency	0	☆
P23.31	Abnormal back-up frequency	0.00Hz~maximum frequency	2.0HZ	☆

24 Group motor Protection parameter

P24.00	Motor overload protection gain	0.20~10.00 The larger the value, the longer the allowable overload operation, and the higher the risk of motor overheating damage.	1.00	☆
P24.01	Motor overload starting current at zero speed	50.0%~150.0%	100.0%	☆
P24.02	Motor overload starting current at Rated speed	50.0%~150.0%	115.0%	☆

Motor in self cooling mode, heat dissipation is poor when in low frequency but good in condition of high frequency . P24.01 and P24.02 is used to set the starting point of zero and rated speed overload current in order to obtain a more reasonable under different speed overload protection Time curve



Left: Motor overload protection starting current

Right: Motor Overload Protection Curve with Different Overload Protection Gains

Motor overload only protects the motor from overload when P24.04 is enabled. P24.00 is used to adjust the overload inverse time curve time, as shown in the right figure above, the minimum motor overload time is 5.0s.

Note: Users need to correctly set the three parameters of P24.00, P24.01 and P24.02 according to the actual overload capacity of the motor. If set unreasonable, prone to motor overheating damage and the inverter is not timely warning of the danger of protection.

Function code	Parameter name	Description	Default	Property
P24.03	Motor overload warning factor	50%~100%, When the overload accumulation degree is greater than this value, the P07 group DO terminal output function code "26" (Motor overload warning) is selected and output valid signal	80%	☆
P24.04	Motor protection option	Unit' digit: Motor 1 protection selection 0: Turn off software overload protection 1: Enable software overload protection Ten's digit: Motor 2 protection selection 0: Turn off software overload protection 1: Enable software overload protection	11	☆

Default inverter is —no motor temperature protection. To enable this protection, please confirm that present motor has a temperature sensor. (PTC means motor sensor, PTC1000 and PTC100 is different motor sensor type. if your motor have temperature sensor, you need to use our special card to connect PTC1000 or PTC100) and set temperature sensor type (P24.08) to start motor overheating protection. User can view present motor temperature through function code R27.07; if motor temperature is greater than motor overheating alarming threshold (P24.10), numeric output terminal —25: Motor Overload alarming's enabled and this signal is used for instruction; if motor temperature is greater than motor overheating protection threshold (P24.09), inverter will give an alarm about motor overheating fault (Er. oH3) and start corresponding protection action.

⚠ Motor overheating fault (Er. oH3) can not be reset immediately until motor temperature drops to a value far below the protection threshold

Function code	Parameter name	Description	Default	Property
P24.08	Motor temperature sensor type	0:no 1:PT100 2:PT1000 3: KTY84-130	0	☆
P24.09	Motor overheat fault threshold	0.0°C~200.0°C	120.0°C	☆
P24.10	Motor overheat warning threshold	0.0°C~200.0°C When the motor temperature detected by the temperature sensor is greater than this value, the DO terminal output function of function "27: Motor over temperature warning" is selected.	90.0°C	☆
r24.11	Motor temperature read data	Unit 0.1°C Display the motor temperature detected by the temperature sensor	-	●
P24.12	Off load protection	0:Ineffective 1:Effective	0	☆
P24.13	Off load detection level	0.0%-100%	10.0%	☆
P24.14	Off load detection time	0.000s-60.000s	1.000s	☆

Off load=unload

If output current is lower than offload detection level (P24.13) and this status continues for offload detection time (P24.14) when offload detection protection is enabled (P24.12=1)

and inverter is in running mode and not in DC brake, then inverter gives an offload protection fault (Er. LL) report and stops as the offload protection setting (P24.12)

25 Group Fault tracking parameter				
Function code	Parameter name	Description	Default	Property
r25.00	Current fault type	- see detail chapter 6 fault diagnosis and solution	-	●
r25.01	Output frequency at fault	Unit:0.01Hz	-	●
r25.02	Output current at fault	Unit:0.1A	-	●
r25.03	Bus voltage at fault	Unit:V	-	●
r25.04	Running mode status 1at fault	- see Parameter r27.10 in detail	-	●
r25.05	Input terminal status at fault	Bit0~Bit6 corresponds to DI1~DI7 Bit12~Bit15 corresponds to VDI1~VDI4	-	●
r25.06	Working time at fault	Unit:0.01S	-	●
r25.07	Accumulated working time at fault	Unit:hour	-	●
r25.08	Frequency source at fault	Unit:0.01hz	-	●
r25.09	Torque source at fault	Unit:0.1% compared to motor rated torque	-	●
r25.10	Encoder speed at fault	Unit:RPM	-	●
r25.11	Electrical angle at fault	Unit: 0.1°		●
r25.12	Running mode status 2 1at fault	See Parameter r27.11 in detail	-	●
r25.13	Input terminal status at fault	Define as per unit, 0:ineffective, 1:effective Bit0: DO1; Bit1: DO2 Bit2: relay; Bit3 (relay 2 as option) Bit4: DO3; Bit5: DO4 Bit6: DO5; Bit7: DO6 Bit8: VDO1; Bit9: VDO2	-	●
r25.14	Heat sink temperature at fault	Unit: 0.1° C	-	●
r25.15	Low-level fault	For the fault type, see theChapter6Fault Diagnosis and Solution	-	●
r25.16	Warning type	For the fault type, see theChapter6Fault Diagnosis and Solution	-	●
26 Group Fault recording parameter				
r26.00	Last fault 1trip type	SEE DETAILS IN CHAPTER 6	-	●
r26.01	Output frequency at fault	Unit:0.01Hz	-	●
r26.02	Output current at fault	Unit:0.1A	-	●
r26.03	Bus voltage at fault	Unit:V	-	●

Function code	Parameter name	Description	Default	Property
r26.04	Running mode status 1at fault	See Parameter r27.10	-	●
r26.05	Input terminal status at fault	Bit0~Bit6 corresponds to DI1~DI7 Bit12~Bit15 corresponds to VDI1~VDI4	-	●
r26.06	working time at fault	Unit:0.01S	-	●
r26.07	Accumulated working time at fault	Unit:hour	-	●
r26.08	Last fault 2 trip type	Same as last fault description	-	●
r26.09	Output frequency at fault		-	●
r26.10	Output current at fault		-	●
r26.11	Bus voltage at fault		-	●
r26.12	Running mode status 1at fault		-	●
r26.13	Input terminal status at fault		-	●
r26.14	Working time at fault		-	●
r26.15	Accumulated working time at fault		-	●
r26.16	Last fault 3 trip type	Same as last fault description	-	●
r26.17	Output frequency at fault		-	●
r26.18	Output current at fault		-	●
r26.19	Bus voltage at fault		-	●
r26.20	Running mode status 1at fault		-	●
r26.21	Input terminal status at fault		-	●
r26.22	Working time at fault		-	●
r26.23	Accumulated working time at fault		-	●
27 Group Monitoring parameter				
r27.00	Running frequency	It can set unit as per Parameter P21.07	-	●
r27.01	Set frequency	It can set unit as per Parameter P21.07	-	●
r27.02	Direction indicator	Bit0: direction of the running frequency (0-positive direction; 1-negative direction, the same below) Bit1: Set the direction of the frequency Bit2: direction of the main frequency Bit3: direction of the secondary frequency Bit4: Direction of the Up Down offset	-	●

Function code	Parameter name	Description	Default	Property
		Bit5: Direction of the encoder feedback frequency Reserved above Bit6		
r27.03	Bus voltage	Unit: 1V	-	●
r27.04	VF separation setting	unit: 0.1%	-	●
r27.05	Output voltage	unit: 0.1V	-	●
r27.06	Output current	unit: 0.1A	-	●
r27.07	Output current percentage	unit: 0.1%(100% of motor rated current)	-	●
r27.08	Output torque	0.1%	-	●
r27.09	Torque setting	0.1%	-	●
r27.10	Drives running mode status 1	Bit0:Running status 0-Stop;1-Run Bit1:Motor direction0-Forward;1-Reverse Bit2:Ready signal:0-not ready;1-ready Bit3:fault status 0-no fault;1-fault Bit4~5:fault type:0-free stop;1-fast stop;2-stop as per stop mode:3:continue to run Bit6:jog status:0-no jog;1-jog status Bit7:Auto tune :0-no;1-yes Bit8:DC braking:0-Non DC braking;1-DC braking Bit9:Reserved Bit10~11:Acceleration and Deceleration: 0:stop/zero output;1:speed up;2:slow down;3:constant speed Bit12:Warning status: 0:no warning; 1:warning Bit13:current limit status:0-no;1-yes Bit14:overvoltage stalladjustment:0-no ;1-yes Bit15:undervoltage stall adjustment :0-no;1-yes	-	●
r27.11	Drives running mode2	Bit0~1:current command source:0-keypad;1-terminal ;2-communicatoin Bit2~3:motor option:0-motor 1;1-motor 2 Bit4~5:current motor control:0-VF;1-SVC;2-VC Bit6~7:current running mode:0-speed;1-torque;2-position	-	●
r27.12	Drives running mode status 3	Reserved	-	●

Function code	Parameter name	Description	Default	Property
r27.13	Drives running mode status 4	Reserved	-	●
r27.14	Accumulated power on time	Unit:hour	-	●
r27.15	Accumulated running time	Unit:hour	-	●
r27.16	Power-on time	Unit:min		
r27.18	Heat sink temperature	Unit:0.1	-	●
r27.19	Main frequency	Unit:0.01Hz	-	●
r27.20	Auxiliary frequency	unit:0.01Hz	-	●
r27.21	Up Down offset frequency	unit:0.01Hz	-	●
29 Group Communication special register				
<p>This set of registers is equivalent to the 0x70xx registers: Example: P29.00 (address 0x1D00) is equivalent to 0x7000; P29.04 (address 0x1D04) is equivalent to 0x7004; This set of registers can display the current value on the panel to facilitate communication data diagnosis.</p>				
P29.00	Communication commands	Communication commands. The values and functions are as follows: 0x0000: The running command is invalid, which is equivalent to all keys under keyboard control being invalid; 0x0001: Forward running; 0x0002: Reverse operation; 0x0003: Forward jog; 0x0004: Reverse jog; 0x0005: Free parking; 0x0006: Slow down and stop; 0x0007: Quick stop; 0x0008: Fault reset.	-	☆
P29.01	Given communication speed	Given communication speed. The unit of this register can be set by 30.14. 0.01(-100.00%~100.00%) 0.01Hz(0~600.00Hz) 1Rpm(0~65535Rpm)	-	☆
P29.02	Communication torque given	Communication torque given. 0.01%(-300.00%~300.00%)	-	☆
P29.03	Communication upper limit frequency	Communication upper limit frequency. The unit of this register can be set by 30.14. The range under different units is the same as 0x7001.	-	☆
P29.04	Torque mode speed limit value	Torque mode speed limit value. The unit of this register can be set by 30.14. The range under different units is the same as 0x7001.	-	☆
P29.05	Electric torque limit	Electric torque limit. 0.1%(0~300.0%)	-	☆
P29.06	Generator torque limit	Generator torque limit. 0.1%(0~300.0%)	-	☆
P29.07	Process PID given.	Process PID given. 0.01%(100.00%~100.00%)	-	☆

Chapter 3 Function code table											
Function code	Parameter name	Description						Default	Property		
P29.08	Process PID feedback	Process PID feedback. 0.01%(-100.00%~100.00%)						-	☆		
P29.09	VF separation voltage given	VF separation voltage given. 0.1%(0~100.0%)						-	☆		
P29.10	External fault setting.	External fault setting.						-	☆		
P29.11	DO status setting	DO status setting. When the DO function (please refer to P07.01~P07.10) is set to 0 (no function), its status comes from the setting of the communication special register, and the corresponding bit is 1 to indicate valid. The bit definitions of this register are as follows:						-	☆		
		Bit7	Bit6	Bit5	Bit4	Bit3	Bit2			Bit1	Bit0
		Reserved	Reserved	Reserved	Reserved	RO L2	RO 1			DO 2	DO 1
		Bit15	Bit14	Bit13	Bit12	Bit11	Bit10			Bit9	Bit8
		Reserved	Reserved	Reserved	Reserved	Reserved	Reserved			VD O2	VD O1
30 Group Modbus communication parameter											
P30.00	Communication type	0:Modbus; 1:Canopen						0	★		
P30.01	Drive Address	1~247 Different slaves on the same network should set different local addresses; 0 is the broadcast address, all slave inverters can be identified						1	★		
P30.02	Modbus baud rate	0:1200 bps; 1:2400 bps 2:4800 bps; 3:9600 bps 4:19200 bps; 5:38400 bps 6:57600 bps; 7:115200 bps						3	★		
P30.03	Modbus data format	0: 1-8-N-1 (1 start bit +8 data bits +1 stop bits) 1: 1-8-E-1 (1start bit +8 data bits +1 even parity +1 stop bit) 2: 1-8-0-1 (1 star bit+8 data bits +1odd parity+1 stop bits) 3: 1-8-N-2 (1 star bit+8 data bits+2 stop bits) 4: 1-8-E-2 (1 star bits+8 data bit+1 even parity+2 stop bits) 5: 1-8-0-2 (1 start bit +8 data bits+1 odd parity+2 stop bits)						0	★		
P30.04	Modbus response delay	1~20msThe delay time of the local to answer the master						2ms	★		

Function code	Parameter name	Description	Default	Property
P30.05	Modbus overtime	0.0s(disabled)~60.0s(works for master-slave system) When this function code effective, if slave do not receive data from master overtime, it will trip as Er.485	0.0s	★
r30.06	Number of frames received by Modbus	Each time a frame is received, this value is incremented by 1,0 to 65535 cycles.	-	●
r30.07	Number of frames that Modbus has sent	Each time a frame is sent, this value is incremented by 1,0 to 65,536 cycles.	-	●
r30.08	Number of error frames received by Modbus	Each time an CRC error frame is received, this value is incremented by 1,0 to 65535 cycles; it can be used to judge the degree of communication interference.	-	●
P30.09	Modbus master-slave option	0: Slave 1: Master(sent by broadcast)	0	★
P30.10	Slave memory when inverter as master	1~9 corresponds to 0x7001~0x7009	1	☆
P30.11	Data sent by Master	0:output frequency 1:set frequency 2:output torque 3:set torque 4:PID setting 5:PID feedback 6:output current	0	☆
P30.12	Sending interval of Master	0.010~10.000sAs a master, after sending one frame of data, the next frame of data is sent after this delay.	0.1s	☆
P30.13	Receiving proportionality factor of slave	-10.000~10.000The values of slave registers 0x7001 and 0x7002 take effect after passing through this scaling factor	1.00	☆
P30.14	Communication special register speed unit	0: 0.01% 1: 0.01Hz 2: 1Rpm Some units of specific communication registers can be set by this parameter. See Appendix A for details.	0	☆
P30.15	Modbus response characteristics	When the format of the received frame is a write register, this parameter can be set to reply to the host. 0: Reply to the host (standard Modbus protocol) 1: Do not reply to the host (non-standard Modbus protocol)	0	☆

Function code	Parameter name	Description	Default	Property
P30.16	Modbus response characteristics	When the format of the received frame is a write register, this parameter can be set to reply to the host. 0: Reply to the host (standard Modbus protocol) 1: Do not reply to the host (non-standard Modbus protocol)	0	☆
P30.17	20 groups of communication mapping enable	0: Disable When the communication reads and writes P20.xx, the operation is the value of P20.xx. 1: Enable communication mapping When the communication reads and writes P20.xx, the operation is the value of the parameter mapped by P20.xx. It can be used to read and write multiple parameters of different parameter groups in one frame to improve communication efficiency. Remark: 0x6Fxx communication address is also the parameter mapped by operation P20.xx.	0	☆
31 Group Canopen communication parameter				
P31.00	CANopen communication address	1 ~ 127	1	☆
P31.01	CANopen Baud rate	0:100k 1:125k 2:250k 3:500k 4:1M	3	☆
P31.02	CANopen overtime	1ms ~ 20ms	4ms	☆
r31.07	CANopen version number	Display the version number of the CANopen card	-	●
r31.08	CANopen Working status	0: Initialization status 1: Disconnected 2: Connecting/Preparing- 3: Stopped 4: Operational status 5: Preoperational	-	●
r31.10	CANopen receive error count	The number of error frames received by CANopen is not saved after power off	-	●
r31.11	CANopen send error count	The number of error frames sent by CANopen is not saved after power off	-	●
r31.12	CANopen receive frame number	The number of frames received by CANopen is not saved after power off	-	●

Function code	Parameter name	Description	Default	Property
r31.14	CANopen send frame number	The number of frames sent by CANopen is not saved after power off	-	•
32 Group Profinet communication parameter				
P32.00	Device name	When the setting value is 0, it is configured by the host computer and no other display is made When the setting value is 1~255, the corresponding device name is mtpn-1~mtpn-255 Note: Effective after power on again	0	☆
P32.01	IP1	IP address format: IP1. IP2. IP3. IP4 When P32.01~P32.04 is set to 0 After power-on, the PN card will write the IP address stored in the card to the drive for display When you need to fix the IP address of the corresponding drive, set P32.01~P32.04 manually (effective after power on)	0	☆
P32.02	IP2		0	☆
P32.03	IP3		0	☆
P32.04	IP4		0	☆
P32.05	MAC1	The standard MAC address is 6 bytes, P32.05~P32.07 corresponds to the MAC address of two bytes, and the corresponding MAC address sequence is M AC1H-MAC1L-MAC2H-MAC2L-MAC3H-MAC3L (H-high 8 bits, L-low 8 bits). When P32.05~P32.07 is set to 0 After power-on, the PN card will write the address stored in the card to the drive for display Note: 1. Each port occupies an MAC address, it is recommended that the P32.07 bits not be modified, and the modification starts from 10 bits 2. The MAC modification must be powered back on to take effect 3. The MAC address should be		☆

Function code	Parameter name	Description	Default	Property
		4. Modified in the drive, and the MAC address of all devices in the network must not be duplicated (including port addresses). The port occupancy address is P32.07, with the lowest bit plus 1 (P1) and plus 2 (P2).		☆
P32.06	MAC2			☆
P32.07	MAC3			☆
P32.08	Ver	Displays the current software version available for PN		☆
40 Group PID function				
r40.00	PID final output value	Read only unit:0.1%	-	●
r40.01	PID final set value	Read-only, physical measurement, the unit is the same as P40.05	-	●
r40.02	PID final feedback value	Read-only, physical measurement, the unit is the same as P40.05	-	●
r40.03	PID deviation value	Read only unit:0.01%	-	●
<p>PID through the target signal (command) and the controlled amount of the difference between the feedback signal proportional (P), integral (I) and differential (D) operation, adjust the inverter output frequency, etc., to achieve closed-loop system, the controlled amount Stable at the target value.</p> <p>VFD500 built-in process PID structure as shown below, suitable for flow control, pressure control, temperature control and tension control applications.</p>				
P40.04	PID reference source	Bit 0~3: PID main given source (ref1) 0: Digital given 1: AI1 2: AI2 3: AI3 4: Reserved 5: HDI 6: Communication setting (address 0x1D07) Bit 4~7: PID auxiliary given source (ref2) Same bit 0~3	0x00	☆

Function code	Parameter name	Description	Default	Property															
P40.05	PID given and feedback range	0.01~655.35 The units of r40.01 and r40.02 are the same as the set value, and the factory value of 100.00 can be regarded as no unit. The unit of P40.06~P40.09 is the same as this setting value.	100.00	☆															
P40.06	PID digital setting 0	0.00~P40.05	0.00	☆															
P40.07	PID digital setting 1	0.00~P40.05	0.00	☆															
P40.08	PID digital setting 2	0.00~P40.05	0.00	☆															
P40.09	PID digital setting 3	0.00~P40.05	0.00	☆															
When PID reference source is digital setting, PID digital setting 0~3 depend on DI terminal function 43 (preset PID terminal 1) and 44 (preset PID terminal 2):																			
<table><tr><td>Preset PID terminal1</td><td>Preset PID terminal 2</td><td>PID Digital setting value</td></tr><tr><td>Ineffective</td><td>Ineffective</td><td>P40.06</td></tr><tr><td>Ineffective</td><td>Effective</td><td>P40.07</td></tr><tr><td>Effective</td><td>Ineffective</td><td>P40.08</td></tr><tr><td>Effective</td><td>Effective</td><td>P40.09</td></tr></table>					Preset PID terminal1	Preset PID terminal 2	PID Digital setting value	Ineffective	Ineffective	P40.06	Ineffective	Effective	P40.07	Effective	Ineffective	P40.08	Effective	Effective	P40.09
Preset PID terminal1	Preset PID terminal 2	PID Digital setting value																	
Ineffective	Ineffective	P40.06																	
Ineffective	Effective	P40.07																	
Effective	Ineffective	P40.08																	
Effective	Effective	P40.09																	
For example: When AI1 is used as PID feedback, if the full range corresponds to 16.0kg pressure and require PID control to be 8.0kg; then set P40.05 PID feedback range to 16.00, PID digital reference terminal select to P40.06, Set P40.06 (PID preset setting 0) to be 8.00																			
P40.10	PID reference source selection	0: Ref1 1: Ref1+ref2 2: Ref1-ref2 3: Ref1*ref2 4: Ref1/ref2 5: Min(ref1,ref2) 6: Max(ref1,ref2) 7: (ref1+ref2)/2 8: Fdb1and fdb2 switchover	0	☆															
P40.11	PID feedback source	Bit 0~3: PID feedback source 1 (fdb1) 0: AI1 1: AI2 2: AI3 3: Reserved 4: HDI 5: Communication given 6: Motor output current 7: Motor output frequency 8: Motor output torque 9: Motor output power Bit 4~7: PID feedback source 2 (fdb2) Same bit 0~3	0x00	☆															

Function code	Parameter name	Description	Default	Property
P40.13	PID feedback function selection	0: Fdb1 1: Fdb1+fdb2 2: Fdb1-fdb2 3: Fdb1*fdb2 4: Fdb1/fdb2 5: Min(fdb1,fdb2) 6: Max(fdb1,fdb2) 7: (ref1+ref2)/2 8: Fdb1 and fdb2 switchover	0	☆
P40.14	PID deviation inversion	0: No negation; 1: Negation	0	☆
Whether the PID deviation is reversed or not is determined jointly by P40.14 and DI terminal No. 42 function "PID forward/reverse action switching": P40.14 = 0 and "42: PID positive/reverse switching" terminal is invalid: PID deviation is not negative P40.14 = 0 and "42: PID positive/negative switching" terminal is valid: PID deviation is negative P40.14 = 1 and "42: PID forward/reverse switching" terminal is invalid: PID deviation is negative P40.14 = 1 and "42: PID forward/reverse switching" terminal is valid: PID deviation is not negative				
P40.15	PID output upper limit	-100.00%~100.00%	100.00%	☆
P40.16	PID output lower limit	-100.00%~100.00%	0.00%	☆
P40.17	Proportional gain KP1	0.0~200.0%	5.0%	☆
P40.18	Integration time TI1	0.000s(no integral action)~20.000s	1.000s	☆
P40.19	Derivative time TD1	0.000s~0.100s	0.000s	☆
P40.20	Proportional gain KP2	0.0~200.0%	5.0%	☆
P40.21	Integration time TI2	0.000s(no integral action)~20.000s	1.000s	☆
P40.22	Derivative time TD2	0.000s~0.100s	0.000s	☆
P40.23	PID switching condition	0: Do not switch, use KP1, TI1, TD1 1: Switch through DI terminal. Use KP1, TI1, TD1 when the function of DI terminal No. 41 is invalid; use KP2, TI2, TD2 when it is valid 2: Automatic switching according to the deviation If the absolute value of PID command and feedback deviation is less than P40.24, use KP1, TI1, TD1; if the absolute value of deviation is greater than P40.25, use KP2, TI2, TD2 parameters; if the absolute value of deviation is between P40.24~P40.25, The two sets of parameters are linearly transitioned.	0	☆
P40.24	PID parameter switching deviation 1	0.00%~P40.25	20.00%	☆
P40.25	PID parameter switching deviation 2	P40.24~100.00%	80.00%	☆
P40.26	PID integral separation threshold	0.0%~100.00%	100.00%	☆
P40.27	PID initial value	0~100.00%	0.00%	☆
P40.28	PID initial value hold time	0.000~650.00s	0.000s	☆
This function is only valid when P40.39 = 0 and the PID output is reset after the inverter stops. If P40.28 ≠ 0, after the inverter runs, the PID output is equal to the initial value of PID, and the time of P40.28 is maintained.				

Function code	Parameter name	Description	Default	Property
P40.29	PID deviation dead zone	0.0%~100.00%	0.00%	☆
P40.30	PID differential limit	0.00%~100.00%	1.00%	☆
P40.33	PID feedback filter time	0.000~30.000s	0.01s	☆
P40.34	PID output filter time	0.000~30.000s	0.01s	☆
P40.35	PID feedback loss detection threshold (lower limit)	0.0%(not detected)~100.00%	0.00%	☆
P40.36	PID feedback loss lower limit detection time	0.000s(not detected)~30.000s	0.000s	☆
P40.37	PID feedback loss detection threshold (upper limit)	0.0%~100.00% (not detected)	100.00%	☆
P40.38	PID feedback loss upper limit detection time	0.000s(not detected)~30.000s	0.000s	☆
P40.39	PID shutdown calculation	0: No operation at stop 1: Stop operation	0	☆
P40.40	PID command acceleration and deceleration time	0.000s~6000.0s	0.0s	☆
P40.41	PID compensation selection	0: Digital setting 1:All 2:AI2 3:AI3	0.100s	☆
P40.42	PID compensation digital setting	-0.00%~100.00%	0.0%	☆
P40.43	PID feedback loss detection starting condition	0: Direct detection 1: Start detection when the absolute value of P40.03 is less than P40.44 2: Start detection after delaying P40.45	0	☆
P40.44	PID feedback loss detection starting deviation	0.00%~100.00%	10.00	☆
P40.45	PID feedback loss detection delay time	0.000s~60.000s	0	☆

41 Group Sleeping function				
Function code	Parameter name	Description	Default	Property
P41.00	Sleep mode and wake up selection	<p>Unit's digit: sleep mode selection</p> <p>0:no sleep function</p> <p>1:Sleep by frequency</p> <p>2:AI1 sleep (AI1 as pressure feedback)</p> <p>3:AI2 sleep(AI2 as pressure feedback)</p> <p>4:AI3 sleep (AI3 as pressure feedback)</p> <p>Ten's digit :wake up mode selection</p> <p>0:Wake up by frequency</p> <p>1:AI1 wake up (AI1 as pressure feedback)</p> <p>2:AI2 wake up (AI2 as pressure feedback)</p> <p>3:AI3 wake up (AI3 as pressure feedback)</p> <p>Hundred's digit: Sleep wake direction selection</p> <p>0: positive direction</p> <p>Sleep source (AI1 ~ AI4) > P41.03, inverter will sleep</p> <p>Wake-up source (AI1 ~ AI4) < P41.04, the inverter will wake up</p> <p>1: reverse direction</p> <p>Sleep source (AI1 ~ AI4) < P41.03, inverter sleep</p> <p>Wake-up source (AI1 ~ AI4) > P41.04, the inverter wakes up.</p> <p>When the sleep source and wakeup source are the same, please pay attention to the size relationship of P41.03 and P41.04. If the parameter setting is unreasonable, when the wake-up condition is selected, even if the sleep condition is established, the sleep state cannot be entered, and special attention is required when using.</p>	010	☆

Function code	Parameter name	Description	Default	Property
P41.01	Sleep setting value by frequency	0.00Hz~600HZ,It will sleep if value is less than this value	0.00Hz	☆
When selecting frequency sleep and frequency wake-up, it must be set by P41.01 < P41.02. When the frequency source is PID setting, and the frequency wake-up must be set to PID shutdown operation: P40.39 = 1.				
P41.02	Frequency sleep wake-up value	0.00Hz~600HZ,It will sleep if value is greater than this value	0.00Hz	☆
P41.03	Sleep setting value by pressure	0~100.0%	0.0%	☆
P41.04	Wake up threshold by pressure	0.~100.0%	0.0%	☆
P41.05	Sleep delay time	0.0s~6000.0s	0.0s	☆
P41.06	Wake up delay up	0.0s~6000.0s	0.0s	☆
P41.07	Sleep decelerating time	Setting value decide by P03.16 P03.16 = 2, 0.00~600.00s; P03.16 = 1, 0.0s~6000.0s; P03.16 = 0, 0s~60000s P41.07 set to 0,sleeping stop mode to free coast.	0.00s	☆
42 Group Simple PLC				
r42.00	PLC current running mode	Read only	-	●
r42.01	PLC current running remaining time	Read only	-	●
r42.02	PLC times of cycles	Read only	-	●
P42.03	Simple PLC running mode	Unit'digit: 0: single cycle then stop 1: single cycle then keep last speed 2: recycle 3: Plc reset when single cycle stop Ten's digit: 0:power off without saving 1:power off with saving Hundred'digit: 0:stop without saving 1:stop with saving 0 : Restart from the first stage; stop during running (cause by the stop command, fault or power loss), run from the first stage after restart. 1 : Continue to run from the stop frequency; stop during running(cause by stop command and fault), the inverter will record the running time automatically, enter into the stage after restart and keep the remaining running at the setting frequency.	003	☆


Function code	Parameter name	Description	Default	Property
P42.04	PLC running times	1~60000	1	☆
P42.05	PLC step 1 running time	0.0~6553.5 unit depend on P42.21 Notice: Running time do not conclude acceleration and deceleration time, same as following	0.0	☆
P42.06	PLC step 2 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.07	PLC step 3 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.08	PLC step 4 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.09	PLC step 5 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.10	PLC step 6 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.11	PLC step 7 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.12	PLC step 8 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.13	PLC step 9 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.14	PLC step 10 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.15	PLC step 11 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.16	PLC step 12 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.17	PLC step 13 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.18	PLC step 14 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.19	PLC step 15 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.20	PLC step 16 running time	0.0~6553.5 unit depend on P42.21	0.0	☆
P42.21	PLC running time unit	0:S;1:minute;2:hour	0	☆

Function code	Parameter name	Description	Default	Property
P42.22	PLC step 1-4 ACCEL/DECEL time selector	Unit'digit: step 1 ACCEL/DECEL time selector ten'digit: step 2 ACCEL/DECEL time selector Hundred's: step 3 ACCEL/DECEL time selector Thousand'unit: step 4 ACCEL/DECEL time selector 0- ACCEL/DECEL time 1 1- ACCEL/DECEL time 2 2- ACCEL/DECEL time 3 3- ACCEL/DECEL time 4	0000	☆
P42.23	PLC step 5-8 ACCEL/DECEL time selector	Unit'digit: ACCEL/DECEL time 5 Ten'digit: ACCEL/DECEL time 6 Hundred'digit: ACCEL/DECEL time 7 Thousand'digit: ACCEL/DECEL time 8 0- ACCEL/DECEL time 1 1- ACCEL/DECEL time 2 2- ACCEL/DECEL time 3 3- ACCEL/DECEL time 4	0000	☆
P42.24	PLC step 9-12 ACCEL/DECEL time selector	Unit'digit: ACCEL/DECEL time 9 ten'digit: ACCEL/DECEL time 10 Hundred'digit: ACCEL/DECEL time 11 Thousand'digit: ACCEL/DECEL time 12 0- ACCEL/DECEL time 1 1- ACCEL/DECEL time 2 2- ACCEL/DECEL time 3 3- ACCEL/DECEL time 4	0000	☆
P42.25	PLC step 13-16 ACCEL/DECEL time selector	Unit's Digit: ACCEL/DECEL time 13 Ten'Digit: ACCEL/DECEL time 14 Hundred'digit: ACCEL/DECEL time 15 Thousand's digit: ACCEL/DECEL tim 16 0- ACCEL/DECEL time 1 1- ACCEL/DECEL time 2 2- ACCEL/DECEL time 3 3- ACCEL/DECEL time 4	0000	☆
P42.26	PLC stop decelerating time	0.01~60000s Setting value decide by P03.16 P03.16 = 2, 0.00~600.00s; P03.16 = 1, 0.0s~6000.0s; P03.16 = 0, 0s~60000s	20.00s	☆

43 Group Programming delay-unit

Function code	Parameter name	Description	Default	Property
r43.00	Delay unit output status	It is used to view the current output status of the delay unit. Bit definition is used, Bit0~Bit3 respectively indicate the output status of delay units 1~4, 0 means invalid, 1 means valid.	-	●

VFD500 inverter built-in 4 delay unit. The delay unit can collect the status of 0 ~ 15 bits of all parameters that can be viewed in the function code table, and finally output the delay unit status after delay processing and logic selection. Can be used for DI / DO, comparator / logic unit output delay and other functions, but also as a virtual relay.




Delay unit 1 block diagram

The picture shows the delay unit 1 block diagram, delay unit 2 to 4 and so on. Delay unitsDelay can be used for DI/DO delay processing also can be combined with comparator units and logic units for more complex applications.

P43.01	Delay unit 1-4 logical	0000B~1111B Bit0~Bit3 corresponds to delay units 1~4, which are used to specify whether the output of the delay unit is inverted.	0	☆
P43.02	Delay unit 1 input parameter selection	00.00-98.99(function code index)	00.00	☆
P43.03	Delay unit 1 input bit selection	0-15	0	☆
P43.04	Delay unit 1 rising edge delay time	0.0s~3000.0s	0.0s	☆
P43.05	Delay unit 1 descending edge delay time	0.0s~3000.0s	0.0s	☆
P43.06	Delay unit 2 input parameter selection	00.00-98.99(function code index)	00.00	☆
P43.07	Delay unit 2 input bit selection	0-15	0	☆
P43.08	Delay unit2 rising edge delay time	0.0s~3000.0s	0.0s	☆
P43.09	Delay unit2descending edge delay time	0.0s~3000.0s	0.0s	☆

Function code	Parameter name	Description	Default	Property
P43.10	Delay unit 3 input parameter selection	00.00-98.99(function code index)	00.00	☆
P43.11	Delay unit 3 input bit selection	0-15	0	☆
P43.12	Delay unit3 rising edge delay time	0.0s~3000.0s	0.0s	☆
P43.13	Delay unit3descending edge delay time	0.0s~3000.0s	0.0s	☆
P43.14	Delay unit 4 input parameter selection	00.00-98.99(function code index)	00.00	☆
P43.15	Delay unit 4 input bit selection	0-15	0	☆
P43.16	Delay unit4 rising edge delay time	0.0s~3000.0s	0.0s	☆
P43.17	Delay unit4 descending edge delay time	0.0s~3000.0s	0.0s	☆
44 Group Variable selector and logic block				
r44.00	Variable selector 1~4 output	bit0~3 indicate the output of variable selector 1-4	-	●
r44.01	Logic block 1~4 output	bit0~3 indicate the output of logic block 1~4	-	●
P44.02	Variable selector 1 input parameter	00.00~98.99(Function code index)	00.00	☆
P44.03	Variable selector1 threshold	00.00~98.99(Function code index)	00.00	☆
P44.04	Variable selector 1 logic mode	0:>; 1:<; 2:S;3:S;4:=; 5:/; 6:=	0	☆
P44.05	Variable selector 1 hysteresis width	0~65535	0	☆
VFD500 inbuilt 4 group variable selector, this function can be used for any two function code parameters, by selecting the comparison relationship, and output will be 1 if it meets conditions or it will be 0. Variable selector output can act as DI,VDI, virtual relay input and DO, relay etc. output. User s can easily and flexibly get logic function , variable selector 1 frame as follows				



Left: variable selector graph Right: hysteresis width graph

Function code	Parameter name	Description	Default	Property
P44.06	Variable selector 2 input parameter	00.00-98.99(function code index)	00.00	☆
P44.07	Variable selector 2 threshold	00.00-98.99(function code index)	00.00	☆
P44.08	Variable selector 2 logic mode	0:>; 1:<; 2:S;3:S;4:=; 5:/; 6:=	0	☆
P44.09	Variable selector 2 hysteresis width	0~65535	0	☆
P44.10	Variable selector 3 input parameter	00.00-98.99(function code index)	00.00	☆
P44.11	Variable selector 3 threshold	00.00-98.99(function code index)	00.00	☆
P44.12	Variable selector 3 logic mode	0:>; 1:<; 2:S;3:S;4:=; 5:/; 6:=	0	☆
P44.13	Variable selector 3 hysteresis width	0~65535	0	☆
P44.14	Variable selector 4 input parameter	00.00-98.99(function code index)	00.00	☆
P44.15	Variable selector 4 threshold	00.00-98.99(function code index)	00.00	☆
P44.16	Variable selector 4 logic mode	0:>; 1:<; 2:S;3:S;4:=; 5:/; 6:=	0	☆
P44.17	Variable selector 4 hysteresis width	0~65535	0	☆
P44.18	Logic block 1 threshold parameter 1	00.00-98.99(function code index)	00.00	☆
P44.19	Logic block 1 threshold parameter2	00.00-98.99(function code index)	00.00	☆

Function code	Parameter name	Description	Default	Property
P44.20	Logic block 1 input source	Unit'digit: parameter 1 bit selection 0-F (Represent 0-15),P44.18 corresponds to 0-15 bit Ten'digit: parameter 2 bit selection 0-F (Represent 0-15),P44.19 corresponds to 0-15 bit	0	
P44.21	Logic block 1 function	0:no function;1:and; 2:or; 3:not and; 4:not or; 5: exclusive OR 6:Ref=1 effective;Ref2=1 ineffective 7:Ref1 up effective,Ref2 up ineffective 8:Ref1 up and signal reverse 9:Ref1 up and output 200ms pulse width	0	☆
<p>VFD500 built-in 4 logical units. The logic unit can perform any one of 0-15 bits of any parameter 1 and any one of 0-15 bits of any parameter 2 for logic processing. The condition is true output 1, otherwise 0 is output. Logic unit output can be used as DI, VDI, delay unit and other inputs, DO, relays and other output, the user can more flexible access to the required logic. The schematic block diagram of the logic unit 1 is as follows.</p>				
P44.22	Logic block 2 threshold parameter 1	00.00-98.99(function code index)	00.00	☆
P44.23	Logic block 2 threshold parameter2	00.00-98.99(function code index)	00.00	☆
P44.24	Logic block 2 input source	Unit'digit: parameter 1 bit selection 0-F (Represent 0-15),P44.22 corresponds to 0-15 bit Ten'digit: parameter 2 bit selection 0-F (Represent 0-15),P44.23 corresponds to 0-15 bit	0	☆

Function code	Parameter name	Description	Default	Property
P44.25	Logic block 2 function	0:no function; 1:and; 2:or; 3:not and; 4:not or; 5: exclusive OR 6:Ref=1 effective;Ref2=1 ineffective 7:Ref1 up effective,Ref2 up ineffective 8:Ref1 up and signal reverse 9:Ref1 up and output 200ms pulse width	0	☆
P44.26	Logic block 3 threshold parameter 1	00.00-98.99(function code index)	00.00	☆
P44.27	Logic block 3 threshold parameter2	00.00-98.99(function code index)	0	☆
P44.28	Logic block 3 input source	Unit'digit: parameter 1 bit selection 0-F (Represent 0-15),P44.26 corresponds to 0-15 bit Ten'digit: parameter 2 bit selection 0-F (Represent 0-15),P44.27 corresponds to 0-15 bit	0	☆
P44.29	Logic block 3 function	0:no function; 1:and; 2:or; 3:not and; 4:not or; 5: exclusive OR 6:Ref=1 effective;Ref2=1 ineffective 7:Ref1 up effective,Ref2 up ineffective 8:Ref1 up and signal reverse 9:Ref1 up and output 200ms pulse width	0	☆
P44.30	Logic block 4 threshold parameter 1	00.00-98.99(function code index)	00.00	☆
P44.31	Logic block 4 threshold parameter2	00.00-98.99(function code index)	00.00	☆
P44.32	Logic block 4 input source	Unit'digit: parameter 1 bit selection 0-F (Represent 0-15),P44.30 corresponds to 0-15 bit Ten'digit: parameter 2 bit selection 0-F (Represent 0-15),P44.31 corresponds to 0-15 bit	0	☆
P44.33	Logic block 4 function	0:no function; 1:and; 2:or; 3:not and; 4:not or;	0	☆


Function code	Parameter name	Description	Default	Property
		5: exclusive OR 6:Ref=1 effective;Ref2=1 ineffective 7:Ref1 up effective,Ref2 up ineffective 8:Ref1 up and signal reverse 9:Ref1 up and output 200ms pulse width		
P44.34	Constant setting 1	0~65535	0	☆
P44.35	Constant setting 2	0~65535	0	☆
P44.36	Constant setting 3	0~65535	0	☆
P44.37	Constant setting 4	-9999~9999	0	☆
P44.38	Constant setting 1 as per bit definition	0~65535(define as bit)	0	☆
P44.39	Constant setting 2 as per bit definition	0~65535(define as bit)	0	☆
P44.40	Constant setting 3 as per bit definition	0~65535(define as bit)	0	☆
P44.41	Constant setting 4 as per bit definition	0~65535(define as bit)	0	☆
Constant setting for reference of variable selector or logic block input				
45 Group Multi-functional counter				
r45.00	Counter 1 input value	The count value before the electronic gear, that is, the number of pulses received by the counter 1 hardware, 32-bit read-only data	-	●
r45.02	Counter 1 count value	Count value after electronic gear, 32-bit read-only data	-	●
P45.04	Counter 1 set value	1 to 4294967295, when the counter 1 count value (after the electronic gear) reaches this setting, the DO function "Counter 1 set value reached" is valid.	1000	☆
P45.06	Counter 1 maximum value	1 to 4294967295, set the maximum value of counter 1 (after electronic gear)	4294967295	☆
P45.08	Counter 1 Electronic gear numerator	1~65535 Counter 1 count value = counter 1 input value × (electronic gear numerator / electronic gear denominator)	1	☆
P45.09	Counter 1 Electronic gear denominator	1~65535	1	☆

VFD500 has two inbuilt counters: Counter 1 is a 32-bit multifunction counter with electronic gears; counter 2 is a 16-bit normal counter with no electronic gear function. Now take the counter 1 as an example to briefly explain its function and use, and the counter 2 will not be specified.

The counter 1 receives the pulse signal through the terminal corresponding to the DI function "Counter 1 input", and the pulse signal is used for the counter 1 counting after passing through the electronic gear. When the count value reaches the set value (P45.04), the DO function "Counter 1 set value reached" is valid; when the count value reaches the maximum value (P45.06), select whether to stop counting or reset the count according to P45.13. value.

The counter can also be reset by the DI terminal. When the DI Terminal is the "Counter 1 reset" function and the terminal is valid, the counter 1 is reset.

For example: P45.04=3, P45.08=3, P45.09=1, the function of counter 1 is as shown below.



Function code	Parameter name	Description	Default	Property
P45.14	Counter 2 control	Unit's digit: counting method 0: Stop counting after counting the maximum value 1: Reset after counting the maximum value, recount from 0 Ten's digit: the action after the counter reaches the set value 0: continue to run 1: Free stop 2: Ramp to stop 3: Emergency stop Hundred's digit : Power-down save option 0: Do not save the count value when power is off 1: save the count value when power is off	100	☆
P45.15	Material break detection input source	0: Counter 1 count value 1: Counter 2 count value	1	RW
P45.16	Material break detection starting frequency	0~50.00Hz When the operating frequency is greater than the set value, material outage detection starts.	10.00	RW
P45.17	Material break detection time	0~60.000s When the counter value does not change within the set value time, a material outage fault occurs.	0	RW
58 Group Fire Mode				
P58.00	Fire mode function	0: Invalid Fire mode is invalid, the inverter operates in normal mode. 1: Fire mode 1 In fire condition, all fault detections are masked the inverter will operate continuously until it is damaged. 2: Fire mode 2 OC, OV fault detect and protect, other faults shielded.	0	RR
P58.01	Running Frequency of Fire Mode	Set the operating frequency in the fire mode.	50.00Hz	RW
r58.02	No-warranty mark of fire mode	When the continuous running time under fire mode exceeds P58.04, this flag will be set to 1, and the VFD is out of warranty. The keyboard shows A. FirE.	0	RO
P58.03	Fire Mode running freq. channel	0: Fire mode running frequency set in P58.01. 1: Fire mode running frequency same to setting in P01.00~P01.05.	0	RW

Function code	Parameter name	Description	Default	Property
P58.04	No-warranty time setting	If the continuous running time in fire mode exceeds this setting, P58.02 will be set to 1, and the VFD is out of warranty. The keyboard displays A.FirE. Set this parameter to 0 to clear the no-warranty mark.	300s	RW
r58.05	Fire mode status	When P58.00/0 and the terminal corresponding to the DI-57 function is valid, this flag is set to 1. It is used to indicate whether it is currently working in a fire state.	0	RO
DI function: 57 fire signal input DO function: 45 fire status output Parameter Modification Method for 380V Inverter Using 220V Power Supply: P00.16=2048, enter agency authority Modify the following two parameters to make it lower than the actual power supply voltage, it can run normally! P22.21: Soft start relay pull-in voltage, unit: V				
60 Group Motor 2 basic parameter				
P60.00	Control mode	Same as P00.04	0	★
P60.01	Upper limit frequency	Same as P01.07	0	★
P60.02	Upper limit frequency digital setting	Lower limit (P01.09) ~ maximum frequency(P01.06)	50.00Hz	☆
P60.04	Accel and Decel time option	0:same as motor 1 1:Accel and Decel time 3 When choose 1,Motor 2 can convert between accel and decal time 3 and 4 by DI terminal function code 55 or switch by output frequency comparing with P60.05 P60.063	0	★
P60.05	Accel time frequency switchover 2	0.00Hz~maximum frequency (P01.06)	0.00Hz	☆
P60.06	Decel time frequency switchover 2	0.00Hz~maximum frequency(P01.06)	0.00Hz	☆
61 Group Motor2 parameter				
61.xx same as motor 1 parameter P11.xx				
62 Group Motor 2 VF control parameter				
62.xx same as motor 1 VF control P12.xx				
63 Group Motor 2 Vector control parameter				
63.xx same as motor 2 Vector control P13.xx				

Chapter 6 Fault Diagnosis and Solution

6.1 Failure and diagnosis

The VFD500 inverter has perfect protection. If a fault occurs, the inverter will act according to the fault attribute. For more serious faults, the inverter will directly block the output; for general faults, it can be configured to stop or continue to operate according to the scheduled stop mode. After the inverter fails, the fault relay contacts act and the fault code is displayed on the display panel. Before seeking service, users can perform self-checking according to the tips in this section, analyze the cause of the fault, and find a solution.

Fault Name	Fault code	Display	Possible Causes	Solutions
Inverter unit protection	1	Er. SC Er. SC	1: Motor insulation aging 2: The cable is damaged and contact, short circuit 3: The distance between motor and inverter are too long. 4: Output transistor breakdown 5: The internal wiring of the inverter is loose, or the hardware is bad. 6: Brake transistor short circuit	1. Confirm the insulation resistance of the motor. If it is turned on, replace the motor. 2. Check the power cable of the motor 3. Install reactor or output filter 4, seeking technical support 5, seeking technical support 6. Check if the braking resistor is damaged and the wiring is correct.
Over current during acceleration	2	Er.OC1 Er.OL1	1: The output circuit is grounded or short circuited. 2: Motor auto-tuning is not performed. 3: The acceleration time is too short. 4: Manual torque boost or V/F curve is not appropriate. 5: The voltage is too low. 6: The startup operation is performed on the rotating motor. 7: A sudden load is added during acceleration. 8: The frequency inverter model is	1: Eliminate external faults. 2: Perform the motor auto-Tuning in cold state 3: Increase the acceleration time. 4: Adjust the manual torque boost or V/F curve. 5: Adjust the voltage to normal range. 6: Select rotational speed tracking restart or start the motor after it stops. 7: Remove the added load. 8: Select a frequency inverter Of higher power class.
Over current during deceleration	3	Er.OC2 Er.OL2	1: The output circuit is grounded or short circuited. 2: Motor auto-tuning is not performed. 3: The deceleration time is too short. 4: The voltage is too low. 5: A sudden load is added during deceleration. 6: The braking unit and braking resistor are not installed	1: Eliminate external faults. 2: Perform the motor auto-tuning. 3: Increase the deceleration time. 4: Adjust the voltage to normal range. 5: Remove the added load. 6: Install the braking unit And braking resistor.

Fault Name	Fault code	Display	Possible Causes	Solutions
Over current at constant speed	4	Er.OC3 Err.O3	1: The output circuit is grounded or short circuited. 2: Motor auto-tuning is not performed. 3: The voltage is too low. 4: A sudden load is added during operation. 5: The frequency inverter model is of too small power class.	1: Eliminate external faults. 2: Perform the motor auto-tuning. 3: Adjust The voltage to normal range. 4: Remove the added load. 5: Select a frequency Inverter of higher power class.
Over voltage during acceleration	5	Er.OU1 Err.OU1	1: The input voltage is too high 2: The surge voltage is mixed in the input power supply. 3: There is an external force to drive the motor to run, or the brake type load is too heavy 4: The acceleration time is too short 5: The motor is shorted to ground	1: The power supply voltage is reduced to the normal range 2: Install DC reactor 3: Cancel the external force of the draggable motor or install the brake unit 4: Increase the acceleration time 5: Eliminate the part of the ground short circuit
Overvoltage during deceleration	6	Er.OU2 Err.OU2	1: The input voltage is too high 2: The surge voltage is mixed in the input power supply. 3: There is an external force to drive the motor to run, or the brake type load is too heavy 4: The deceleration time is too short 5: The motor is shorted to ground	1: The power supply voltage is reduced to the normal range 2: Install DC reactor 3: Cancel the external force of the draggable motor or install the brake unit 4: Increase the deceleration time 5: Eliminate the part of the ground
Over voltage at constant speed	7	Er.OU3 Err.OU3	1: The input voltage is too high 2: The surge voltage is mixed in the input power supply. 3: There is an external force to drive the motor to run, or the brake type load is too heavy 4: The acceleration or deceleration time is too short 5: The motor is shorted to ground	1: The power supply voltage is reduced to the normal range 2: Install DC reactor 3: Cancel the external force of the draggable motor or install the brake unit 4: Increase the acceleration or deceleration time 5: Eliminate the part of the ground

Fault Name	Fault code	Display	Possible Causes	Solutions
Low voltage	8	Er.Lv1 Er.Lv1	<p>1: Instantaneous power failure occurs on the input power supply or input phase loss</p> <p>2: The frequency inverter's input voltage is not within the allowable range.</p> <p>3: Cut off the power during operation</p> <p>4:the internal wiring of the inverter is loose, or the hardware is bad.</p>	<p>1:Check if the input power supply is abnormal, whether the input power terminal is loose, whether the input contactor or the air switch is abnormal.</p> <p>2:adjust the voltage to the normal range</p> <p>3:Power off after the inverter stops</p> <p>4:seeking technical support</p> <p>5: For the unstable power supply, if the performance requirements are low, try to enable the undervoltage stall function (P23.00).</p>
Contactor open	9	Er.Lv2 Er.Lv2	<p>1: Instantaneous power failure occurs on the input power supply</p> <p>2: The frequency inverter's input voltage is not within the allowable range.</p> <p>3: Cut off the power during operation</p> <p>4:the internal wiring of the inverter is loose, or the hardware is bad.</p>	<p>1:Check if the input power supply is abnormal, whether the input power terminal is loose, whether the input contactor or the air switch is abnormal.</p> <p>2:adjust the voltage to the normal range</p> <p>3:Power off after the inverter stops</p> <p>4:seeking technical support</p> <p>5: For the unstable power supply, if the performance requirements are low, try to enable the undervoltage stall function (P23.00).</p>
Frequency inverter overload	10	Er. Ol Er. ol	<p>1:The load is too large or the motor is blocked.</p> <p>2:The large inertia load acceleration and deceleration time is too short</p> <p>3: When the VF is controlled, the torque boost or V/F curve is not suitable.</p> <p>4:The frequency converter selection is too small</p> <p>5:Overload at low speed operation</p>	<p>1. Reduce the load and check the motor and mechanical conditions.</p> <p>2, increase the acceleration and deceleration time</p> <p>3. Adjust the torque boost or V/F curve</p> <p>4, select the inverter with a larger power level</p> <p>5. Perform motor self-learning in cold state and reduce carrier frequency at low speed</p>

Fault Name	Fault code	Display	Possible Causes	Solutions
Motor overload	11	Er.oL1 Er.oL1	1:The load is too large or the motor is blocked. 2:The large inertia load acceleration and deceleration time is too short 3:When the VF is controlled, the torque boost or V/F curve is not suitable. 4:The motor selection is too small 5:overload at low speed operation 6:Improper setting of motor parameters and motor protection parameters	1. Reduce the load and check the motor and mechanical conditions. Correctly set the motor parameters and motor protection parameters. 2, increase the acceleration and deceleration time 3. Adjust the torque boost or V/F curve 4, select a motor with a higher power level 5. Perform motor self-learning in cold state and reduce carrier frequency at low speed 6, check the settings of related parameters
Power input phase loss	12	Er.iLP Er.iLP	1: The three-phase power input is abnormal. 2: The drive board is faulty. 3: Thelightning proof board is faulty. 4: The main control board is faulty.	1:Eliminate external faults. 2: Ask for technical support. 3: Ask for technical support. 4: Ask for technical support.
Power output phase loss	13	Er.oLP Er.oLP	1: The cable connecting the frequency inverter and the motor is faulty. 2: The frequency inverter's three-phase outputs are unbalanced when the motor is running. 3: The drive board is faulty. 4: The IGBT module is faulty.	1:Eliminate external faults. 2: Check whether the Motor three phase winding is normal. 3: Ask for technical support. 4: Ask for technical support.

Fault Name	Fault code	Display	Possible Causes	Solutions
IGBT Module overheat	14	Er. oH Er. oH	1: The ambient temperature is too high. 2: The air filter is blocked. 3: The fan is damaged. 4: The thermally sensitive resistor of the IGBT module is damaged. 5: The inverter IGBT module is damaged	1: Lower the ambient temperature. 2: Clean the air filter. 3: Replace the damaged fan. 4: Replace the damaged thermally sensitive resistor. 5: Replace the inverter module.
Motor overheat	16	Er. oH3 Er. oH3	1: The temperature sensor wiring is loose 2: The motor temperature is too high 3: The motor temperature sensor detects that the temperature is greater than the set threshold.	1: Check the temperature sensor wiring 2: Improve the carrier frequency, strengthen the heat dissipation of the motor, reduce the load, and select a motor with higher power. 3: Check if the set threshold is reasonable.
By wave current limiting fault	17	Er. CbC Er. CbC	1: The load is too heavy or locked-rotor occurs on the motor. 2: The frequency inverter model is of too small power class	1: Reduce the load and check the motor and mechanical condition. 2: Select a frequency inverter of higher power class.
Ground short circuit	18	Er. GF Er. GF	1. Motor burnout or insulation aging 2, The cable is damaged and contact, short circuit 3. The distributed capacitance of the \oplus terminal and motor cable is larger motor cable 4, Hardware is damaged	1. Confirm the insulation resistance of the motor. If it is turned on, replace the motor. 2. Check the power cable of the motor to eliminate the fault point. 3, reduce the carrier frequency, install the output reactor 4, seeking technical support
Module temperature detection fault	20	Er. tCK Er. tCK	1, Temperature detection line broken 2, Drive board is faulty 3. Main control board is faulty 4, The environmental temperature is too low	1. Check the thermistor wiring 2. Ask for technical support 3. Ask for technical support 4, manual intervention to drive the temperature rise
Current detection fault	21	Er. Cur Er. CUR	1: The HALL device is faulty. 2: The drive board is faulty. 3: The control board is faulty	1: Replace the faulty HALL device. 2: Replace the faulty drive board. 3: Ask for technical support.

Fault Name	Fault code	Display	Possible Causes	Solutions
Encoder offline	22	Er.PGL Er.PGL	<ol style="list-style-type: none"> 1. Motor locked 2. Encoder pulse setting wrong 3. Encoder offline 	<ol style="list-style-type: none"> 1 check motor and mechanical condition 2 set correct parameter for encoder 3 check encoder connecting line
Motor over-speed	25	Er.oS Er.oS	<ol style="list-style-type: none"> 1: The encoder parameters are set incorrectly. 2: The motor auto-tuning is not performed. 3: The over-speed detection parameters are set incorrectly 	<ol style="list-style-type: none"> 1: Set the encoder parameters properly. 2: Perform the motor auto-tuning. 3: Set the over-speed detection parameter correctly based on the actual situation.
Too large speed deviation	26	Er.DEV Er.dEv	<ol style="list-style-type: none"> 1: The encoder parameters are set incorrectly. 2: The motor auto-tuning is not performed. 3: The detection parameters of too large speed deviation are set incorrectly. 	<ol style="list-style-type: none"> 1: Set the encoder parameters properly. 2: Perform the motor auto-tuning. 3: Set the detection parameters correctly based on the actual situation.
Motor auto-tuning fault 1	27	Er.tU1 Er.tU1	<ol style="list-style-type: none"> 1: The motor parameters are not set according to the nameplate. 2: The motor auto-tuning times out. 	<ol style="list-style-type: none"> 1: Set the motor parameters according to the name plate properly. 2: Check the cable connecting between the Frequency inverter and the motor.
Motor auto-tuning fault 3	28	Er.tU3 Er.tU3	<ol style="list-style-type: none"> 1: The motor parameters are not set according to the nameplate. 2: The motor auto-tuning times out. 	<ol style="list-style-type: none"> 1: Set the motor parameters according to the name plate properly. 2: Check the cable connecting between the Frequency inverter
Off load	31	Er.LL Er.LL	<ol style="list-style-type: none"> 1. The frequency inverter running current is lower than the setting value. 	<ol style="list-style-type: none"> 1. Confirm whether the load is off 2. Check that the load is disconnected or the parameter setting is correct
EEPROM read- write fault	32	Er.EEP Er.EEP	<ol style="list-style-type: none"> 1. Eeprom Operate too frequent 2. The EEPROM chip is damaged. 	<ol style="list-style-type: none"> 1. Operate Eeprom suitable 2. Replace the main control board
Running time arrival	33	Er.TTA Er.tTA	Inverter trial time arrival	1:Contact agent or distributor
485 Communication fault	34	Er.485 Er.485	<ol style="list-style-type: none"> 1, The work of the host computer is not normal 2, The communication line is not normal 3, The communication parameter set is incorrect 	<ol style="list-style-type: none"> 1. Check the connection of upper computer 2. Check the communication connection line 3. Set communication parameters correctly

Fault Name	Fault code	Display	Possible Causes	Solutions
PID feedback lost during running	36	Er.FbL Er.FbL	1s PID feedback<P40.35 setting value and P40.36 not zero,PID feedback>P40.37 setting value and P40.38 not zero	1s Check PID feedback signal 2s P40.35 and P40.37 set correct parameter
User-defined fault 1	37	Er.Ud1 Er.Ud1	1: The signal of user-defined fault 1 is input via DI. 2:The signal of user-defined fault 1 is input via virtual I/O.	1: Reset the operation. 2: Reset the operation
User-defined fault 2	38	Er.Ud2 Er.Ud2	1: The signal of user-defined fault 2 is input via DI. 2:The signal of user-defined fault 2 is input via virtual I/O.	1: Reset the operation. 2: Reset the operation



The fault code is used for the communication read fault type: when the communication reads the registers r25.00, r26.00, r26.08, r26.16, the register contents of the reply are fault coded.

6.2 Warning type

The warning is used to remind and inform the user of the current state of the inverter. When the warning occurs, the keypad will display a warning message, and the warning will automatically reset when the warning is cleared. Some warnings require the user to check the cause before running the drive, and some do not care. Warning As an instant reminder, the drive does not store the corresponding information. Bit 12 of r27.10 indicates whether there is a warning message currently.

Warning name	Warning code	Display	Reason	Measure
Insufficient power	1	PoFF PoFF	1: The DC link voltage is insufficient and cannot be started normally.	1:Check if the inverter power supply is normal.
Wrong parameter	2	A.PARA APArA	1: The parameter settings are wrong, such as: The torque mode is set in the VF control mode.	1:Modify and check the parameter compatibility problem
Sleeping status	5	SLEEP SLEEP	1. The system is in a sleep state, and the system will automatically start when hibernation is over.	1:Generally no need to pay attention to it



The warning code is used for the communication read warning type: when the communication reads register r25.16, the contents of the returned register are the warning code.

Chapter 7 Selection Guide of inverter Accessory

7.1 Selection Guide of braking component

The braking resistor is used to consume the energy fed back by the motor to the inverter during braking or generating operation, so as to achieve quick braking or prevent the inverter from reporting the main circuit overvoltage fault. Braking resistor selection has two parameters: resistance and power, under normal circumstances, the greater the system inertia, the need for deceleration time is shorter, the more frequent braking, the braking resistor selection should be greater power, The smaller the resistance.

1. Selection of braking units

When braking, almost all the renewable energy of motor is consumed on the braking resistor.

$$R = \frac{U^2}{P_B}$$

Formula:

U --- The braking voltage when the system brakes stably (Different models have different values. Models with built-in braking unit can be set by P22.12)

R - Braking resistor

P_B – Braking Power

2 .Selection power of braking resistor

Braking resistor power can be calculated according to the following formula:

$$P_R = P_B \times D$$

Formula,

P_R----Braking resistor power

D----- Braking frequency (braking process accounts for the proportion of the entire process), by the load conditions to determine the characteristics of common occasions typical values are shown in the table below:

Table 7-1 Braking frequency of common applications

applications	D value
elevator	20%~40%
Unwinding and winding	40%~60%
Centrifuge	40%~60%
Hoist and crane	40%~60%
General application	10%

Braking components selection table

Table 7-2 VFD500 braking components selection table

Three phase 380V			
Model	Recommend power of braking resistor C10%braking	Recommend resistance value of braking resistor	Braking unit
VFD500-R75GT4B	100W	$\geq 200\Omega$	Built-in as standard
VFD500-1R5GT4B	150W	$\geq 180\Omega$	
VFD500-2R2GT4B	300W	$\geq 180\Omega$	
VFD500-4R0G/5R5PT4B	500W	$\geq 90\Omega$	
VFD500-5R5G/7R5PT4B	800W	$\geq 60\Omega$	
VFD500-7R5G/011PT4B	1000W	$\geq 60\Omega$	
VFD500-011G/015PT4B	1.2KW	$\geq 25\Omega$	
VFD500-015G/018PT4B	1.5KW	$\geq 25\Omega$	
VFD500-018G/022PT4B	2.0KW	$\geq 18\Omega$	
VFD500-022G/030PT4B	2.5KW	$\geq 18\Omega$	
VFD500-030G/037PT4	3.0KW	$\geq 12\Omega$	Built-in as option
VFD500-037G/045PT4	3.7 KW	$\geq 8\Omega$	
VFD500-045G/055PT4	4.5 KW	$\geq 8\Omega$	
VFD500-055G/075PT4	5.5 KW	$\geq 6\Omega$	
VFD500-075G/090PT4	7.5 KW	$\geq 6\Omega$	
VFD500-090G/110T4~ VFD500-710GT4	As per actual load and braking power		external

7.2 PG card type

The optional PG card and supported encoders for the VFD500 are shown in the table below.

Model	name	USAGE
MT500-PG-INC3	Incremental encoder PG card	Suitable for open collector, push-pull output, and differential output encoders.
MT500-PG-INC2	Incremental encoder PG card with frequency-dividable output	Suitable for open collector, push-pull output, and differential output encoders. Frequency division range: 0~63
MT500-PG-RT1	Resolver PG card	Adaptive resolver.

Chart 7-3 PG type view chart

(1) Incremental encoder PG card (INC3)




Figure 7-5 MT500-PG-INC3 incremental PG card

Table 7-11 Incremental encoder PG card (MT500-PG-INC3) port definition

Pin number diagram	Pin number	Name	Usage
	1	PE	Shielded terminal
	2	+15V	Power output, used to power the encoder (15V±2%, maximum 200mA)
	3	+5V	Power output, used to power the encoder (5V±2%, maximum 200mA)
	4	0V	Power and signal common terminal
	5	A-	Encoder A-signal
	6	A+	Encoder A+signal
	7	B-	Encoder B-signal
	8	B+	Encoder B+signal
	9	Z-	Encoder Z-signal
	10	Z+	Encoder Z+signal


Installation Diagram	Mark	Function																								
	SW1	<p>1 and 2 are used to select the filter level</p> <table><tr><th>Dial switch 1</th><th>Dial switch 2</th><th>Filter level</th></tr><tr><td>1</td><td>2</td><td>Level 1 filtering</td></tr><tr><td>ON</td><td>2</td><td>Level 2 filtering</td></tr><tr><td>1</td><td>ON</td><td>Level 3 filtering</td></tr><tr><td>ON</td><td>ON</td><td>Level 4 filtering</td></tr></table> <p>3 is used to start the orthogonal processing of pulse signals</p> <table><tr><th>Dial switch 3</th><th>D6 (Red light)</th><th>Status explanation</th></tr><tr><td>ON</td><td>On</td><td>Turn on orthogonal processing</td></tr><tr><td>3</td><td>Off</td><td>Turn off orthogonal processing</td></tr></table>	Dial switch 1	Dial switch 2	Filter level	1	2	Level 1 filtering	ON	2	Level 2 filtering	1	ON	Level 3 filtering	ON	ON	Level 4 filtering	Dial switch 3	D6 (Red light)	Status explanation	ON	On	Turn on orthogonal processing	3	Off	Turn off orthogonal processing
	Dial switch 1	Dial switch 2	Filter level																							
	1	2	Level 1 filtering																							
	ON	2	Level 2 filtering																							
1	ON	Level 3 filtering																								
ON	ON	Level 4 filtering																								
Dial switch 3	D6 (Red light)	Status explanation																								
ON	On	Turn on orthogonal processing																								
3	Off	Turn off orthogonal processing																								
SW4	<p>Y capacitor on PG card to ground enable selection</p> <ul style="list-style-type: none">➤ Turn it to ON to connect the Y capacitor to the ground.➤ Turn to 1 to disconnect the Y capacitor from the ground.																									
D5 (Green light)	On: indicates normal operation																									
D6 (Red light)	On: indicates orthogonal processing of pulse signals																									

Table 7-12 Installation position and function description of selector switches and indicator lights

◆ Wiring of open collector and push-pull output encoders:

When wiring, the PGA+, PGB+, and PGZ+ terminals of the PG card do not need to be wired, and the encoder signal output is connected to the PGA-, PGB-, and PGZ- terminals of the PG card, as shown in Figure 7-6.:




Figure 7-6 Wiring diagram of open collector and push-pull output encoders

◆ Differential output encoder wiring:

The wiring of the PG card and the encoder is connected one-to-one according to the silk screen, as shown in Figure 7-7:




Figure 7-7 Wiring diagram of differential output encoder

◆ Differential output encoder wiring :

Select the encoder power supply through SW3 on the PG card, SW1 and SW2 to the TP side, as shown below :




Chart 7-7 Differential output type encoder DIP switch selection

The wiring of the PG card and the encoder are connected one by one according to the silkscreen.

Pin number diagram	Pin number	Name	Usage
	1	PE	Shield terminal
	2	VCC	Power output for powering the encoder 5V \pm 2%, maximum 200mA 12V \pm 5%, maximum 200mA
	3	GND	Power supply common terminal and signal
	4	Z-	Encoder Z-signal
	5	Z+	Encoder Z+signal
	6	B-	Encoder B-signal
	7	B+	Encoder B+signal
	8	A-	Encoder A-signal
	9	A+	Encoder A+signal
	10	OZ	Z signal crossover output (NPN open collector type)
	11	OB	B-phase pulse frequency dividing output (NPN open collector type)
	12	OA	Phase A pulse divider output (NPN open collector type)
	13	OZ-	Z signal crossover output Z- (differential output type)
	14	OZ+	Z signal crossover output Z+ (differential output type)
	15	OB-	B-phase pulse divider output B- (differential output type)
	16	OB+	B-phase pulse divider output B+ (differential output type)
	17	OA-	Phase A pulse divider output A- (differential output type)
	18	OA+	Phase A pulse divider output A+ (differential output type)

(2) Incremental encoder PG card with Frequency division

The input signal of the MT500-PG-INC2 crossover PG card can be differential or open collector type, selected by the DIP switch; there are two sets of output signals, open collector type and differential output type; The card's port definition is shown in the table below.

Chart 7-8 Incremental encoder PG card with frequency division (MT500-PG-INC2) port definition

In the schematic diagram of the crossover card in Table 7-5, the dial switch indicates bit 0~bit5 of the frequency division number from right to left, the frequency division range is 0~63, and the frequency division number is set to 0 and 1 when there is no frequency division.

Frequency division corresponding to a single DIP switch


DIP switch	Number of frequency division
1	32
2	16
3	8
4	4
5	2
6	1

For example 35 frequency division $\approx 35 = 32+2+1$

Just turn the dial switches corresponding to the subscripts 1, 5, and 6 to "ON". Please refer to the description of MT500-PG-INC1 for encoder wiring of MT500-PG-INC2.

(3) Resolver PG card



Chart 7-9 Resolver PG Card (MT500-PG-RT1) interface Definition

Pin number diagram	Pin number	Name	Usage
 <p>CPORT TYPE:DB93</p>	1	EXCLO	Resolver excitation negative
	2	EXC	Resolver excitation positive
	3	SIN	Resolver feedback SIN positive
	4	SINLO	Resolver feedback SIN negative
	5	COS	Resolver feedback COS positive
	9	COSLO	Resolver feedback COS negative
	6,7,8	NC	Hanging in air

7.3 IO Extension card

◆ MT500-IOEX1 Extension card

- ◆ The MT500-IOEX1 expansion card is a multi-function IO expansion card for VFD530 series inverters. It can expand 4 channels of DI, 2 channels of AI, and 4 channels of DO. Among them, , AI4 can be used as an ordinary voltage input analog quantity, and can also be used as a temperature detection input of PT100/PT1000/KTY84-130 (temperature detection is connected to PT and COM).
- ◆ The terminal definitions of the MT500-IOEX1 expansion card are shown in Table 7-10

Terminal distribution	SN	Terminal name	Terminal function description																		
	1s10	GND	Analog ground, internally isolated from COM																		
	2	AI4	Analog input 4 Input 0~10V: input impedance 22KΩ																		
	3s6s16	COM	+24V, PT, PLC and digital input and output public terminal																		
	4	24V	Provides +24V power supply to the outside, generally used as digital input and output terminal working power supply and external sensor power supply																		
	5	PLC	Digital input power terminal																		
			It is used for switching between high and low level of switch input. It is short-circuited with +24V at the factory, that is, DI is active at low level.																		
			When the external power is input, disconnect the PLC from the +24V.																		
			It is a separate network from the PLC on the IO board and is used separately.																		
	7	PT	Support PT100/PT1000/KTY84-130 AI4 is inactive when using the temperature sensor direct connection function (temperature detection connection PT and COM)																		
			DIP switch switching mode: <table><tr><th>DIP switch</th><th>SW 1</th><th>SW 2</th><th>SW 3</th></tr><tr><td>AI4</td><td>ON</td><td>ON</td><td>ON</td></tr><tr><td>PT100</td><td>OFF</td><td>OFF</td><td>OFF</td></tr><tr><td>PT1000</td><td>OFF</td><td>OFF</td><td>ON</td></tr><tr><td>KTY84-130</td><td>OFF</td><td>ON</td><td>ON</td></tr></table>		DIP switch	SW 1	SW 2	SW 3	AI4	ON	ON	ON	PT100	OFF	OFF	OFF	PT1000	OFF	OFF	ON	KTY84-130
DIP switch	SW 1	SW 2	SW 3																		
AI4	ON	ON	ON																		
PT100	OFF	OFF	OFF																		
PT1000	OFF	OFF	ON																		
KTY84-130	OFF	ON	ON																		
8	DI9	Digital input 9	Input frequency: 0~200Hz Voltage range: 0~30V																		
9	DI7	Digital input 7																			
11	AI3	Analog input 3 input 0~10V																			
12	DO6	Open collector output 6	Voltage range:																		

				0~24V
	13	DO4	Open collector output 4	
	14	DO5	Open collector output 5	
	15	DO3	Open collector output 3	
	17	DI8	Digital input 8	Input frequency: 0~200Hz Voltage range: 0~30V
	18	DI6	Digital input 6	

7.4 CANopen extension card

The MT500-CAN1 communication card is a CANopen slave communication card for connecting VFD500 series inverters to the CANopen network. Please note that CANopen communication cannot be used simultaneously with Modbus communication.

Product Features:

Support Node Guard protocol, the master station can use this function to query device status;

Support the Heartbeat protocol, and the slave station periodically reports the current status to the primary station;

Support NMT network management protocol;

SDO only supports the accelerated transfer mechanism, which can transfer up to 4 bytes and can be used to read and write the inverter parameters.

Support 4 groups of PDO




Figure 7-11 CANOpen communication card and installation Diagram Table 7-12 CANOpen communication card hardware description

Graphic name	Description name	Function description
J1	Terminals	CANOpen bus terminal block, see description of Table 7-9
LED1	Power Indicator	Lights up to indicate normal power supply
Indicator light: Yellow light (1) Red light (2)	Status Indicator	Working status and fault indication: Yellow light (1) on: indicates normal operation Yellow light (1) flash: indicates communication initialization Red light (2) on: indicates internal communication failure Red light (2) flash: indicates CANOpen communication failure or bus off
SW1	DIP switch	Terminating resistor for setting the CANOpen bus

Table 7-9 Function description of J1 terminal block

Graphic name	Description name	Function description
1, 4	CANH	Signal line positive
2, 5	CANL	Signal line negative
3	GND	Signal ground

Chapter 8 Daily maintenance of frequency inverters

8.1 Daily maintenance

Due to the influence of temperature, humidity, dust and vibration, it will lead to poor heat dissipation and component aging of frequency inverter, and results in potential failure or reducing the service life of frequency inverter. Therefore, it is necessary to do daily and regular maintenance of the frequency inverter.

8.1.1 Daily maintenance

Due to the influence of temperature, humidity, dust and vibration, it will lead to poor heat dissipation and component aging of frequency inverter, and results in potential failure or reducing the service life of frequency inverter. Therefore, it is necessary to do daily and regular maintenance of the frequency inverter.

Daily check items:

- 1) Check if the sound is normal during the running of the motor;
- 2) Check if there is a vibration during the running of the motor;
- 3) check whether the installation environment of frequency inverter has changed;
- 4) Check if the cooling fan of frequency inverter is working correctly, the cooling air duct is clear;
- 5) Check if the frequency inverter is overheating;
- 6) Make sure that the frequency inverter should always be kept in a clean state;
- 7) Clear up effectively the dust on the surface of frequency inverter, prevent the dust from entering into the inside of frequency inverter, especially for the metal dust;
- 8) Clear up effectively the oil and dust on the cooling fan of frequency inverter.

8.1.2 Regular inspection

Please regularly check the frequency inverter, especially for the difficult checking place of running.

Regular inspection items:

- 1) Check the air duct and clear up regularly;
- 2) Check if there are any loose screws;
- 3) Check if the inverter has been corroded;
- 4) Check whether the wiring terminals show signs of arcing;
- 5) Main circuit insulation test.

Note: When using the megger (please use the DC 500V meg ohm meter) to measure the insulation resistance, you shall disconnect the main circuit with the frequency inverter. Do not use the insulation resistance meter to test the control circuit. It don't have to do the high voltage test (It has been done when the frequency inverter produced in factory.)

8.2 Wearing parts replacement

The vulnerable parts of the inverter mainly include cooling fans, electrolytic capacitors, relays, etc. The life of the inverter is closely related to the environment and maintenance conditions used. Table 8-3 lists the replacement time and causes of damage to the main components for reference. In addition, if abnormality is found during maintenance, please replace it in time.

Table 8-3 Spared parts replacement time

Spared parts	Replacing time	Damaged reasons	How to check
fans	30000 ~ 60000h	Bearing wear, blade aging	1, the blade has cracks 2 abnormal vibration, excessive noise
Electrolytic capacitor	40000 ~ 50000h	Poor input power quality, high ambient temperature, low air pressure, frequent load changes, electrolyte aging	1, there is liquid leakage 2, the safety valve protrudes 3, the capacitance value is beyond the allowable range 4, insulation resistance is abnormal 5, DC bus voltage fluctuations are too large
Relay	50000 ~ 100000 times	Corrosion, dust affect contact effect, contact action is too frequent	Contact ineffective

The user can refer to the accumulated power-on time and accumulated running time recorded by the inverter, and combine the actual operating conditions and the external environment to determine the replacement period.

- 1) Possible reasons for the damage of cooling fan: bearing wear and vane aging. Distinguish standard: Any cracks in the fan vanes, any abnormal vibration sound during the starting of frequency inverter.
- 2) Possible reasons for the damage of filter electrolytic capacitor: poor quality of the input power supply, the environment temperature is high, the load change frequently and the electrolyte aging. Distinguish standard: Any leakage of its liquid, if the safety valve is protruding, electrostatic capacitance and insulation resistance measurement.

8.3 Warranty Items

- 1) Warranty only refers to frequency inverter.
- 2) Under normal use, if there is any failure or damage, our company is responsible for the warranty within 18 months. (Leave factory date is subjected to the S/N on the frequency inverter nameplate or according to the contract). When over 18 months, reasonable fee will be charged for maintenance;
- 3) During the period of 18 months, if the following situation happens, certain maintenance fee will be charged;
 - a. The users don't follow the rules in the manual lead to the frequency inverter damaged;
 - b. The damage caused by fire, flood and abnormal voltage;
 - c. The damage caused by using the frequency inverter for abnormal functions;
 - d. The relevant service fee is calculated according to the manufacturer's standard, if there is an contract, then it is subject to the contract items.



For detailed warranty instructions, please refer to the Product Warranty Card.

Appendix A Modbus communication protocol

VFD500 series of inverter provides RS485 communication on interface, and adopts MODBUS communication protocol. User can carry out centralized monitoring through PC/PLC to get operating

requirements and user can set the running command, modify or read the function codes, the working state or fault information of frequency inverter by Modbus communication protocol. In addition VFD 500 can also be used as a host to broadcast with other VFD500 communication.


A.1 Protocol format

RS485 asynchronous half-duplex.

RS485 terminal default data format: 1-8-N-1 (1 start bit, 8 data bits, no parity, 1 stop bit), the default baud rate: 9600bps. See parameter group set 30.

A.2 Message format

The VFD500 series inverter Modbus message includes the start sign, the RTU message, and the end sign.



The RTU message includes the address code, the PDU (Protocol Data Unit, the protocol data unit), and the CRC check. PDU includes the function code and the data section.

RTU frame format :

Frame start (START)	More than the 3.5 byte transmission time	
Target station address (ADR)	Communication address:1 to 247(0: broadcast address)	
Command code (CMD)	Command code	Description
	0x03	Read multiple registers of the AC drive
	0x06	Write a single register to the AC drive.
	0x10	Write Multiple registers to the AC drive.
	0x08	Diagnostic command code
Number of function code	Including the register address (2Byte), the number of registers n(2Byte) and the register content (2nByte), etc. see A3 in detail	
CRC CHK low level	It indicates the replying data or the data waiting to write-in. CRC 16 check value, During the transmission, high bit is put in front and low bit is at the back. see detail in A.5 Chapter	
CRC CHK high level		
FRAME END	More than 3.5 byte transmission time	

A.3 Command code instruction

A.3.1 Command code 0x03 Read multiple registers or status words• **Request PDU**

Command code	1byte	0x03
initial address	2byte	0x0000~0xFFFF(high 8 bit in front)
Number of registers	2byte	0x0001-0x0010 (1~16,high 8 bit in front)

• **Response PDU**

Command code	1byte	0x03
Initial address	1byte	2*N (N means Number of Registers)
Number of registers	2* n byte	Register value high 8 bit in front, first send initial address' register value

• **Wrong PDU**

Command code	1byte	0x83
Abnormal code	1byte	See A.4Abnormal response information

Currently Modbus protocol 0x03 command code does not support cross-group read multiple function codes, it will be wrong if more than the current group of function code number

A.3.2 Command code 0x06 write single registers or status word command codes**Request PDU**

Command code	1byte	0x06
Initial address	2byte	0x0000~0xFFFF(high 8 bit in front)
Register value	2byte	0x0000~0xFFFF(register value high 8 bit in front)

• **Respond PDU**

Command code	1byte	0x06
Register address	2byte	0x0000~0xFFFF
Register value	2byte	0x0000~0xFFFF

• **Wrong PDU**

Command code	1byte	0x86
Abnormal code	1byte	See A4 Abnormal response information

A.3.3 Command 0x10write multiple registers or status word command codes• **Request PDU**

Command code	1byte	0x10
Initial address	2byte	0x0000~0xFFFF(high 8 bit in front)
Number of Register	2byte	0x0001~0x0010(1~16, high 8 bit in front)
Number of Byte	1byte	2n (n is number of Register)
Register Value	2* n byte	Register value high 8 bit

		in front, first send initial address' register value
--	--	--

- **Respond PDU**

Command code	1byte	0x10
Initial address	2byte	0x0000 ~ 0xFFFF(high 8 bit in front)
Number of register	2byte	1 ~ 16(1 ~ 16, high 8 bit in front)

- **Wrong PDU**

Command code	1byte	0x90
Abnormal Code	1byte	See Abnormal response information

A.3.4 Command code 0x08 Diagnostic function

- Modbus Command Code 0x08 Provide series of tests to check the communication system between the client (master) device and the server (slave) or various internal error conditions in the server.
- This function uses the sub-command code of 2 bytes inquiry to define the type of test to be performed. The server copies the command and subcommand codes in the normal response. Some diagnostics cause the remote device to return the data through the normally responding data fields.
- Diagnostic functions to remote devices generally do not affect the user program running in the device. The main diagnostic function of this product is not line diagnosis (0000), used to test the host from the machine is normal communication.
- Request PDU

Command code	1byte	0x08
Subcommand code	2byte	0x0000 ~ 0xFFFF
Data	2byte	0x0000 ~ 0xFFFF

Respond PDU

Command code	1byte	0x08
Subcommand code	2byte	0x0000
Data	2byte	Same as request of PDU

Wrong PDU

Command code	1byte	0x88
Abnormal code	1byte	See Abnormal response information

A.4 Abnormal response information

When the master device sends a request to the slave device, the master expects a normal response. The master's query may result in one of four events:

- (1) If the slave device receives a request for a communication error and the query can be processed normally, the slave device will return a normal response.
- (2) If the slave device does not receive the request due to a communication error, no information can be returned and the slave device times out.
- (3) If the slave device receives a request and detects a communication error (parity, address, framing error, etc.), no response is returned and the slave device times out.
- (4) If the slave device receives no communication error request, but can not handle the request (such as the register address does not exist, etc.), the slave station will return

an abnormal response to inform the master of the actual situation.

Abnormal response command code = normal response command code + 0x80,
Abnormal code value and meaning as shown in the following table

Error code	Name	Description
0x01	Invalid command code/error function code	The function code received by the slave is outside the configured range
0x02	Error data address/Illegal register address	Slave station receives the data address is not allowed address the number of registers being Read and write is out of range When writing multiple registers, the number of bytes in the PDU is not equal to the number of registers
0x03	wrong frame format	Length of frame is not correct CRC verifying not passed
0x04	Data is out of range	The data received by the slave exceeds the corresponding register minimum to maximum range
0x05	Reading request refuse	Operate to read-only register write Operate to read-only register write in running status

A.5 CRC check

CRC(Cyclical Redundancy Check)use RTU frame,The message includes an error detection field based on the CRC method. The CRC field examines the contents of the entire message. The CRC field is two bytes containing a binary value of 16 bits. It is calculated by the transmission equipment and added to the message. The receiving device recalculates the CRC of the received message and compares it with the value in the received CRC field, If the two CRC values are not equal, there is an error in the transmission. There is a lot of information on the Internet about CRC checking it is not elaborated hereabout CRC check code generation algorithm,

A.6 Register address distribution

The register address of VFD500 is 16-bit data, the upper 8 bits represent the function code group number, the lower 8 bits represent the group number, the upper 8 bits are sent before. The 32-bit register occupies two adjacent addresses, the even address stores the lower 16 bits, and the next address (odd address) of the even address stores the upper 16 bits.

In the register write operation, in order to avoid frequent damage caused by memory EEPROM write, using the highest bit of the register address indicates whether it save as EEPROM, the highest bit to be 1 indicates to save in EEPROM, 0 means save only in RAM. In other words, if you want to write the register value which is saved after power-off, you should add 0x8000 to the original register address.

VFD500 register address as follows :

Address space	Description
0x0000~0x6363 (Function code address space)	Rule: The upper 8 digits of the hexadecimal number indicate the group number (0 to 99), and the lower 8 digits indicate the serial number within the group (0 to 99). Example 1: Function code 27.10 (drive status word 1), which The hexadecimal address is: 0x1B0A (0x1B = 27, 0x0A = 10),

		Decimal address: $27 \times 256 + 10 = 6922$. Example 2: Function code 14.01 (digital setting of torque reference), when no EEPROM is stored, its The hexadecimal address is: 0x0E01 (0x0E = 14, 0x01 = 1), The decimal address is: $14 \times 256 + 1 = 3585$. If you want to save the content written in communication to EEPROM after power off, then The hexadecimal address is 0x8E01 (0x0E01 plus 0x8000), The decimal address is 36353 (3585 plus 32768). Note: The addresses calculated in hexadecimal or decimal are the same, and users can choose a familiar calculation method.																																
Communication special address	0x7000	Communication command. The values and functions are as follows: 0x0000:disable command : 0x0001:forward running: 0x0002:reverse running: 0x0003:forward jog: 0x0004:reverse jog: 0x0005:free stop: 0x0006:decelerating stop: 0x0007:immediate stop: 0x0008:fault reset:																																
	0x7001	Communication speed given. The unit of this register can be set by P30.14. 0.01%(-100.00% ~ 100.00%) 0.01Hz(0 ~ 600.00Hz) 1Rpm(0 ~ 65535Rpm)																																
	0x7002	Communication Torque given.0.01%(-300.00% ~ 300.00%)																																
	0x7003	Communication upper frequency given. The unit of this register can be set by P30.14. Different units range same as 0x7001.																																
	0x7004	Torque mode speed limit. The unit of this register can be set by P30.14. Different units range same as 0x7001.																																
	0x7005	Electric torque limit 0.1%(0~300.0%)																																
	0x7006	Power generation torque limit 0.1%(0~300.0%)																																
	0x7007	PID setting source.0.01%(-100.00% ~ 100.00%)																																
	0x7008	PID feedback source 0.01%(-100.00% ~ 100.00%)																																
	0x7009	VF separation voltage given.0.1%(0~ 100.0%)																																
	0x700A	External fault setting																																
	0x700B	DO status setting. When the DO function (please refer to P07.01 ~ P07.10) is set to 0 (no function), its status comes from the setting of the communication dedicated register, and the corresponding bit of 1 means it is valid. The bits of this register are defined as follows: <table><tr><td>Bit7</td><td>Bit6</td><td>Bit5</td><td>Bit4</td><td>Bit3</td><td>Bit2</td><td>Bit1</td><td>Bit0</td></tr><tr><td></td><td></td><td></td><td></td><td>RL2</td><td>RL1</td><td>DO2</td><td>DO1</td></tr><tr><td>Bit15</td><td>Bit14</td><td>Bit13</td><td>Bit12</td><td>Bit11</td><td>Bit10</td><td>Bit9</td><td>Bit8</td></tr><tr><td></td><td></td><td></td><td></td><td></td><td></td><td>VDO2</td><td>VDO1</td></tr></table>	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0					RL2	RL1	DO2	DO1	Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8							VDO2	VDO1
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0																											
				RL2	RL1	DO2	DO1																											
Bit15	Bit14	Bit13	Bit12	Bit11	Bit10	Bit9	Bit8																											
						VDO2	VDO1																											

2. Inverter status: Read the inverter status, see 27 groups of function codes.

3) Inverter fault description: read the inverter fault see 25.00 function code (0x1900)

VFD Fault address	VFD trip information	
0x1900(25.00 function code)	0000:no fault	0015:current detection fault
	0001:SC protection	0016:PG card feedback fault
	0002:overcurrent during acceleration	0017:Encoder zero detection fault
	0003:overcurrent during deceleration	0018:Reserved
	0004:overcurrent at constant speed	0019:overspeed
	0005:overvoltage during acceleration	001A:too large speed deviation
	0006:overvoltage during deceleration	001B: motor auto tuning fault 1
	0007:overvoltage at constant speed	001C: motor auto tuning fault 2
	0008:low voltage fault	001D: motor auto tuning fault 3
	0009:contactor open	001E:motor auto tuning fault 4
	000A:VFD overload	001F:off load
	000B:motor overload	0020:Eeprom read and write fault
	000C:power input phase loss	0021:Reserved
	000D:power output phase loss	0022:Communication time out fault
	000E:IGBT module overheat	0023:extension card fault
	000F:Reserved	0024:PID feedback lost during running
	0010:motor over heat	0025>User-defined fault 1
	0011:fast overcurrent time out fault	0026>User-defined fault 2
	0012:Ground fault	
	0013:motor auto tuning fault reserved	
	0014:drives temperature detection fault	

A.7 Register data type

There are several types of register data, and each type of communication setting method is shown in the following table:

Types of register data	Communication setting method
16-bit unsigned number	0~65535 corresponds to 0xFFFF; the decimal point does not need to be processed. Example, Set P00.07 to 40.00Hz: Write 0x0FA0 to the 0x0007 address.
16-bit signed number	-32768~32767 corresponds to 0x8000~0x7FFFF. Example: Set P14.01 to -50.0%: Write 0xFE0C to the 0x0E01 address.
Binary number	Represents a value of 16 bits. For example, the content of the 0x0600 address is 0x0012, which means: Bit1 of r06.00=1, bit4=1; that is, DI1 and DI5 (HDI) are valid.
"One hundred thousand" type	"Units" ~ "Thousands" correspond to 0~3bit, 4~7bit, 8~11bit, 12~15bit respectively. Example: Set the "Unit'digit" of P40.04 to AI1 and "ten's digit" to AI2: Write 0x0021 to the 0x2804 address.

32-bit unsigned number	<p>The contents of the two registers need to be combined into 32-bit numbers.</p> <p>For example, read the meter r16.00:</p> <p>Step 1: Read 2 registers from the starting address 0x1000</p> <p>Step 2: Watt-hour meter reading = ((UInt32)0x1001 value<<16) + 0x1000 value</p>
32-bit signed number	<p>Similar to 32-bit unsigned numbers. The value of the even address is still the lower 16 bits, and the value of the next address (odd number) of the even address indicates the upper 16 bits.</p>

A.8 The inverter acts as a Modbus master

VFD500 can be used as a Modbus master station, it currently only supports broadcast network. When P30.09 is set as 1, master mode can be enabled. The sending frame as master station is as follows:

0x00	0x06	0x70	<u>N</u>	<u>ValH</u>	<u>ValL</u>	CRCL	CRCH
-------------	-------------	-------------	-----------------	--------------------	--------------------	-------------	-------------

Instruction :

1. N indicates the slave register of the operation which is set by P30.10.
2. Val means the data sent, Val = (ValH << 8) + ValL, the function code P30.11 is to select the contents of the data sent.
3. The idle time between frame and frame is set by function code P30.12.



4F, Building 5, Dongluyang Industrial ,Park,
No. 4, Tengfeng 4th Road, Fuyong Phoenix
Third, Industrial Zone, Baoan District,
Shenzhen